



RECEIVED .

JAN 09 2004

Technology Center 2100

**VIRTUAL LINE REPLACEABLE UNIT FOR A PASSENGER ENTERTAINMENT SYSTEM,
METHOD AND ARTICLE OF MANUFACTURE**

COPYRIGHT NOTIFICATION

- 5 Portions of this patent application contain materials that are subject to copyright protection. The copyright owner has no objection to the facsimile reproduction by anyone of the patent document, or the patent disclosure, as it appears in the Patent and Trademark Office.

FIELD OF THE INVENTION

- 10 The present invention relates to providing entertainment to passengers in a vehicle, and more specifically, to systems, methods and articles of manufacture that provide for a networked passenger entertainment system that integrates audio, video, passenger information, product ordering and service processing, communications, and maintainability features, and permits passengers to selectively order or request
- 15 products and services, receive video, audio and game data for entertainment purposes, and communicate with other passengers and computers on- and off-board the aircraft, and which thereby provides for passenger selected delivery of content over a communication network.

BACKGROUND OF THE INVENTION

- 20 The assignee of the present invention manufactures in-flight aircraft passenger entertainment systems. Such systems distribute audio and video material to passengers derived from a variety of sources. For example, such systems provide passengers with audio generated from audio tape players, movies derived from video tape players, and interactive services such as games, shopping and
- 25 telecommunications. A variety of inventions have been patented by the assignee of the present invention and others relating to in-flight aircraft entertainment systems and their components. Certain of these prior art systems and components are summarized below.

- 30 US Patent No. 3,795,771 entitled "Passenger Entertainment/Passenger Service and Self-Test System" discloses a time multiplexed passenger entertainment and service combined system suitable for distribution throughout compartments of super aircraft.

Common power supplies, cabling, and boxes, and hybrid microelectronics and/or medium or large scale MOSFET integrated circuit chips are employed. A main multiplexer receives passenger address or tape deck analog signals and converts them to a pulse code modulated digital bit stream which is time shared between channels. A
5 coaxial cable transmits the bit stream to compartment submultiplexers. Each submultiplexer receives the digital bit stream, optionally inserts into the bit stream bits representing analog-to-digital converted movie audio or compartment introduced passenger address and distributes the data stream along four columns of seat group units on individual column coaxial cables. At each seat group unit a demultiplexer of a
10 seat group demultiplexer/encoder converts the bit stream into the original analog signals, amplifiers the analog signals and drives individual seat transducers for passenger listening.

A passenger control unit provides channel and volume level selection. The passenger service system provides control functions comprising reading light, stewardess call
15 (aisle and control panel lights and chimes). The service system comprises a section timer/decoder to generate binary logic pulses which are transmitted by cable sequentially down and up the seat columns from seat group unit to seat group unit. A similar cable connects the corresponding overhead unit containing the reading lights, etc. to the section timer/decoder. The seat encoder of each seat group demultiplex-
20 er/encoder receives digital interrogating signals, processes them relative to switch positions determined by the passenger and sends out results to the section timer/decoder. The overhead decoder of each seat group receives the retransmitted digital signals from the section timer/decoder and performs switching functions conforming to seat encoder commands. The system incorporates a self-test subsystem comprising a test signal
25 generator and circuits operating in conjunction with the entertainment and service system circuits.

US Patent No. 5,289,272 entitled "Combined Data, Audio and Video Distribution System in Passenger Aircraft" discloses a passenger aircraft video distribution system that distributes modulated RF carrier signals from a central signal source to be used at
30 each passenger seat. The carriers are modulated to contain audio, video also other digital data, such as graphics, and slide shows and the like. Analog video signals from the video source are modulated on individually discrete carriers in the range of 54 to 300 megahertz. Audio information, including audio sound channels and the video audio, are digitized and combined with digital data in a combined serial bit stream that

is multiplexed, and then modulated on an RF carrier having a frequency sufficiently above the frequency band of the video signals so that the resulting spectrum of the modulated audio RF carrier does not interfere with the modulated video carriers. The RF carrier signals are combined and distributed to individual seats. The modulated
5 audio carrier is separated from the video carriers at each seat or each group of seats and then demodulated and demultiplexed for selection at each individual seat of a chosen audio channel.

US Patent No. 4,866,515 entitled "Passenger Service and Entertainment System for Supplying Frequency-Multiplexed Video, Audio, and Television Game Software Signals
10 to Passenger Seat Terminals" discloses a service and entertainment system for transmitting video signals, audio signals and television game software signals from a central transmitting apparatus to each of a plurality of terminals mounted at respective passenger seats in an aircraft, or at respective seats in a stadium, or theater, or the like. The video signals, audio signals and television game software signals are
15 frequency-multiplexed and then transmitted to the terminals, so that desired ones of the frequency-multiplexed signals can be selected at each terminal unit.

US Patent No. 4,647,980 entitled "Aircraft Passenger Television System" discloses a television system that provides for individualized program selection and viewing by aircraft passengers. The system comprises a plurality of compact television receivers
20 mounted in front of each airline passenger in a rearwardly facing position within the passenger seat immediately in front of each passenger. Each television receiver is provided as a lightweight module adapted for rapid, removable installation into a mounting bracket opening rearwardly on the rear side of a passenger seat, with a viewing screen set at a tilt angle accommodating an average reclined position of the
25 seat. Exposed controls permit channel and volume selection by the individual passenger, and an audio headset is provided for plug-in connection to the module. A broadcast station on the aircraft provides prerecorded and/or locally received programs on different channels to each television module for individual passenger selection.

US Patent No. 4,630,821 entitled "Video Game Apparatus Integral with Aircraft
30 Passenger Seat Tray" discloses a video game apparatus employed by a passenger of an aircraft. The apparatus includes a tray that is mounted on the rear of an aircraft seat. The tray has an internal hollow with a rectangular aperture on a top surface which surface faces the passenger when the tray is placed in a usable position. Located in the

rectangular aperture is a TV display screen. Located in the internal hollow of the tray is a video game apparatus that operates to provide a video game display on the surface of said TV display screen. The surface of the tray containing the TV display screen also includes a plurality of control elements that are coupled to the video game apparatus to enable the passenger to operate the game. To energize the game, the tray contains a cable coupling assembly whereby when a cable is inserted into the assembly, the video game is energized to provide a display of a game selected by means of a selector switch also mounted on the top surface of the tray.

US Patent No. 4,352,200 entitled "Wireless Aircraft Passenger Audio Entertainment System" discloses that audio information in several audio channels is supplied via headsets to passengers seated aboard an aircraft in rows of seats including armrests and being distributed along an elongate passenger section inside a metallic fuselage. An antenna is run along the elongate passenger section of the aircraft for radio transmission inside such elongate passenger section. Individual antennas are provided for the passenger seats for receiving the latter radio transmission. These receiving antennas are distributed among predetermined armrests of the passenger seats. The audio information to be transmitted is provided in radio frequency channels in a band between 72 and 73 MHz. The distributed receiving antennas are coupled via seated passengers to the transmitting antenna. The radio frequency channels are transmitted in the mentioned band via the transmitting antenna, seated passengers and distributed receiving antennas to the predetermined armrests. Audio information is derived in the audio channels from the transmitted radio frequency channels also in the predetermined armrests. Passengers are individually enabled to select audio information from among the derived audio information in the audio channels. The selected audio information is applied individually to the headsets.

US Patent Nos. 5,965,647 and 5,617,331 entitled "Integrated Video and Audio Signal Distribution System and Method for use on Commercial Aircraft and Other Vehicles" disclose passenger entertainment systems employing an improved digital audio signal distribution system and method for use on commercial aircraft and other vehicles. A plurality of digital audio signal sources are provided for generating a plurality of compressed digital audio signals. The compressed digital audio signals are provided to a multiplexer that domain multiplexes the signals to produce a single composite digital audio data signal. The composite digital audio data signal is provided to a demultiplexer which is capable of selecting a desired channel from the composite digital

audio data signal. The selected channel is provided to a decompression circuit, where it is expanded to produce a decompressed digital output signal. The decompressed digital output signal is then provided to a digital-to-analog converter and converted to an analog audio signal. The analog audio signal is provided to an audio transducer.

5 While the above patents disclose various aspects of passenger entertainment systems and components used therein, none of these prior art references disclose a fully integrated networked passenger entertainment system that integrates audio, video, product ordering and service processing, networked communications, and maintainability features. Accordingly, it is an objective of the present invention to
10 provide for systems and methods that implement an integrated networked passenger entertainment and communication system that provides for passenger selected delivery of content over a communication network. It is a further objective of the present invention to provide for systems and methods that permit passengers to selectively order or request products or services, receive audio, video and game data, that permits
15 communication of information to passengers from aircraft personnel, and that permits passengers to communicate with other passengers and computers located on- and off-board an aircraft.

SUMMARY OF THE INVENTION

The foregoing problems are overcome in an illustrative embodiment of the invention in
20 which a computer manages communication over a network between one or more network addressable units and a plurality of physical devices of a passenger entertainment system on a vehicle. The passenger entertainment system is configured and operated using software to provide passenger entertainment services including audio and video on-demand, information dissemination, product and service order
25 processing, video teleconferencing and data communication services between passengers on-board the vehicle using a local networks, and between passengers and people and computers off-board the vehicle using a communications link.

The passenger entertainment system includes a system server and a network for
30 supporting a plurality of computer processors that are each coupled to a video camera, a microphone, a video display, an audio reproducing device, and an input device located proximal to a plurality of seats. The computer processors and the system server comprise application software that selectively controls telephony applications and

network services. The system server has a plurality of interfaces that interface to components (physical devices) of the passenger entertainment system.

5 In carrying out the present invention, the system server is coupled by way of the network to a plurality of physical devices. The system server comprises software for instantiating a dispatch object to open a framework for one or more network addressable unit objects. The system server comprises software for instantiating one or more virtual line replaceable unit objects to manage communication between a network address unit and one or more physical devices. The system server comprises software
10 for communicating network messages through the dispatch object to the one or more network addressable unit objects to the one or more physical devices to control one or more aspects of the passenger entertainment system.

The dispatch object contains logic that tracks messages to the one or more physical
15 devices utilizing a queue, logic that tracks messages from the one or more physical devices utilizing a queue, and logic that converts messages from a first format to a second format. The dispatch object maintains the status of related devices. The dispatch object also contains logic for adding and removing one or more of the network addressable unit objects. The network addressable unit objects include logic for moving
20 data from one storage location to another.

BRIEF DESCRIPTION OF THE DRAWINGS

The various features and advantages of the present invention may be more readily
25 understood with reference to the following detailed description taken in conjunction with the accompanying drawings, and in which:

Figure 1 illustrates an operational environment depicting a total entertainment system in accordance with a preferred embodiment;

Figure 2 is an exemplary block diagram of an embodiment of the total entertainment system;

30 Figure 3 shows a detailed block diagram of the total entertainment system of Figure 2;

Figure 4 shows a diagram illustrating a typical hardware configuration of a workstation employed in accordance with a preferred embodiment;

Figure 5 is a diagram illustrating head end equipment in accordance with a preferred embodiment;

- 5 Figure 5a is a diagram illustrating distribution of QAM digital audio in accordance with in accordance with a preferred embodiment;

Figure 6 is a block diagram of area distribution equipment in accordance with a preferred embodiment;

- 10 Figure 7 is a block diagram of seat group equipment in accordance with a preferred embodiment;

Figure 7a is a block diagram of the seat controller card of the seat group equipment in accordance with a preferred embodiment;

Figure 7b illustrates a typical fixed passenger control unit;

- 15 Figure 8 is a block diagram of overhead equipment in accordance with a preferred embodiment;

Figure 9 is a block diagram of an Airplane Configuration System (ACS) tool used in accordance with a preferred embodiment;

Figure 10 is a block diagram of the software architecture in accordance with a preferred embodiment;

- 20 Figure 11 illustrates message processor function and data paths;

Figure 12 illustrates operational flow of an ARCNET driver;

Figure 13 illustrates primary access terminal network addressable unit function and data paths;

Figure 14 illustrates transaction dispatcher function and data paths;

- 25 Figure 15 illustrates system monitor function and data paths;

Figure 16 illustrates primary access terminal RPC client.DLL function and data paths

Figure 17 illustrates backbone network addressable unit function and data paths;

Figure 18 illustrates seat network addressable unit function and data paths;

Figure 19 illustrates VCP network addressable unit function and data paths;

5 Figure 20 illustrates Test Port network addressable unit function and data paths; and

Figure 21 illustrates Services function and data paths.

DETAILED DESCRIPTION

System Overview

Figure 1 illustrates an operational environment depicting an exemplary total
10 entertainment system **100** in accordance with a preferred embodiment. The
operational environment shown in Figure 1 depicts a flight of an aircraft **111** employing
the total entertainment system **100**. The total entertainment system **100** comprises an
integrated networked passenger entertainment and communication system **100** that
provides for in-flight passenger entertainment and information dissemination, service
15 and product order processing, video teleconferencing and data communication between
passengers on-board the aircraft **111**, and video teleconferencing, voice and data
communication between passengers **117** on-board the aircraft **111** and people and
computers on the ground using local networks and the Internet **113**. The present
invention thus provides for a level of capabilities and services heretofore unavailable in
20 any airborne passenger entertainment system.

The system **100** is comprised of four main functional areas including head end
equipment **200**, area distribution equipment **210**, seat group equipment **220**, and
overhead equipment **230**. The head end equipment **200** provides an interface to
external hardware and operators. The area distribution equipment **210** routes signals
25 to and/or from the head end equipment **200**, the seat group equipment **220**, and the
overhead equipment **230**, depending upon the type of service provided to or requested
by the passengers. The seat group equipment **220** contains passenger control units
(PCU) **121** and screen displays **122** for use by the passengers **117**. The overhead
equipment **230** includes video monitors and/or projectors and bulkhead screens or

displays for displaying movies and other information. The system **100** thus routes or otherwise displays information to the passengers either under control of the flight attendants or passengers **117**.

5 Video conferencing data and computer data derived from ground based computers **112** connected to the Internet **113** are transferred over the Internet **113** to a satellite ground station **114** and are uplinked to a communications satellite **115** orbiting the Earth. The communications satellite **115** downlinks the video conferencing and/or computer data to the aircraft **111** which is received by way of an antenna **116** that is part of a satellite communications system employed in the head end equipment **200** of
10 the system **100**. In a similar manner, video conferencing data and/or computer data derived from passengers **117** on-board the aircraft **111** is uplinked to the satellite **115** by way of the satellite communications system and antenna **116** to the satellite **115**, and from there is downlinked by way of the satellite ground station **114** and Internet **113** to the ground based computer **112**.

15 One or more satellites **115**, which may be the same as or different from the satellites **115** used for Internet communication, transmit television signals to the aircraft **111**. One currently deployed satellite television broadcast system is the DIRECTV system that has orbiting satellites **115** that may be used to transmit television programs to the aircraft **111**, in a manner similar to ground-based systems used in homes and
20 businesses. In the present system **100**, however, a steerable antenna **116** is used to track the position of the satellite **115** that transmits the signals so that the antenna **116** remains locked onto the transmitted signal.

Handheld or fixed passenger control units **121** and seatback screen displays **122** (seat displays **122**) are provided at each passenger seat **123** that permit the passengers **117**
25 to interface to the system **100**. The passenger control units **121** are used to control downloading of movies for viewing, select audio channels for listening, initiate service calls to flight attendants, order products and services, and control lighting. The passenger control units **121** are also used to control game programs that are downloaded and played at the passenger seat **123**. In addition, the passenger control
30 units **121** are also used to initiate video conferencing and computer data transfer sessions either within the aircraft or with ground based computers **112**.

The present system **100** thus provides for an integrated and networked passenger entertainment and communication system **100** that in essence functions as an airborne intranet that provides a level of passenger selected and controlled entertainment and communications services, passenger services and product ordering services that has
5 heretofore not been provided to aircraft passengers.

Figure 2 is an exemplary block diagram of an embodiment of a total entertainment system **100** that is employed on the aircraft **111**, and illustrates inputs, outputs and interfaces of the system **100**. The system **100** comprises the head end equipment **200**, the area distribution equipment **210**, the seat group equipment **220**, and the overhead
10 equipment **230**. The head end equipment **200** and the seat group equipment **220** include a variety of computer processors and operating software that communicate over various networks to control and distribute data throughout the aircraft **111** and send data to and receive data from sources external to the aircraft **111**. A detailed embodiment of the total entertainment system **100** is shown in Figure 3, which will be
15 described after discussing a representative hardware environment that is useful in understanding the system **100** and its operation that is presented in Figure 4.

An embodiment of the system **100** is practiced in the context of a personal computer such as the IBM PS/2, APPLE MACINTOSH computer or UNIX based workstation. A representative hardware environment is depicted in Figure 4, which illustrates a typical
20 hardware configuration of a workstation in accordance with a preferred embodiment having a central processing unit **310**, such as a microprocessor, and a number of other units interconnected via a system bus **312**. The workstation shown in Figure 4 includes a random access memory (RAM) **314**, read only memory (ROM) **316**, an I/O adapter **318** for connecting peripheral devices such as disk storage units **320** to the
25 bus **312**, a user interface adapter **322** for connecting a keyboard **324**, a mouse **326**, a speaker **328**, a microphone **332**, and/or other user interface devices such as a touch screen (not shown) to the bus **312**, communication adapter **334** for connecting the workstation to a communication network (e.g., a data processing network) and a display adapter **336** for connecting the bus **312** to a display device **338**. The workstation
30 typically has resident thereon an operating system such as the MICROSOFT WINDOWS NT or WINDOWS/95 operating system (OS), the IBM OS/2 operating system, the MAC OS, or UNIX operating system. Those skilled in the art will appreciate that the present invention may also be implemented on platforms and operating systems other than those mentioned.

Detailed System Description

The in-flight entertainment system **100** in accordance with a preferred embodiment is a complex system with many components and that forms a total entertainment system (TES) **100**. To assist the reader in making and utilizing the invention without undue experimentation, the following is a detailed description that discusses some of the components and a typical system configuration. The system **100** in accordance with a preferred embodiment is a configurable and scaleable in-flight entertainment system **100** that provides a wide range of passenger entertainment, communications, passenger service, and cabin management services. A fully capable system **100** provides passengers with audio entertainment, video entertainment, video games, and other interactive and communications services.

The system **100** shown in Figure 1 and 2 has four main functional areas comprising: 1) head end equipment **200**, 2) area distribution equipment **210**, 3) seat group equipment **220**, and 4) overhead equipment **230**. Figure 3 shows the four functional areas and the line replaceable units (LRU) that comprise a typical passenger entertainment system **100**. An overview of the LRUs in each of the functional areas is described in the following paragraphs.

The head end equipment **200** is the prime interface between external hardware and operators (purser and flight attendants). The head end equipment **200** includes an operator interface, an aircraft interface, a maintenance interface, and an interface for downloading configuration data to the system **100** and for downloading reports from the system.

The head end equipment **200** shown in Figure 3 comprises a primary access terminal (PAT) **225** and a cabin file server (CFS) **268** that are used to control the system **100**. The cabin file server **268** is a system controller that controls many of the system functions, such as interactive functions, and stores the system configuration database and the application software. The cabin file server **268** communicates with other components within the head end equipment **200** via an ARCNET interface **216**. The cabin file server may be a computer terminal as shown in Figure 4 that includes a hard disk drive and a database that stores the system **100** configuration and other system **100** information.

The cabin file server **268** is coupled to the primary access terminal **225** and to a printer **226** by way of an Ethernet network **228**, such as a 100 Base-T Ethernet network, for example. Flight attendant workstations **225a** are also coupled to the cabin file server **268** by way of the Ethernet network **228**. A media file server **211** is controlled from the cabin file server **268** by way of an ARINC 485 (RS-485) network **229** coupled therebetween. The cabin file server **268** is optionally coupled to a BIT/BITE tester **221** that is used to perform built in testing operations on the system **100**.

The cabin file server **268** provides the following functions: processes and stores transaction information from passengers; stores passenger usage statistics for movies, games, and shopping; stores passenger survey responses; stores flight attendant usage statistics for login/logout; provides flight attendant access control; controls the video reproducers; controls the landscape camera; controls the PVIS line replaceable unit; stores seat application software and game software; distributes seat application and game software via the RF distribution system; provides power backup sufficient to allow orderly automatic shutdown of the cabin file server **268** operating system when primary power is removed; provides indicators representing power, operational status, and communication status; downloads databases via the RF distribution system; provides the ability to print reports; and provides connectors for a keyboard, monitor, and mouse.

The primary access terminal **225** shown in Figure 3 provides an operator interface to the system **100**, enabling an operator to centrally control a video reproducer **227** and the media server **211**, start BITE, control the landscape cameras **213**, and other functions provided in the system **100**. The primary access terminal **225** may also be a computer terminal as shown in Figure 2 that may include a hard disk drive and a display **338** for graphical user interface (GUI) by a flight attendant to the system **100**. The display may be a touch screen display to access the system **100**. A keyboard (not shown) may also be provided to access the system **100**. The primary access terminal **225** is used to configure the system **100** to set up the entertainment options that are available to passengers **117**. The flight attendant workstations **225a** are distributed throughout the aircraft **111** and allow flight attendants to respond to passenger service requests and to process orders and monetary transactions.

The primary access terminal **225** provides the following functions: a flight attendant interface to the cabin sales capability, a flight attendant interface to the video

entertainment capability, a flight attendant interface to the report and receipt printing capability, monitoring of video and audio output from the video reproducer, maintenance personnel interface to system diagnostics and status reports, power backup sufficient to allow an orderly shutdown of the primary access terminal
5 operating system when primary power is removed, indicators representing power, operational status, and communication status, single and dual plug stereo audio jack, magnetic card reader, and floppy disk drive.

The head end equipment **200** comprises the media server **211** that is coupled to a first video modulator **212a**. The media server **211** may be one manufactured by Formation,
10 for example. The media server **211** supplies 30 independent streams of video, and stores about 54 hour of video. The first video modulator **212a** may be one manufactured by Olsen Technologies, for example. The video reproducer **227** (or video cassette player **227**), such as a triple deck player manufactured by TEAC, for example, is also coupled to the first video modulator **212a**. The video cassette player **227** may be
15 three 8-mm Hi-8 video cassette players that output three video programs on three video channels under control of a flight attendant.

The video reproducer **227** (or video cassette player **227**) outputs an NTSC video (and audio) streams corresponding to a first plurality of prerecorded video channels. The media server **211** stores and outputs a plurality of quadrature amplitude modulated
20 MPEG-compressed video transport streams corresponding to a second plurality of prerecorded video channels. The first video modulator **212a** modulates both the NTSC video streams from the video reproducer **227** and the quadrature amplitude modulated MPEG-compressed video streams from the media server **211** to produce modulated RF signals that are distributed to passenger seats **123** of the aircraft **111**.

25 The head end equipment **200** also comprises one or more landscape cameras **213** and a passenger video information system (PVIS) **214** that are coupled to a second video modulator **212b**. The landscape cameras **213** may be cameras manufactured by Sexton, or Puritan Bennett, for example. The second video modulator **212b** may also be one manufactured by Olsen Technologies, for example. The passenger video information
30 system **214** may be a unit manufactured by AIRSHOW, for example.

The head end equipment **200** comprises first and second passenger entertainment system controllers (PESC-A, PESC-V) **224a**, **224b**, that comprise video, audio and

telephone processors. Although only one unit is shown in Figure 3, in certain configurations, primary and secondary PESC-A controllers **224a** may be used. The second video modulator **212b** routes RF signals through the first video modulator **212a**, and the outputs of both video modulators **212a**, **212b** are routed through the
5 second passenger entertainment system controller (PESC-V) **224b** to the first passenger entertainment system controller (PESC-A) **224a**. The first passenger entertainment system controller (PESC-A) **224a** is used to distribute video and data by way of an RF cable **215** and an ARCNET network **216**, to area distribution equipment **210** that routes the video and data to the passenger seats **123**. The ARCNET network **216** is
10 used to send control signals between components of the head end equipment and the components of the seat group equipment **220**. The PESC-A **224a** also provides an interface to the overhead equipment **230**.

The first passenger entertainment system controller (PESC-A) **224a** is coupled to the cabin file server **268** by way of the ARCNET network **216**, and is coupled to the primary
15 access terminal (PAT) **225** and the second passenger entertainment system controller (PESC-V) **224b** by way of the ARCNET network **216**. The first passenger entertainment system controller (PESC-A) **224a** is also coupled to a public address (PA) system **222**, to an audio tape reproducer (ATR) **223**, and to a cabin telephone system (CTS) **239**. The audio tape reproducer **223** may be one manufactured by Sony or Matsushita, for
20 example. The cabin telephone system **239** may be systems manufactured by AT&T or GTE, for example. Signals associated with the cabin telephone system **239** are routed through the system **100** by means of a CEPT-E1 network **219**.

The passenger entertainment system audio controller (PESC-A) **224a** and the passenger entertainment system video controller (PESC-V) **224b** are similarly designed and have
25 similar capabilities. However, some features are implemented only in the PESC-A **224a** or only in the PESC-V **224b**. The passenger entertainment system controller software implements specific features particular to the PESC-A **224a** or PESC-V **224b**.

The passenger entertainment system controller performs the following functions:
30 digitizes up to 32 audio inputs from entertainment and video audio sources, RF modulates the digital data, mixes the RF digital audio data with the RF input from a VMOD or another passenger entertainment system controller, outputs the combined RF video carrier and RF digital audio information to the RF distribution system, inputs up to five analog inputs, and multiplex in any combination to a maximum of five analog

outputs, provides programmable volume control of the five analog outputs, provides RS-232, RS-485, ARINC-429, and ARCNET communications interfaces, provides input
discretes for the control and distribution of PA audio to the seats, provides input and
output discretes for the control and distribution of video announcement audio to the
5 overhead PA system of the aircraft **111**, provides input discretes for passenger
entertainment system controller type and address information, provides input discrete
for aircraft status (in air/on ground), amplifies output RF, software monitorable and
controllable, provides an external test/diagnostic communication port, provides
indicators representing power, operation status, and communication status, provides
10 telephone control and distribution (PESC-A **224a** only), and provides a fault depository
for BIT data (PESC-A primary **224a** only).

Referring now to Figure 5, it shows a simplified diagram of the system **100** and
illustrates distribution of video signals from the video cassette player **227** and media
server **211** to the seat displays **122**. To implement video on demand in accordance
15 with a preferred embodiment, the media server **211** outputs 30 digital MPEG-
compressed video transport streams on three video channels (ten streams each), while
the video cassette player **227** outputs three video streams on three video channels.

To gain extra throughput, the 30 digital MPEG compressed video streams output by the
media server **211** are 64-value quadrature amplitude modulated (QAM). However, it is
20 to be understood, however, that by using 256-value QAM encoding, for example, the
number of video programs delivered in each video channel may be further increased.
Consequently, the present system **100** is not limited to any specific QAM encoding
value.

The video streams from the video cassette player **227** and the quadrature amplitude
25 modulated MPEG compressed video transport streams from the media server **211** are
then modulated by the first video modulator **212a** for transmission over the RF cable
215 to an audio-video distribution unit **231** at each of the passenger seats **123**. To
provide first class passengers **117**, for example, with true video on demand, the
streams are controlled by the passengers **117**, with one stream assigned to each
30 passenger that requests video services.

The simultaneous transfer of video streams derived from both the video cassette player
227 and the media server **211** in an aircraft entertainment system is considered

unique. In particular, conventional systems either process analog (NTSC) video signals or digital video signals, but do not process both simultaneously. However, in the present system **100**, NTSC and quadrature amplitude modulated MPEG-compressed digital video signals are processed simultaneously through the first video modulator **212a** and distributed to passenger seats **123** for display.

The first passenger entertainment system controller (PESC-A) **224a** is coupled to a plurality of area distribution boxes **217** by way of the RF cable **215** and the ARCNET network **216**. The area distribution boxes **217** are used to distribute digital and analog video streams to the audio-video distribution units **231** at the passenger seats **123**.

Figure 5a is a diagram illustrating the passenger entertainment system controller (PESC-A) **224a** and a cooperative audio-video unit **231** that provide for distribution of quadrature amplitude modulated (QAM) digital audio signals to passenger seats **123** throughout the aircraft **111**. The passenger entertainment system controller **224a** comprises a plurality of analog to digital converters (A/D) **351** that digitize audio input signals from input sources, such as one or more audio tape reproducers **223**, the public address system **222** and a passenger service system **275**. The digitized signals from these sources are multiplexed in a multiplexer (MUX) **352** that is controlled by a controller **353** and microprocessor (μ P) **355** having a programmable memory **354**. The programmable memory **354** stores code for use by the microprocessor **355** in multiplexing the signals.

The output of the multiplexer **352** is input to a first-in first-out (FIFO) buffer **356** and output signals therefrom are quadrature amplitude modulated using a quadrature amplitude modulator (QAM) **357**. The format of the output signals from the FIFO buffer **356** is shown and includes a start frame set of bits (header) followed by each of the respective audio channels (CH1 ... CHn). The output of the quadrature amplitude modulator **357** is modulated onto a carrier by an RF modulator **358** that transmits the QAM and RF modulated signal over the RF cable **215** to the audio-video units **231** at each of the passenger seats **123**.

The audio-video units **231** each comprise a RF tuner **235** that demodulates the RF modulated signal transmitted over the RF cable **215** that is coupled to a QAM demodulator **237** that demodulates the quadrature amplitude modulated signals. The output of the QAM demodulator **237** is converted to an analog signal by a digital to

analog converter (D/A) **363** and sent to the headphones **132**. Selection of a particular channel to be listened to by a passenger **117** is made using the tuner **235** that demodulates the signal associated with the selected channel.

5 The improved quadrature amplitude modulated (QAM) digital audio distribution provided by this aspect of the present invention provides for a greater number of audio channels to be communicated over the RF cable **215**. This is similar to the quadrature amplitude modulation of the video streams discussed above with reference to Figure 5. The quadrature amplitude modulation provides for a plurality of states (not compression) that increases the usage of the bandwidth of the RF cable **215**. Any type
10 of analog input signal may be processed, including signals from the audio tape reproducers **223**, passenger address system **222**, passenger service system **275** or other analog audio source.

The area distribution equipment **210** distributes information from the head end equipment **200** to the seat group equipment **220**. The area distribution equipment **210**
15 also provides power to the seat group equipment **220**. Figure 6 is a block diagram showing the area distribution equipment **210** in accordance with a preferred embodiment.

The area distribution equipment **210** distributes data throughout the communications network formed between the head end equipment **200** and the seat group equipment
20 **220**. The area distribution equipment **210** comprises the plurality of area distribution boxes **217** that are each coupled to a plurality of floor junction boxes **232** that are individually coupled to respective audio-video seat distribution units **231** in the seat group equipment **220** of respective columns of passenger seats **123**.

In a basic system, the area distribution box (ADB) **217** provides for interfacing the first
25 passenger entertainment system controller (PESC-A) **224a** to audio-video units **231** either directly or via floor junction boxes **232**. The area distribution boxes **217** interface to the audio-video seat distribution units **231** by way of the junction boxes **232** using full-duplex RS-485 interfaces **218** and RF cables **215**. The RS-485 interfaces **218** provide control and data links between the seat group equipment **220** and the head end
30 equipment **200**. The RF cables **215** couple audio and video data to headphones **132** and seat displays **122** for listening and viewing by the passengers **117**. The area distribution box **217** acts as a connection box to facilitate the distribution of system

power, combined audio/video signals and service data for up to five columns of audio-video units **231**, and relay of service data and combined audio/video signals to the next area distribution box **217**. The area distribution box **217** has an RS-232 serial diagnostic port to allow verification of functionality.

5 The area distribution box **217** removes power from a seat column in which either a short circuit or ground fault condition is identified. The area distribution box **217** restores power to a seat column from which power had been removed without requiring physical access to the area distribution box **217**. When power is reapplied to such a column, the short circuit protection circuit functions normally and removes power from
10 the column if the short circuit condition persists. An area distribution box **217** processor monitors the status of the AC power output to each individual AVU column for BIT/BITE purposes.

The area distribution box **217** provides the means to adjust the RF level in order to ensure that the proper RF levels for the video and modulated audio signals are supplied
15 to the AVU tuners and demodulators in the presence of changing system configurations and operational conditions. This RF leveling is accomplished by the local processor/s in the area distribution box **217** by controlling a variable attenuator.

The area distribution box **217** provides for interfacing voice data, originating at passenger telephones **121c**, to the first passenger entertainment system controller
20 **224a**. The telephone interface provides for input data from each AVU column to be combined with input data from another area distribution box **217** and retransmitted to the first passenger entertainment system controller **224a** or the next area distribution box **217**.

Figure 7 is a block diagram of exemplary seat group equipment **220** in accordance with
25 a preferred embodiment. The seat group equipment **220** allows individual passengers **117** to interact with the system **100** to view movies, listen to audio, select languages, play games, video conference with others on and off the aircraft **111**, and interface with other interactive services.

The seat group equipment **220** includes a passenger control unit **121**, a seat display
30 **122**, headphones **132**, interface **128a** for a personal video player **128** (in certain zones), an audio-video unit **231** with a plurality of seat controller cards (SCC) **269** one for each seat **123** in a row to interface with the area distribution equipment **210**, a video camera

267 and a microphone 268 for use in video conferencing, and a telephone card 271 that interfaces to the passenger control unit 121 when it includes the telephone 121c and/or credit card reader 121d. One audio-video unit 231 is provided for each seat 123 and controls distribution of video, audio and data to the headset or headphones 132, the seat display 122, and the passenger control unit 121.

Referring to Figure 3, in certain zones of the aircraft 111, a personal computer interface 129a is provided which allows the passenger 117 to power a personal computer (not shown) and to interface to the system 100 through the audio-video unit 231. Alternatively, a keyboard 129b may be provided that allows the passenger 117 to interface to the system 100. The use of the personal computer 129a or keyboard 129b provides a means for uploading and downloading data by way of the satellite communications system 241 and the Internet.

The major functional requirements of the audio-video unit 231 are that it drives one to three seat display units 122 with or without touch screens, provides touch screen and display controls, provides two audio jacks per seat, provides two passenger control unit interfaces per seat 123, interfaces to a parallel telephone system, provides discrete signal interface, a parallel laptop power supply system, demodulates and tunes NTSC and QAM from the RF signal, provides PC type video games, provides an RS-485 interface for ADB-AVU or AVU-AVU communications, provides an interface for personal video players, and provides a PSS interface to an external parallel passenger service system (PSS), provides hardware and software interfaces that provide for video teleconferencing and Internet communications.

Referring to Figure 7, one seat controller card 269 is dedicated to a passenger seat. Therefore, three seat controller cards 269 are required for a three-wide audio-video unit. Two seat controller cards 269 are required for a two-wide audio-video unit 231. A power supply module (PSM) 233 supplies power for the three seat controller cards 269, an audio card 234, the displays 122, and PCUs 121. The audio card 234 electrical circuits comprise RF demodulators to supply audio outputs. An interconnect card (not shown) connects the three seat controller cards 269, the audio card 234, the power supply module 233, and external connectors within the AVU 231.

The seat controller card (SCC) 269 provides many functions for a single passenger 117. Some of the functions that the seat controller card 269 provides include analog video

and audio demodulation, graphics overlay capability, and Motion Picture Experts Group (MPEG) video and audio decompression. The seat controller card **269** provides the ability to demodulate the existing analog video signals as well as MPEG encoded signals delivered by the media server **211** that comprises a video-on-demand (VOD) server.

5 The seat controller cards **269** in Figure 7 and 7a in each audio-video seat distribution unit **231** contain a tuner **235** that downconverts the modulated RF signals to produce intermediate frequency signals containing the NTSC video streams and the quadrature amplitude modulated (QAM) MPEG compressed video streams. A QAM demodulator **237** and an MPEG decoder **238** are used to demodulate and decompress the
10 quadrature amplitude modulated and compressed MPEG compressed video streams to produce MPEG NTSC video and audio signals for display.

An analog (video) demodulator **236** demodulates the NTSC video signals that are then passed to a video multiplexer **235a** where an external NTSC video signal may be added. The NTSC signals are then digitized in a video A/D converter **235b** and are passed to
15 the MPEG decoder **238**. The format of the digital channels after QAM demodulation is MPEG-2 transport streams. The MPEG-2 transport streams may contain many streams of video, audio and data information. The MPEG decoder **238** (demultiplexer) may also receive data information to be sent to the SCC processor group **272**. In the MPEG transport group, the capability exists to add text overlay with the digital video data.
20 The digital data is converted to analog NTSC format using an NTSC encoder **238a** for the display **122**.

Each of the seat controller cards **269** includes a microprocessor (mP) **272** that controls the tuner. The microprocessor **272** is used to address the seat controller card **269** as a node on the network. A database is set up in the cabin file server **268** that includes
25 entries for each of the microprocessors (i.e., each seat **123**). The addressability feature permits programming of each seat to receive certain types of data. Thus, each audio-video unit **231** may be programmed to selectively receive certain videos or groups of video selections, or audio selections from selected audio reproducers. The addressability aspect of the present system **100** allows the airline to put together
30 entertainment "packages" for distribution to different zones or groups of seats. Also, each seat (or seats in different zones) may be programmed to be able to play games, use the telephones **121c** and credit card reader **121d**, use a personal video player or computer, have the ability to engage in video teleconferencing and computer data

interchange, or gain access to the Internet. Furthermore, the addressability associated with each seat permits order processing and tracking, and control over menus that are available to passengers at respective seats, for example. The addressability feature also permits dynamic reconfiguration of the total entertainment system **100**.

5 To provide control from passenger seats **123**, the microprocessor **272** in the audio-video unit **231** includes software that performs substantially the same functions as those in the primary access terminal **225**. This may be achieved by selectively downloading a software module to the microprocessor **269** in the audio-video unit **231** when the passenger **117** requests this service. The downloaded software module
10 operates in the same manner as the software on the primary access terminal **225**. However, the RS-485 interface is used to send commands to the cabin file server **268** that control the ARINC-485 driver. Alternatively, and preferably, use of an Ethernet network **228** to interconnect the audio-video units **231** provides a readily implemented control path directly to the primary access terminal **225** and cabin file server **268**,
15 since they are normally connected by way of the Ethernet network **228**.

The audio card **234** in Figure 7 provides several functions. It demodulates the RF signal to provide audio. It has a multiplexer with audio inputs from the seat controller card **269**, demodulated RF signal audio, and external audio. It routes the 115 VAC power to the power supply module and routes the DC power from the power supply
20 module **233** to the interconnect card.

Figure 7b illustrates a typical fixed passenger control unit **121**. The passenger control unit (PCU) **121** interfaces with the system **100** via the audio-video unit (AVU) **231** and provides a passenger interface having input controls **381** and indicators **382**. The passenger control unit **121** communicates with the audio-video unit **231** for PCU/AVU
25 data, AVU/PCU data, and power.

The passenger control unit **121** may be either side mounted or top mounted onto a seat **123** arm rest. The passenger control unit **121** has a four character alphanumeric display **389**. Brightness of the LED display **389** is controllable, as a minimum, to two levels of brightness. The passenger control unit display **389** is controlled by the audio-
30 video unit **231** to inform the passenger of current mode status and video functions.

The passenger control unit **121** also comprises depressible buttons that permit selection of items displayed on the seat display **122** and turn on call lights and

overhead lights, and electronics. In designated sections or seats, the passengers also control selection of movies and games that are to be played, control the landscape cameras, and activate video conferencing and data communications. In selected sections (business and first class) of the aircraft **111**, the telephone **121c** and credit
5 card reader **121d** are integrated into the passenger control unit **121**, while in other sections (such as coach class) these components are not provided.

A reading light on/off function key **382a** turns on/off an overhead reading light. Call light on and call cancel function keys **382b**, **382c** permit calling a flight attendant. A volume control (increase/decrease volume) key **383** is provided. A select function key
10 **384** allows the passenger to make a selection. Screen navigation function keys **385** provide a means for a passenger **117** to navigate through menus displayed on the display **122** or seat display unit (SDU) **122a**. A channel up/down function key **386** provides for channel control (increase/decrease channel selection). A TV/OFF function key **387** turns the seat display unit backlight on. Pressing a mode function key **388**
15 allows the passenger to have picture adjustment control of the seat video display through menus displayed on the seat display unit **122a**.

The passenger control unit **121** interfaces to the credit card reader **121d**. The credit card reader **121d** reads three magnetically encoded tracks from credit cards that are encoded in accordance with ISO standards 7810 and 7811. Data content is read in
20 accordance with the VisaNet Standards Manual and contain at least: major industry identifier, issuer identifier, primary account number, surname, first name, middle initial, expiration date, service code, and PIN verification data.

Figure 8 is a block diagram of exemplary overhead equipment **230** in accordance with a preferred embodiment. The overhead equipment **230** comprises a plurality of tapping
25 units **261** coupled to the overhead and bulkhead displays **263** and video projectors **262**. The overhead equipment **230** uses RF video distribution, wherein the RF signal is distributed from the head end equipment **200** to the overhead equipment **230** via the plurality of tapping units **261** which are connected in series. The tapping units **261** contain tuners **235** to select and demodulate the RF signal providing video for the
30 monitors **263** and projectors **262** coupled thereto. Control is provided to the overhead equipment **230** using an RS-485 interface **264** coupled to the first passenger entertainment system controller (PESC-A) **224a**. The information on the RS-485 interface **218** between the first passenger entertainment system controller (PESC-A)

224a and the tapping units **261** is controlled via operator input and protocol software running on the cabin file server **268**.

In order to efficiently implement video teleconferencing, the use of a higher speed, larger bandwidth communication network may be provided to permit many
5 simultaneous uses. This is achieved using a high speed network, such as the 100 Base-T Ethernet network **228** that is currently employed in the head end equipment **200**. Interconnection of each of the audio-video seat distribution units **231** by way of a 100 Base-T Ethernet network **228** in addition to, or which replaces the lower bandwidth RS-485 network **218**, provides substantial bandwidth to implement video
10 teleconferencing.

Interconnection of the audio-video seat distribution units **231** using the 100 Base-T Ethernet network **228** also permits data communications between personal computers located at the seats **123** and remote computers **112**. This is achieved by interfacing the 100 Base-T Ethernet network **228** to the satellite communications system **241**. Inter-
15 computer telecommunications may be readily achieved using a Web browser running on portable computers connected to the audio-video seat distribution units **231**, or by integrating a Web browser into the audio-video seat distribution units **231**. This is readily achieved by running the Web browser on the microprocessor **272** used in each audio-video seat distribution unit **231**. Messages may be drafted using a keyboard
20 **129b** connected to the audio-video seat distribution units **231**. Touchscreen seat displays **122** may be also readily programmed to initiate actions necessary to initiate videoconferencing, initiate communications, transfer messages, and other required actions.

Certain line replaceable unit types require the assignment of a unique address within
25 the system **100**. This is referred to as line replaceable unit addressing. Line replaceable units that require unique addresses are the PESC-A primary/secondary **224a**, PESC-V **224b**, video reproducers **227**, area distribution box **217**, tapping unit **261**, and primary access terminal **225**. Each of these line replaceable unit types is assigned a unique address during system installation.

30 Referring again to Figure 2, it depicts the architecture of the system **100**, and its operation will now be described with reference to this figure. The architecture of the system **100** is centered on RF signal distribution of video, audio, and data from the

head end equipment **200** to the seat group equipment **220**. Video and audio information is modulated onto an RF carrier in the head end equipment **200** via the video modulator **212a** and passenger entertainment system controllers **224a**, **224b** respectively prior to distribution throughout the aircraft **111**. Referring again to Figure 5, it shows a functional block diagram of the signal flow to and from the head end equipment **200**.

The source of video may be from video cassette players **227**, landscape cameras **213**, and the TV video output by the media server **211**, or the passenger video information system **214**. The source of audio information may be from audio reproducers **223**, audio from video cassette players **227**, or audio from the passenger address system **222**.

The system **100** uses the RF network **215** to distribute all audio and video programming from the head end equipment **200** to the seats **123**. The RF network **215** is also used to support downloading of video games and other applications to the seats **123**.

The RF network **215** operates over a nominal frequency range from 44 to 550 MHz. The system **100** provides up to 48 6-MHz wide channels for distribution of video information. One of these channels may be used for the distribution of video games and other application software to the seats **123**. The video channels are allocated to a bandwidth from 61.25 through 242.6 MHz (nominal). The frequency range from 108 to 137 MHz (nominal) remains unused.

The frequency range from 300 to 550 MHz is used for distribution of audio information to the seats **123**. One embodiment of the system **100** uses pulse code modulation to transmit the audio data over the allocated frequency range. This supports a maximum of 88 mono audio channels (83 entertainment and five PA). The allocation of these channels to audio reproducers **223** (entertainment audio), video reproducers **227** (movie audio tracks) and to passenger address lines (PA audio) is database configurable and may be defined by the user. It is also possible to read and set RF levels for the passenger entertainment system controllers **224a**, **224b** and area distribution box **217** by means of an off-line maintenance program.

The system **100** uses the ARCNET network **216** as the major data communications path between major components. The ARCNET network **216** interconnects the

following components: cabin file server **268**, primary access terminal **225**, PESC-A (primary) **224a**, PESC-A (secondary) **224a**, PESC-V **224b**, and all the area distribution boxes **217**.

5 The ARCNET network **216** is implemented as two physical networks, with the primary PESC-A **224a** serving as a bridge/router between the two. Any device on ARCNET 1 **216** is addressable by any device on ARCNET 2 **216** and vice versa. In addition to the primary PESC-A **224a**, ARCNET 1 **216** connects the following components: cabin file server **268**, and a maximum of eight area distribution boxes **217**. In addition to the primary PESC-A **224a**, ARCNET 2 **224b** connects the following components: a
10 maximum of one PESC-V **224b**, primary access terminal **225**, and the secondary PESC-A **224a**. Both ARCNET subnetworks (ARCNET 1, ARCNET 2) **216** operate at a data transmission speed of 1.25 Mbps.

System Operation

15 A preferred embodiment of the in-flight entertainment system **100** operates in three possible states. These states include 1) a configuration state, 2) a ground maintenance state, and 3) an entertainment state. In the configuration state, aircraft-installation-unique parameters are initialized and modified. The configuration state is initiated by an operator. The configuration state is entered and exited without the use of additional or modified system hardware. In the ground maintenance state, the system **100**
20 performs self-diagnostics to determine system failures. The ground maintenance state is initiated by an operator. The ground maintenance state is entered and exited without the use of additional or modified system hardware. The entertainment state is the primary state of the system **100** and is initiated by the operator. The system **100** provides several entertainment modes as defined below. The system **100** is modular in
25 design so any one or all modes may exist simultaneously depending on the configuration of the system **100**. The system **100** is configurable so that each zone (first class, business class, coach class, for example) of the aircraft **111** can operate in a different entertainment mode. In the entertainment state, the passenger address functions and passenger service functions are independent of the mode of operation.

30 The entertainment modes include an overhead video mode, a distributed video mode, and an interactive video mode. In the overhead video mode, video is displayed in the aircraft **111** on the overhead monitors **263**. Different video entertainment is possible

for different sections of the aircraft. In the distributed video mode, multiple video programs are distributed to the individual passengers of the aircraft at their seat. The passenger selects the video program to view. The quantity of programs available depends upon system configuration. In the interactive video mode, the system **100** provides a selection of features in a graphical user interface (GUI) presentation to the passenger. Depending on the system configuration, the features may include language selection, audio selection, movie selection, video game selection, surveys, and display settings.

The system **100** provides audio programming to the passengers. When in the interactive audio mode of operation, the system **100** displays a list of audio programs available to the passenger on the seat display **122**. This list is configurable via an off-line database. The system **100** may be configured to allow selection of an audio program using either the seat display **122** or controls on the passenger control unit **121** depending on the system **100** requirements. The selected audio program is routed to the corresponding passenger headphone **132**.

The system **100** provides video programming to all passengers **117**. When in the interactive video mode of operation, the system **100** displays a list of video programs available to the passenger on the screen of the seat display unit **122a**. This list is specified via an off-line database. The system **100** may be configured to allow selection of a video program using either the seat display **122** or controls on the passenger control unit **121** depending on the system requirements. The selected video program is routed to the corresponding seat display unit **122**.

When in the interactive mode of operation, the system **100** provides video games to the passengers **117**. The system **100** displays a list of up to 10 video games available to the passenger on the seat display **122**. This list is specified via an off-line database. The system **100** may be configured to allow selection of a video game using either the seat display unit **122a** or controls on the passenger control unit **121** depending on the system requirements. The selected video game is downloaded to the corresponding passenger seat **123** for viewing on the seat display **122**.

The system **100** supports entertainment packaging. An entertainment package is a predetermined set of one or more movie titles and/or game titles with a predetermined amount of game play time. The content of each entertainment package is specified via

an off-line database. The system **100** requires payment for entertainment packages according to a unit price and a price policy. The system **100** displays a list of available packages on the screen the seat display unit **122a**. Each package in this list must have an associated date range that specifies when the package is available. Up to four
5 packages per date range are specified via an off-line database. The displayed list only contains those packages where the date of the current flight falls within the date range specified for that particular package.

As is shown in Figure 7, for example, if configured with a personal video player **128** that interfaces to the audio-video unit **231** by way of a personal video player interface
10 **128a**, the system **100** controls the personal video player **128** via controls at the seat display **122**. The system **100** provides commands to the personal video player **128** to play, rewind, fast forward, pause, stop and eject a tape.

The system **100** provides the ability to place telephone calls from each passenger seat **123**. In certain configurations, the telephone handset is integrated into the passenger
15 control unit **121**. The handset includes a telephone button pad, a microphone, and a speaker. The system **100** prompts for payment when using the telephone service. Payment must be made via a credit card. The system **100** provides the capability to enter the phone number via controls on the passenger control unit **121**. The system **100** also displays phone call status on the screen of the seat display **122**.

20 The system **100** provides the ability for passengers **117** to select items from an electronic catalog displayed on the screen of the seat display **122**. The catalog may be divided into categories. The system **100** provides the capability to configure the categories and the items via an off-line database tool.

The system **100** provides the capability to display on the screen of the seat display **122**
25 a running tabulation of all expenses, excluding telephone charges, incurred at a seat during the current flight.

The system **100** is configured to allow the flight attendants to display flight information at the primary access terminal **225** from the off-line database or retrieved from other equipment on-board the aircraft **111**. If this information is not available, the system
30 **100** is configured to allow information to be entered manually at the operator console as detailed below. Flight information may include the following: aircraft registration

number, flight number, departure airport, arrival airport, flight duration, and route type.

System Software

5 The system **100** employs a software architecture that integrates processing performed by each of the subsystems. The software and firmware comprising the software architecture controls the system, manages the flow of analog and digital audio and video data to passenger consoles and displays, manages the flow of communications data, and manages service and order processing. Various subsystems also have their own software architectures that are integrated into the overall system software
10 architecture.

The system software is designed in a layered fashion, and an application programming interface (API) layer is defined and documented for the primary access terminal **225** and seat display **122**. These application programming interfaces are used as the foundation upon which to implement the graphical user interfaces (GUIs). The GUIs
15 are thus implemented in a manner that facilitates rapid prototyping and GUI modification within the constraints of the services provided by the application programming interfaces. The system **100** has a flight attendant GUI at the primary access terminal **225** and passenger GUIs at the seat **123** (seat display unit **122a**). Each of these GUIs have the following properties: graphic orientation, clear and directly
20 selectable functions (no "hidden" functions), consistency in screen layout and flow (look and feel), and "lexical" feedback (i.e., visible change on the display) for every user action.

Many of the line replaceable units in the system **100** are software loadable in that the contents of the line replaceable unit's memory can be overwritten from a source
25 external to the line replaceable unit. The system **100** provides a facility for loading software into all line replaceable units. The software loading facility ensures that any attempt to load software into a line replaceable unit is appropriate for that type of line replaceable unit. The software loading function indicates when a line replaceable unit can and can not be loaded, the status of software load attempts as either successful or
30 unsuccessful, and an estimate of the time required to load the software into the line replaceable unit. The software load facility employs a high speed download link to the line replaceable units, when appropriate, in order to minimize the time required to load

software into a line replaceable unit. The software loading facility precludes load attempts when the aircraft **111** is in flight.

Software and firmware employed in the present invention permits credit card processing, data collection processing, Internet processing for each passenger, gambling
5 for each passenger, duty free ordering, intra-cabin audio communication between passengers, and display of flight information. The system software includes parallel telephone system software, landscape camera management software, PESC system software, passenger address override software, passenger address emergency software, monetary transaction processing software, language support software, built-in-test
10 software, user request processing software, database management software using a distributed configuration database, software for implementing interactive access, software for processing passenger orders, software for updating inventories, application software, media file encryption software, area distribution box software, audio-video unit programming software, telephone operation software, gatelink node and software,
15 product service pricing software, passenger survey software, transaction reporting software, automatic seat availability reporting software, and video conferencing and data communications software.

Object oriented programming (OOP) is employed in the software and firmware used in the system **100**. A preferred embodiment of the software used in the system **100** is
20 written using JAVA, C, or the C++ language and utilizes object oriented programming methodology. Object oriented programming (OOP) has become increasingly used to develop complex applications. As OOP moves toward the mainstream of software design and development, various software solutions require adaptation to make use of the benefits of OOP. A need exists for these principles of OOP to be applied to a passenger
25 entertainment system such that a set of OOP classes and objects for the messaging interface can be provided.

The system **100** is constructed in a modular framework, and is designed to expand to support various aircraft **111** configurations. System configuration information is defined in an off-line configurable database. System configuration support tools
30 provide the capability to generate database information, which is downloaded to the appropriate system line replaceable units. The line replaceable units store database information in non-volatile memory, and revert to default database information when

they detect newly downloaded data inconsistent with the physical aircraft configuration, or when a database download is unsuccessful.

Aircraft configuration data requires modification only when the aircraft configuration changes, or when the line replaceable unit in which it resides has been replaced or corrupted. Aircraft configuration data at a minimum includes the following fields: Aircraft type, ACS database configuration ID, Overhead system type, Seat configuration, tapping unit and Overhead monitor assignments, Reading/Call light assignment, Master call lamps/attendant chimes data, RF level gain values, Internal ARCNET termination, PA/VA headphone, APAX-140-to-TES interface assignments, PESC audio channel assignments, VMOD video channel assignments, ADB phone capability, ADB discretes, PA zone, display controller, configuration of passenger entertainment system controllers **224**, interactive/distributed video only (DVO), PAT/CFS options, and movie preview.

The entertainment system data define specific parameters for the available system features. It is necessary to reload the database whenever it is determined the associated features are to be changed. Entertainment system data, at a minimum, includes the following fields: Entertainment system data configuration ID, Video games, Movies, Pay/Free entertainment per zone, Passenger surveys per zone, General service/Duty free zones, seat display unit entertainment titles per route type, Currency exchange rates, primary access terminal display currency, Airline name, flight number, arrival/departure city, flight duration, and route type, Movie cycle attributes, Video announcements, video reproducer entertainment assignments, Product data, Credit card data, and Entertainment package details.

Figure 9 is a block diagram of the ACS tool and shows its functionality. The ACS tool provides hardware, user, software, and database interfaces as described below. The ACS tool supports the following hardware interfaces. The ACS tool supports a standard 101 key PC keyboard for the PC application and the primary access terminal standard keyboard. The ACS tool supports a standard MICROSOFT mouse, or equivalent, for the PC application. The off-line configuration database tools support generation of all downloadable configuration data. Airplane Configuration System (ACS) tools are used to generate aircraft configuration system data. The ACS tool is executable on an IBM-compatible 486 PC running MICROSOFT WINDOWS 3.1 or a later version. The ACS

tool produces downloadable data file on media that may be directly input via the primary access terminal **225** or a maintenance PC connected to a test port.

The ACS tool provides the following user interfaces. In general, the graphical user interface includes a series of screens with buttons and other controls and indicators.

5 Screens, buttons, other controls, and indicators follow the general conventions for WINDOWS screens as described in *The Windows Interface Guidelines for Software Design*. The GUI provides user access to the ACS tool's functions via keyboard and mouse inputs.

10 The ACS tool provides the functionality to maintain multiple configurations for all the aircraft types the TES **100** and APAX-150 systems support. The ACS tool is a single executable, regardless of aircraft type. This single executable utilizes a configuration file for pre-initialization of aircraft configuration data (.CFG). It also utilizes a WINDOWS.INI file for ACS tool-specific parameter definition.

15 The ACS tool generates configuration data files that can be distributed to the TES line replaceable units. The applicable data files may be downloaded upon operator request via the MAINT Utility.

The ACS tool provides the ability to create and change an aircraft configuration by the use of menus, list boxes, data entry screens, utilities, error messages and help functions. An aircraft configuration defines what TES devices are installed on the
20 aircraft, where those devices are located and what functions those devices perform.

The PESC-A **224a**, PESC-V **224b**, area distribution box **217**, ADB local area controller (ALAC) (not shown), AVU/SEB **231**, and overhead electronic box (not shown) line replaceable units, as well as the primary access terminal **225** and cabin file server **268**, the MAINT and Config/Status utilities all require knowledge of the aircraft
25 configuration. The database created by the ACS tool that can be downloaded into the PESC-A **224a** and contains the configuration data needed by the PESC-A **224a**, PESC-V **224b**, area distribution boxes **217**, ALACs, AVUs/SEBs **231**, tapping units **261**, and overhead electronics boxes. The ACS tool has the capability to create separate configuration data files for the primary access terminal **225** and cabin file server **268**
30 and the MAINT and Config/Status Utilities.

The ACS tool also has the capability to create downloadable data files that can be loaded directly into the area distribution boxes **217**. The data files that the ACS tool creates for the primary access terminal **225** and cabin file server **268** are able to be imported by the primary access terminal **225** and cabin file server **268** into its
5 database. These files provide information about the aircraft **111** so that interactive services can be provided to the passengers.

The ACS tool creates a downloadable data file (.INT File) that is able to be used by the MAINT and Config/Status Utilities to determine system-wide LRU status, software configuration, and diagnostic information. These utilities require system configuration
10 definition data.

The ACS tool provides a configuration editor function that allows the user to modify an existing aircraft configuration or generate a new aircraft configuration by entering values into displayed data fields or by selecting values from drop-down menus, if applicable. The configuration editor allows the user to import, or copy, selected aircraft
15 configuration data from one configuration to another. "cut" and "paste" operations are provided so that similar or identical configuration entries may be copied from one configuration to another. The configuration editor validates the value entered for each data field. The ACS tool generates error messages when the user enters invalid data in dialog boxes. The configuration editor provides the capability to save a configuration to
20 disk. The ACS tool provides the capability to initiate a configuration validation test. If the validation test finds errors with the data, a detailed error report is displayed. The ACS tool allows a configuration that is INVALID to be saved to disk (.CFG), but the ACS tool does not allow a downloadable database to be built from a configuration that is INVALID.

25 A configuration data builder function of the ACS tool System provides the capability to generate downloadable configuration data files for use with the system **100** and peripherals. When the user attempts to create the downloadable data files, the ACS tool performs a validation check and tests for limits.

30 A reports generator function of the ACS tool provides the capability to generate, for a specified configuration, a validation report and a configuration report. A validation report contains information defining the validity of a specified configuration, including appropriate messages for entries in the configuration which are currently invalid. A

validation report may be generated upon user request or upon request to generate download files. The configuration report provides a detailed report which describes the current configuration. The configuration report is generated only when a request to generate download files is made and the current configuration is determined to be valid.

- 5 A create floppy disk function of the ACS tool provides the capability to generate a disk that contains all files generated by the ACS tool. These downloadable configuration files are loaded to the various line replaceable units in the system. The diskette also contains a setup utility that can be run from the primary access terminal **225** to reinitialize the database on the cabin file server **268** with a new configuration.
- 10 Each line replaceable unit that uses the database contains electrically erasable programmable read-only memory (EEPROM) which are "downloaded" with the database. This means that the database which contains information about the airplane configuration can be passed to each controller (i.e., downloaded). These controllers include the PESC-A **224a**, PESC-V **224b**, area distribution boxes **217**, ALACs, SEBs
- 15 (AVUs) and overhead electronic boxes.

- Many different configurations can be stored for an aircraft **111**. Each contains slightly different options, such as the seating configuration. The ACS tool enables the different configurations, after established, to be recalled season after season by allowing the user to select an existing configuration to edit when a change is made to the aircraft **111**
- 20 during re-configuration. The ACS tool allows the user to create a new configuration that can subsequently be saved.

- Presented below is software design information for a set of programs common to the cabin file server **268** and primary access terminal **225** LRUs of the system **100**. The software forms the fundamental mechanism of moving application information through
- 25 the system **100**. The following description will be readily understood to those familiar with C++ and the WINDOWS NT development environment. Reference is made to Figure 10, which illustrates a block diagram of the software architecture in accordance with a preferred embodiment. The architecture facilitates a control center runtime that is implemented in C++ for the primary access terminal **225** and the cabin file server
 - 30 **268** of an in-flight entertainment system **100**.

As for the primary access terminal **225**, an uninterruptable power supply **400** is used to provide power to the primary access terminal **225** and is in communication with the

programs in the software architecture using a serial NT driver **401**. A PI board **402** provides a communication port for the magnetic card reader and video tuner and interfaces to the serial NT driver **401**. The tuner **235** in the audio-video unit **231** also interfaces to the serial NT driver **401**. The video camera **267** coupled to the audio-video unit **231** is also coupled to the serial NT driver **401**. The serial NT driver **401** also interfaces with the PESC-V **224b**. An ARCNET driver **408** interfaces to the ARCNET network **216**.

The serial NT driver **401** and ARCNET driver **408** interface to an I/O handler **403** to provide selective communications between a message processor **404** and the various communications devices (**400**, **402**, **235**, and **267**). The message processor **404** is responsible for processing messages and putting them into a common format for use by a transaction dispatcher **421**. A pipe processor **405** is utilized to move common format messages from the message processor **404** through a primary access terminal network addressing unit (NAU) program **409** and through another pipe processor **420** into the transaction dispatcher **421**. The message processor **404** also interfaces to a system monitor **412** that is coupled to a watch dog driver **410** that is used to automatically reset the primary access terminal **225** if no activity is detected in a given time interval, and a power down module **414** that performs graceful power down of the primary access terminal **225**. The transaction dispatcher **421** interfaces with a cabin application programming interface (CAPI) library DLL **427** by means of a CAPI message service handler **422**.

A touch panel NT driver **424** interfaces with runtime utilities **425** and a graphical user interface (GUI) **426** to provide operator control over the software. The runtime utilities **425** and graphical user interface **426** interface to the CAPI library DLL **427**, a Reports DLL **429** and a video driver DLL and system (SYS) **430**.

The Ethernet network **228** is used for messaging between the primary access terminal **225** and the cabin file server **268**. The Ethernet network **228** interfaces to the primary access terminal network addressing unit **409**, the transaction dispatcher **421**, the CAPI Library DLL **427**, and the Reports DLL **429**.

As for the cabin file server **268**, an uninterruptible power supply **440** is used to provide power to the cabin file server **268** and is in communication with the programs in the software architecture using a serial NT driver **447**. The serial NT driver **447** is also

coupled to an auxiliary port **441** and the video reproducers **227**. An ARINC-429 NT driver **448** is coupled to the satellite broadcast receiver **240** and the satellite communication system **241**. An ARCNET driver **450** interfaces to the ARCNET network **216**. A high-speed data link (HSDL) NT driver **449** interfaces to the video modulator **212a**.

The serial NT driver **447**, ARCNET driver **450** and ARINC-429 NT driver **448** interface to an I/O handler **451** to provide selective communications between a message processor **452** and the various communications devices (**440**, **441**, **227**, **216**, **212a**). The message processor **452** is responsible for processing messages and putting them into a common format for use by a transaction dispatcher **473**. A pipe processor **456** is utilized to move common format messages from the message processor **452** through various network addressing units **461-465** and through another pipe processor **470** into the transaction dispatcher **473**. The network addressing units **461-465** include a test port NAU program **461**, a VCP NAU program **462**, a backbone NAU program **463**, an ARINC-485 NAU program **464** and a seat NAU program **465**.

The message processor **452** also interfaces to a system monitor **454** that is coupled to a watch dog driver **446** that is used to automatically reset the cabin file server **268** if no activity is detected in a given time interval, and a power down module **455** that performs graceful power down of the cabin file server **268**. Each of the network addressing units **461-465** is coupled to the system monitor **454**. The system monitor **454** is also coupled to the transaction dispatcher **473**. The transaction dispatcher **473** interfaces with CAPI services **477** that are called from the CAPI message service handler **422** in the primary access terminal **225**. The transaction dispatcher **473** also interfaces to the primary access terminal **225** by way of the Ethernet network **228**.

Cabin Application Programming Interface (CAPI) calls **476** are used to communicate information (as shown by arrow **475**) between various cabin services **477** and the primary access terminal **225** via the Ethernet network **228** and various service interfaces. The separate communication link for the crystal reports DLL **429** is enabled through object oriented data base calls **434** to the Standard Query Language (SQL) server **492**. The cabin services **477** include CAPI calls **476** with predefined formats for various services. The services include in-flight entertainment (IFE) control **478**, movie cycle **479**, video services **480**, video announcement **481**, game rental **482**, movie sales **483**, catalog sales **484**, drink sales **485**, duty-free sales **486**, landscape camera **487**,

media server **488**, Internet **489** and teleconferencing **490**. Each of these services are controlled by way of the SQL server **492** which is coupled to a relational database **493** and are configured by means of runtime database utilities **491**. The various services **478-490** are routed by way of the pipe processor **474** to the transaction dispatcher
5 **473**, through the associated NAU program **461-465**, the message processor **452**, and the relevant driver **447, 448, 449, 450**, to the appropriate device **440, 441, 227, 240, 241, 216, 212b**.

More specifically, the cabin file server **268** and primary access terminal **225** software comprises a control center common executive that includes the message processors
10 **404** and **452**, transaction dispatchers **421** and **473**, and network addressable unit (NAU) programs **409, 461-465** that together manage communications flow among line replaceable units and applications, and record or log system irregularities for subsequent analysis. The control center common executive efficiently moves
15 information from source to destination with a minimum of system resources, provides real-time expense or over-handling, provides a means to allow communications to originate at any source, including periodic status messages such as those to the primary access terminal **225** from the video players **227**, and provides a consistent method of handling existing line replaceable units while allowing for additional line replaceable units. In addition, the common executive stores drivers that are not
20 already part of the operating system. The system monitors **412** and **454** are provided to launch all application programs and shut them down as needed.

Each line replaceable unit type that communicates with the control center common executive has a corresponding network addressable unit (NAU) program **461-465**. For example, any seat **123** that must communicate routes to the seat NAU program **465**,
25 any video cassette player **227** routes to the VCP NAU program **461**, etc. Each time a line replaceable unit communicates with an NAU program **461-465**, a virtual LRU is used to maintain cohesion between the application (service) and the device (driver). The virtual LRU is a state machine, one for each physical device associated to this NAU type. For example, if two seats "001A" and "021J" are communicating with the control
30 center common executive, two virtual seat LRUs exist within the seat NAU program **465**. It is within this state machine that the actual conversion between IFE-message and native messages takes place. Status and other information regarding each line replaceable unit are maintained in the VLRU.

In addition to the device-initiated VLRUs, several VLRUs are provided whose function is to maintain the status of related devices. For example, the primary access terminal **225** must constantly monitor the status of the printer, so a VLRU for the printer is used in primary access terminal NAU program **409**. Similarly, the seats must be kept
5 apprised of changes to the states of the system, so a VLRU for broadcasting this information is created in the seat NAU program **465**.

Primary Access Terminal

The primary access terminal executive extension set of routines that, together with the common executive software, form the generic application for the primary access
10 terminal **225**.

The message processor **404** is shown in Figure 11, which illustrates the message processor function and data paths. The message processor **404** interfaces a plurality of device drivers **531**, including an ARCNET driver **531a** and a serial NT driver **531b**. The device drivers **531** are coupled to a plurality of device handlers **532**. The device
15 handlers **532** include MessageFromDrivers() **532a** and MessageToDrivers() **532b**. The MessageToDrivers() **532b** associated with the serial NT driver **531b** is coupled to a ToDriverQueue **532c**, and the MessageToDrivers() **532b** associated with the serial NT driver **531a** is coupled to an ArcnetHandler FIFO **532d**.

A NAU server **535** is provided that includes two named pipes (or communication lines)
20 having a plurality of InPipeProcessors() **535a** and OutPipeProcessors() **535b**. The InPipeProcessors() **535a** and OutPipeProcessors() **535b** are coupled by way of a plurality of pipes **537a** to NAU clients **533**. The respective InPipeProcessors() **535a** are coupled to a corresponding plurality of NAU out FIFO queues **538**.

A plurality of routers **537** coupled the device handlers **532** to the NAU server **535**. The
25 plurality of routers **537** include the AddMessageToPipeProcessor() **536**, an AddMessageToOutQueue() **539a**, and a MessageToHandler() **539b**. The MessageFromDrivers() **532a** of the device handlers **532** are coupled to the MessageToPipeProcessor() **536**. The InPipeProcessors() **535a** are coupled to the MessageToHandler() **539b**. The AddMessageToPipeProcessor() **536** and the
30 MessageToHandler() **539b** are coupled to the LRU table **534**.

The primary duty of the message processor **404** is to move communications between various I/O devices and their appropriate logical devices, the network addressable unit (NAU) **533**. This duty is assigned to the message processor **404** instead of residing with the NAUs **533** because there is no one-to-one correspondence between the NAUs **533** and the device drivers **531**. For example, several devices' communications may arrive via an ARCNET driver **531a** (i.e., passenger entertainment system controller **224**, seat **123**, area distribution box **217**, and AVU/SEB **231**).

To support this duty, the message processor **404** includes the following sub-functions. Using an I/O handler **532**, the message processor **404** receives messages from the device drivers **531**. Each message, regardless of original format must contain a destination or network address for routing purposes. Using this network address coupled with the device type (i.e., ARCNET, RS-232, etc.) the network address determines the appropriate NAU via a look-up table **534** and routes the message to that NAU. Since communications from the devices employ a variety of protocols, they are bundled into an IFE-message upon receipt from the physical device, and unbundled after receipt from the application services (via the NAUs). In this way, the message processor **404** acts as a system translator. Using named pipes **535a** and **535b**, the message processor **404** receives messages from the NAUs. The message processor **404** determines the appropriate device driver **531** and network address and routes the message to the device. As NAUs demand, the message processor **404** creates two named pipes **535a** (input) and **535b** (output) for each NAU, maintaining the table **534** of pipe names (or handles) and their corresponding NAU IDs. The message processor **404** logs invalid destination address errors. The message processor **404** registers with the system monitor **412** for coordinated system operation.

The detailed design of the Message Processor **404** will now be discussed. MP.EXE is the Message Processor and comprises the following files:

ARCNTCLS.CPP	The ARCNET interface Class
ARCSMCLS.CPP	The ARCNET Simulator Class for testing
DVCHNDLR.CPP	The Device Handler Class
MSSGPRCS.CPP	The Message Processor Class and <i>Main()</i>
PPPRCSSR.CPP	The Pipe Processor Class

SRLCLASS.CPP The Serial Driver Class

WNRTLCL.CPP The WinRTUtil Class

ARCNTDRV.RT The ARCNET User-side Driver

A *Main()* function used in the message processor **404** initializes its processing threads using *StartHandlers()* and *PipeProcessorClass::StartNAUThread()* functions. These threads operate continuously to move data from source to destination. *Main()* also registers its existence with the system monitor **412** program (using

5 *MessageProcessorClass::Register()* and waits for a shutdown signal from the system monitor **412**, after which it performs an orderly shutdown of all its threads.

For each device driver **531**, a Device Handler Class member is created. ArcnetClass defines Device Handler routines for the ARCNET driver **531a**. The ARCNET driver **531a** is a user side driver that performs the actual I/O with the ARCNET hardware. Because
10 it is loaded along with the rest of the message processor **404**, its interface is via *Queue::Put()* and *Queue::Get()* functions. SerialIOClass defines the Device Handler routines **532** for a serial device driver **531b**. The serial driver **531b** is a standard WINDOWS NT Serial Device Driver. *ReadFile()* and *WriteFile()* are the functions used to
15 the following capability. Two Input-Driven threads are provided to control I/O. The names vary from handler to handler, but these functions launch the infinitely looping threads that constantly wait for data to move between the device (or queue) and the Message Processor **404**.

Handler	Launch Function Name	Thread Function
Serial Device	<i>SerialInputInterface()</i>	<i>MessageFromDriver()</i>
	<i>SerialOutputInterface()</i>	<i>MessageToDriver()</i>
ARCNET Device	<i>MessageToHandlerThreadProc()</i>	<i>MessageFromDriver()</i>
	<i>MessageFromHandlerThreadProc()</i>	<i>MessageToDriver()</i>

To receive data from the device drivers **531**, *MessageFromDriver()* **532a** reads a
20 message from its associated driver **531a** or **531b** using *Get()* or *ReadFile()* functions. It converts the input to a valid IFE Message using functions from the IFE_Message Class

or ARCNET_Message Classes. It then calls
MessageProcessorClass::MessageToPipeProcessor() to add the message to the NAU
Output Queue **538**.

To put data to an Output Queue **538**, *PutToHandler()* puts a valid message at the end of
5 the output queue **538** of its associated driver. It does not perform any data conversion.

To output queued data to a device driver **531**, *MessageToDriver()* **532b** reads the output
FIFO queue **538** and issues the appropriate driver output command. It does not
perform any data conversion.

To start the handler to open communications to I/O ports, *StartHandler()* performs the
10 necessary initialization to get queues, pointers and driver connections ready. It then
starts-up the two I/O threads (*InPipeProcessor()* **535a** and *OutPipeProcessor()* **535b**).

The term NAU Server means the set of routines that comprise a "server" for the Network
Addressable Unit processes. They are kept in the PipeProcessorClass. Two threads,
NAUInThread() and *NAUOutThread()* are used to launch the set of I/O threads
15 (*InPipeProcessor()* **535a** and *OutPipeProcessor()* **535b**) for an as yet unknown NAU
process. The first message received from any NAU registers it to this set of threads,
causing *NAUInThread()* and *NAUOutThread()* to launch another set, getting ready for the
next NAU to speak. In this way, the Message Processor **404** is dynamic and can
support different numbers of NAUs as needed.

20 As for incoming messages, *NAUInThread()* launches the *InPipeProcessor()* thread **535a**
which continuously receives a message from its input pipe **537b**. If the message is
meant to be routed to a driver **531**, it gets sent to *MessageToHandler()* **539b** which
places it on the appropriate driver's output queue **532c**. If the message is meant to be
routed back to an NAU, it is sent instead to *AddMessageToOutQueue()* **539a** which
25 performs this routing.

As for outgoing messages, *NAUOutThread()* launches the *OutPipeProcessor()* thread **535b**
which continuously reads a message from the NAU Out Queue **538** and sends it to its
associated NAU process via its named pipe **537a**.

Routers **537** are routines that use the LRU table **534** to determine which processing thread needs to process the message. One router **537** is a From-NAU Router. Upon demand, *MessageProcessorClass::MessageToHandler()* **539b** moves the message to the appropriate handler. If necessary, it converts the message to the appropriate 'native'
5 syntax using functions from IFE_Message Class or ARCNET_Message Class. It calls appropriate *PutToHandler()* function to move the converted message to the handler's output queue **532c**. Another router **537** is a From-Device Router. Upon demand, *PipeProcessorClass::AddMessageToOutQueue()* **539a** calls the appropriate *PutData()* function to move the message to the NAU's output queue **538**.

10 The LRU table **534** is an internal memory structure which contains an entry for each device in the system **100**. It contains sufficient information to translate message addresses from NAU-to-Driver and Driver-to-NAU. Specifically, it contains a physical name, which is the name of each device (e.g., 001A for seat 1A); NAU Type, which is the NAU that processes message (e.g., 7 corresponds to SeatNAU); Network Address (e.g.,
15 4F040552 for seat 1A's seat display unit **122**); and Device Handler that indicates which device driver **531** to use (e.g., 0 for ARCNET). This information is kept in a SQL database table which is read during the Message Processor *Main()* initialization via *CreateLRUtable()*.

As NAU processes register with the Message Processor **404**, their identities are updated
20 in this table via *PipeProcessorClass::AddQueueInfoToLookUpTable()*, *PipeProcessorClass::AddThreadPointerToLookUpTable()* and *PipeProcessorClass::AddPipeHandleToLookUpTable()* functions, which include Pipe Handle, Thread Class, Registeree, Queue Class, and Queue Semaphore.

ARCNET is the token-passing network that provides the primary communication link
25 between the Control Center and the backbone of the system **100**. The ARCNET driver **408** and **450** is software that provides the interface between the message processor **404** and **452** and the physical ARCNET device interface in the cabin file server **268** or the primary access terminal **225**. The description below is for the primary access terminal **225**.

30 For development efficiency, the ARCNET driver **408** has been attached to the message processor **404**. The ARCNET driver **408** performs the following. The ARCNET driver **408** obtains a network address of this line replaceable unit. The ARCNET driver **408**

understands network addresses for up to 8 cabin file servers **268** and up to 8 primary access terminals **225**, to provide for future growth. The ARCNET driver **408** initializes the ARCNET device to proper configuration. The ARCNET driver **408** signs-on to the network. The ARCNET driver **408** handles network reconfigurations and builds up
5 network map to obtain information for routing messages across multiple ARCNET networks. The ARCNET driver **408** deals with transmit handshaking exceptions that may occur.

The ARCNET device is an SMC COM20020 Universal Local Area Network Controller, the same device as used in all backbone line replaceable units. The network speed is 1.25
10 Mbps. The 256-byte ARCNET packet (short packet format) is employed. A 2KB internal device RAM is divided into two 256-byte pages: 1 receive buffer and 1 transmit buffer. The rest is currently not used. The line replaceable units are arranged in 2 ARCNET networks **216**, one each supported by the primary access terminal **225** and the cabin file servers **268**. The ARCNET driver **408** supports this variability.

15 Figure 12 illustrates the operational flow of the ARCNET Driver **408**. The ARCNET driver **408** is part of MP.EXE and comprises the following source file: ARCNTDRV.RT the ARCNET Driver Source. This file is pre-processed using WinRT (see the make file) to incorporate the necessary additional functionality.

To use the ARCNET driver **408**, a user first calls *ArcnetDriverClass::StartDriver()* **601** to
20 initialize this driver and its device and establish queues **607**, **606** to be used to transmit and receive data.

Figure 12 illustrates the operational flow of the ARCNET Driver **408**, where *StartDriver()* **601** launches I/O (receive, transmit) threads **604**, **605** and an interrupt handler **603**, and *StopDriver()* **602** shuts them all down.

25 A discussion follows regarding the Network Addressable Units (NAU) that reside on the primary access terminal **225**. The primary access terminal **225** Network Addressable Unit program **409** function and data paths are shown in Figure 13. The primary access terminal NAU **409** provides the interface between the PAT GUI **426** or the Application Services and the unique devices attached to the Primary Access Terminal **225**. Each of
30 these devices is controlled via its own Virtual LRU (VLRU) set of functions. In addition, most of these devices communicate via the same I/O channel, the PI Mux **402**. The VLRUs are listed below.

Audio Tuner VLRU	The Audio Tuner VLRU allows control of audio channel selections for flight attendant previewing via the PAT GUI.
Card Reader VLRU	The Card Reader VLRU collects and forwards data from the card reader, to be used by the Access Functions and Sales Services' Functions.
GUI Monitor VLRU	No LRU is actually associated with this VLRU. The GUI Monitor VLRU's duty is to start the GUI and end the GUI as appropriate.
PAT VLRU	The PAT VLRU responds to loopback messages from the CFS TestPort NAU via Ethernet for BIT functionality. It logs communication failures between the PAT and the CFS. It controls the BITE and COMM LEDs on the front of the PAT, lighting them to indicate failures.
Printer VLRU	The Printer VLRU periodically queries the Control Center Printer for its status and provide this status as an unsolicited message to the PAT GUI.

PAT.EXE contains the primary access terminal NAU program **409**. In general, a network addressable unit program must first construct a NAUDispatch object and then construct one or more NAU objects, one for each virtual LRU (VLRU) that it supports.

- 5 Certain VLRU-specific functions (such as NAU::StartItUp()) must be created for each VLRU type. The primary access terminal NAU program **409** includes the following primary components:

PAT.CPP	The <i>Main()</i> Program
PDSPATCH.CPP	The NAU Dispatcher
GUMNITOR.CPP	The GUI Monitor VLRU Class
CRDRDRVL.CPP	The Card Reader VLRU Class
TUNRVLRU.CPP	The Audio Tuner VLRU Class
PATVLRU.CPP	The PAT main VLRU Class
PRNTRVLR.CPP	The Printer VLRU Class
PRNTRSTT.CPP	The Printer VLRU's Status Sub-Class
PIMUX.CPP	The PI MUX VLRU Class
PINTRFCE.CPP	The base class for the Tuner VLRU, Card

Reader VLRU and PAT VLRUs

Main() registers with the System Monitor **412** and launches a *PIDispatch* object to open up communications between the message processor **404** and the transaction dispatcher **421**. It calls *PIDispatch::startItUp()* **518** to initialize the VLRUs, one each. It also
 5 launches the *Session()* threads **507**. *Main()* waits to die, either by receiving a *ProcessStop* command from System Monitor **412**, or else it sleeps forever until interrupted. It calls *shutItDown()* **518a** to close all the VLRUs down with a *SubProcessStop* command and exit gracefully.

Referring to Figure 13, the message processor (MP) **404** and the transaction dispatcher
 10 (TD) **421** communicate by way of a Network Addressable Unit (NAU) dispatcher **500** that comprises *NAUDispatch*. *NAUDispatch* is a base class that contains the code necessary to open a framework for a new Network Addressable Unit. It contains the following global objects:

Qpair MP_Fifos	Qpair MP_Fifos keep track of traffic between the NAU and the Message Processor. The NAU Object Ids are stored in these two queues.
Qpair TD_Fifos	Qpair TD_Fifos keep track of traffic between the NAU and the Transaction Dispatcher. The NAU Object Ids are stored in these two queues.
Queue RunImmediateFifo	The Queue RunImmediateFifo keeps track of NAUs which require immediate attention, regardless of outside messages.
Queue TimedOutFifo	The Queue TimedOutFifo allows an NAU VLRU to time out, thus giving processing over to others until the time out occurs.
Queue DestructFifo	The Queue DestructFifo is used by <i>shutItDown()</i> to cause each VLRU to shut down.
Queue AuxFifo	The Queue AuxFifo is used in <i>Session.cpp</i> of <i>Seat.exe</i> only.

Only the first constructor call per program uses *InitNAUDispatch()* to start all session
 15 threads **507** (one for each VLRU plus 2 up to a maximum of 14) for the NAU. It opens Named Pipes **519a** and **519b** between the message processor **404** and the transaction dispatcher **421** Fifos **501**, **502** and the session threads **507** to manage I/O between

them. It then initiates threads **511-514** that manage input and output between the message processor **404** and the transaction dispatcher **421** (*MPLeft()* **511**, *MPRight()* **512**, *TDLeft()* **513** and *TDRight()* **514**). Once these initialization steps have been accomplished, the main program constructs NAU state machine objects **510** (also called
5 VLRUs).

In addition, this class contains the following utility functions:

- AddNAU()* This routine adds a VLRU object ID to an array for later lookup (to send it a message or shut it down, for example).
- AddNAUMap()* This routine adds a VLRU object ID and its text name to an array for later lookup.
- FindNAU()* Returns the VLRU object ID based on the text name passed to it.
- GetNthNAU()* Returns the VLRU object ID in the 'nth' position in the array.
- GetNumberOfNAUs()* Returns the number of VLRU object IDs in the array.
- RemoveNAUFromMap()* This routine removes a VLRU object ID and its text name from the array.
- SendToAllVLRUs()* This routine sends the same message to all VLRUs via their *MPRight.queue*, as if it was sent via the MP. It uses MP logic as a short-cut, rather than developing more routines for intra-process communication.
- SendToOneVLRU()* This routine sends a message to a single VLRU via its *MPRight.queue*, as if it was sent via the MP. It uses MP logic as a short-cut, rather than developing more routines for intra-process communication.
- shutItDown()* This routine is used to turn off all VLRUs, typically called because a message was sent by the System Monitor to the *main()* routine to do so.
- startItUp()* The *startItUp()* routine is used to start up all VLRUs.

The *MPRight()* Thread routine **512** continuously waits for incoming messages from the Message Processor **404** via the Named Pipe **519a**. The term 'right' indicates that the data moves from left-to-right in Figure 13.

The *MPRight()* Thread **512** uses the IFE Message Class routines to deal with the data received. Once a message is received using *IFE_Message::GetData()*, it looks up the appropriate VLRU name (*IFE_Message::GetAddress()*) and uses it to look up the appropriate NAU object ID (*FindNAU()*). Then it stores the incoming message in that
5 NAU's MPQueue.Right queue **516a** and places the NAU's ID into the Dispatcher's MP_Fifos.Right queue (*MPPutNAU()*) **501**. This ID is then used by the *Session* threads **507** that are constantly running to decide which VLRU needs to be processed.

A "hook" function pointer is provided with this thread to allow applications to pre-process the message prior to *MPRight()*'s storage. If no hook function is defined, this is
10 ignored.

The *MPLeft()* Thread routine **511** continuously waits for outgoing messages for the Message Processor **404**. The term "left" indicates that the data moves from right-to-left in Figure 13. It uses the IFE Message Class routines to deal with received data.

Using *Queue::Get()* it reads the NAU ID from the MP_Fifos.Left queue **501** then uses
15 that NAU's *MPGetNAU()* function to read the data from its MPQueue.Left **517a**, and uses *IFE_message::PutData()* to output the message via the Named Pipe **519b**.

The *TDLeft()* Thread **513** behaves like *MPRight()* **512**, except that the input comes from the transaction dispatcher **421**. The *TDRight()* Thread **514** behaves like *MPLeft()* **511**, except that the output goes to the transaction dispatcher **421**.

20 It is sometimes impractical for all VLRUs to be running at once (for example, the seat NAU can contain more than 500 VLRUs), so a maximum number of processing threads has been established as 14. These threads **511-514** each execute a *Session()* function **507** which waits for an event such as input from any source (message processor **404**, transaction dispatcher **421**, TimeOut, etc.), then determines which VLRU state machine
25 needs to be run to process the message and executes it via the VLRU's *StartItUp()* function **518** called by *NAU::EntryPt()*. When *EntryPt()* returns, the message is fully processed, and *Session()* **507** loops to get another one.

The NAU class contains foundation routines and data for any VLRU. It is derived from the timed Callback class and Cobject class (from a C++ Foundation Class Library). The
30 NAU constructor makes an object that has TDQueue and MPQueue, two Qpair objects.

These queues are used to store the actual data or IFE_Message needed by the VLRU state machine. The NAU constructor also creates three Event Semaphores, including a RunImmediateEvent semaphore, a TimeoutEvent semaphore and an AuxEvent semaphore, which allow it to control processing via the related Queues in the NAU dispatcher **500**. Finally, the NAU constructor creates one mutex, DispatchMutex which coordinates which Session thread can access the data for a given VLRU (in case two threads try to handle messages for the same VLRU).

The *StartItUp()* function **518** (not the same as *NAUDispatch::startItUp()*) is called by *NAUDispatch::Session()* when a message is ready to be processed by the VLRU. The *StartItUp()* function **518** typically varies per VLRU, but its job is to fully process one message received from any source. That may simply mean passing the message on, say from message processor **404** to transaction dispatcher **421** or vice-versa.

Data Movement Functions will now be discussed. The NAU class contains the following members used to move data to and from the message processor **404** and the transaction dispatcher **421**:

- MPGetNAU()* Moves data from MPQueue.Left for output to the MP.
- MPPutNAU()* Moves data from input from MP to MPQueue.Right.
- NAUGetMP()* Moves data from MPQueue.Right into StartItUp() for processing.
- NAUGetTD()* Moves data from TDQueue.Left into StartItUp() for processing.
- NAUPutMP()* Moves data from StartItUp() into MPQueue.Left for later output.
- NAUPutTD()* Moves data from StartItUp() into TDQueue.Right for later output.
- TDGetNAU()* Moves data from TDQueue.Right for output to the TD.
- TDPutNAU()* Moves data from input from the TD to TDQueue.Left.

Other generic NAU functions include:

- bOKToRun()* Reports to NAU Dispatch whether a VLRU is ready to run. The base version of this always returns TRUE.
- EntryPt()* This launches the VLRU's own *StartItUp()* function.

- get_hTimeOutEvent()* Returns the value of the Time Out Event handle.
- get_hVLRUEvents()* Returns a pointer to all the Event Handles used by this session to get Input.
- get_NAUState()* Returns the current state of the VLRU. If "Active", the VLRU is capable of processing information. If "Inactive", it can't take any messages. For example, if the system is not currently allowing game play, the HSDL VLRU would be "Inactive".
- GetBITEStatus()* This function varies from VLRU to VLRU and is only a placeholder in the base class.
- GetMPQPair()* Returns a pointer to the MP Queues - lets the user bypass the entire message traffic philosophy.
- GetName()* Returns the text name of the current NAU VLRU.
- GetTDQPair()* Returns a pointer to the TD Queues - lets the user bypass the entire message traffic philosophy.
- GetUseMessageCounter()* Retrieves a flag set with *SetUseMessageCounter()*.
- set_NAUState()* Used to control the state of the VLRU state machine. Currently, the two states used are "Active" and "Inactive".
- SetUseMessageCounter()* Sets a flag used by *NAUDispatch::Session()*. If TRUE, *Session()* counts messages for the VLRU.

As discussed above, each of the devices (**402, 235, 224, 216**) attached to the primary access terminal **225** is controlled via its own virtual LRU (VLRU) or NAU state machine objects **510** functions discussed in conjunction with Figure 13. Most of these devices communicate via the same I/O channel, a PI Mux.

- 5 The tuner VLRU allows control of audio channel selections for flight attendant previewing via the PAT GUI **426**. The TunerVLRU class is also a PIInterface class child. Its *StartItUp()* routine handles the SubProcessStart and SubProcessStop commands the same as the others, and then waits for I/O from either the PI Mux or the transaction dispatcher **421**. If a message is received from the PI Mux, it forwards it to the
- 10 transaction dispatcher **421** using *NAU::NAUPutTD()*. If a message is received from the message processor **404**, it forwards it to the PI Mux using *ToMuxPut()*.

The card reader VLRU collects and forwards data from the card reader **121d**, to be used by the access functions and sales services' functions. Based on the *PIInterface* class, the *CardReaderVLRU* class is the first actual VLRU created for this NAU. It creates an event called *StartEvent* which is used by *PIMux* to coordinate all the other *PIInterface* VLRUs. Its *StartItUp()* **518** routine loops forever retaining its *Session()* thread. It looks for a *SubProcessStart* command from the message processor **404** (which is issued by *NAUDispatch::startItUp()*) and then waits for *StartEvent* to trigger before processing any other messages. Once *StartEvent* has occurred, it can continue processing. If it receives a *SubProcessStop* message, it terminates. It reads and ignores all other messages from the message processor **404** and the transaction dispatcher **421**. Instead, it looks for input via its *FromMux* semaphore event, which tells when it has received data from the PI Mux. If the PI Mux sends a *CardRead* command, this VLRU calls *MagCardData()* to process this message. All other messages are returned to the Mux via the *ToMux* queue. *MagCardData()* converts the data into ASCII and forwards it to the primary access terminal application via the transaction dispatcher **421**. Optionally for testing, the Register can be set with the value "DisplayMagCardData" to cause all the card data to be printed to a window at the primary access terminal **225** via *stdout*.

The GUI Monitor VLRU starts the GUI and ends the GUI as appropriate. No LRU is actually associated with this VLRU. When the *GUI_Monitor* object is created, it creates an extra event called *ServiceAlive*. This event is set via *ServiceMonitor()* and tested in *StartItUp()* **518** to know whether Cabin Service is communicating to this NAU. The *StartItUp()* routine is called as soon as all the VLRUs are created via the *PIDispatch::startItUp()* it launches another thread called *ServiceMonitor()* which continuously tries to receive messages from the Cabin Services program via a mail slot. It then uses this as a 'heart beat' to know if the application is still alive. If this heart beat fails to occur after having been established, the GUI Monitor terminates the GUI process. If this heart beat is never established, *ServiceMonitor()* simulates one, for test purposes. *StartItUp()* **518** continuously loops and waits for the *SubProcessStart* command from the message processor **404** (from the *PIDispatch::startItUp()* routine), and then it waits for *PIDispatch()* to tell whether it connected to the database successfully by triggering the *ConnectedToService* event. Then it attempts to start the *CGUI.EXE* program. If *StartItUp()* detects that the GUI terminated, it attempts to restart

it. *StartUp()* ignores messages from the transaction dispatcher **421**, and only processes the SubProcessStart and Stop commands from the message processor **404**.

The Card Reader, Tuner, PI Mux, primary access terminal and Printer VLRUs are all based on the PIInterface class. Essentially, this provides support for one more source
5 of I/O, from the PI Mux (or multiplexed I/O port) via the PIMux VLRU. The PIMux VLRU provides the following member routines:

ToMuxPut() Converts a PAT_Message into appropriate syntax for either Audio Tuner or PI 'Board' message and sends the data to the ToMux queue.

FromMuxPut() Places a message on the FromMux queue.

FromMuxGet() Reads a PI_Message from the FromMux queue and converts it to a PAT_Message.

ToMuxGet() Reads and encodes for transmission a PI_Message from the ToMux queue.

FromMuxSemaphoreHandle() Returns the handle for this queue

FromMuxSemaphoreHandle() Returns the handle for this queue.

The PIMux class is the VLRU which communicates via the message processor **404** and the transaction dispatcher **421** for all I/O with the PI Board, for card reader, tuning, etc. The PIMux class points to each of these VLRU classes for data transfers through
10 their FromMux and ToMux queues. A *StartUp()* routine loops forever retaining its *Session()* thread. It looks for a SubProcessStart command from the message processor **404** (which is issued by the *NAUDispatch::startUp()* routine) and triggers the StartEvent to activate its associated VLRUs (Card Reader, etc.).

Once StartEvent has occurred, it proceeds to receive I/O from the message processor
15 **404** and the transaction dispatcher **421**. It determines which sub-VLRU should process the message and forwards it to their FromMux queue for handling, and then it responds an Ack or Nak to the PI board, as applicable to satisfy its communications protocol needs.

Messages from the VLRUs intended for the PI Mux are sent to this VLRU as well via
20 their ToMux queues. It encodes the messages as needed, forwards them and handles

the Ack/Nak protocol. It has its own version of *NAUGetMP()* in order to use the *PI_Message* data handling routines.

The primary access terminal VLRU responds to loopback messages from the CFS TestPort NAU via Ethernet for BIT functionality. It logs communication failures

5 between the primary access terminal (PAT) **225** and the cabin file server (CFS) **268**. It controls the BITE and COMM LEDs on the front of the PAT, lighting them to indicate failures. The *PatVLRU* class is also a *PIInterface* class child only so it can synchronize operation via the *StartEvent* trigger. Its constructor reads the registry

10 "VerbosePATVLRU" settings (for test purposes) and the "BITTestInterval" value for BIT testing timeouts. *StartItUp()* launches a thread called *BitTestMonitor()* and then loops continuously to process messages. First, it waits to receive a *SubProcessStart* message, then it waits for the *StartEvent* to know that *PI_Mux* is alive and ready to go.

SubProcessStop causes it to kill the *BitTestMonitor()* thread and then die. All other messages from the message processor **404** are ignored. If an Ethernet Loopback

15 message is received from Test Port NAU via the transaction dispatcher **421**, it uses *EthernetLoopback()* to return a message via *NAU::NAUPutTD()*, and then tell the *BitTestMonitor* that the loopback occurred. All messages from the *PI_Mux* are returned to it via *PIInterface::ToMuxPut()* and otherwise ignored as an error. The *BitTestMonitor()* turns both BITE and COMM LEDs on at the primary access terminal **225** to show that

20 they are both working. Then it turns off the BITE light and waits. If it receives notification from *StartItUp()* that a loopback occurred, it turns off the BITE LED. If it times out waiting for a loopback, it turns the LED back on. If it gets several successive failures (timeouts) it logs it to the event log. If it gets told to exit by *StartItUp()*, it turns the BITE LED on and dies.

25 The Printer VLRU periodically queries the control center printer for its status and provides this status as an unsolicited message to the PAT GUI **426**. The *PrinterVLRU* object is a *PIInterface* class child only so that it can sync up with *PI_Mux* to start processing. Its constructor retrieves "PrinterPollInterval" and "PrinterStatusTimeout" from the Registry and then creates *hEventPrinterStatusChange* and *hEventStop* to

30 communicate to the monitor thread that is created in *StartItUp()*. This class also has a *PrinterStatus* class object called *Printer* which does all the actual communication with the printer over the Ethernet network **228**. *StartItUp()* launches the

PrinterStatusMonitor() thread, and then loops forever. The only message processor messages it processes are:

SubProcessStart After receipt it waits for the StartEvent signal to continue

SubProcessStop Kills the Monitor thread and dies

StartItUp() ignores all messages from the transaction dispatcher **421**. It echoes any messages back to the PI Mux and otherwise ignores them. If *StartItUp()* receives a
5 *PrinterStatus* event (from the monitor), it calls *SendPrinterStatus()* to build the status message and then sends it to the CAPI Message Service via *NAU::NAUPutTD()*.

PrinterStatusMonitor() uses the *PrinterStatus* object of this VLRU to talk to the printer. If it cannot talk to the printer via *PrinterStatus::InitializePrinterSNMP()*, it logs the error to the event log. If changes in the printer status occur, it tells *StartItUp()* via
10 *hEventPrinterStatusChange*. It logs the following other events to the event log: Out of Paper, Has Paper Again, any other errors, and 1st Status after any error.

SendPrinterStatus() uses *PAT_Message* routines to convert the *PrinterStatus* info to ASCII. It then sends it on to the CAPI Message Service via *NAU::NAUPutTD()*. The *PrinterStatus* class constructor connects to the Printer via the Ethernet network **228**
15 using *InitializePrinterSNMP()*, requests the status via *RequestRawPrinterStatus()*, Interprets (with *StatusDescription()*) and displays the printer status info using *DisplayPrinterStatus()*, among other private routines.

Transaction Dispatcher

The transaction dispatcher **421** will now be discussed with reference to Figure 14. The
20 transaction dispatcher **421** comprises NAU Clients **551**, a NAU Server **552**, a Router and Mail Slots **553**, a Services Server **554**, and Service Clients **555**. The NAU Server **552** comprises a plurality of *OutPipeProcessors()* **552a**, a plurality of *InPipeProcessors()* **552b**, and a plurality of NAU Out FIFO Queues **552c**. A plurality of Name Pipes **556** couple the NAU Clients **551** to the *InPipeProcessors()* **552b** and *OutPipeProcessors()*
25 **552a** and *InPipeProcessors()* **552b**. The NAU Out FIFO Queues **552c** are respectively coupled to the *OutPipeProcessors()* **552a**. The Services Server **554** comprises a plurality of *OutPipeProcessors()* **552a**, a plurality of *InPipeProcessors()* **552b**, and a plurality of Service Out FIFO Queues **552d**. The Service Out FIFO Queues **552d** are respectively coupled to the to the *OutPipeProcessors()* **552a**. A plurality of Name Pipes

556 couple the Service Clients **555** to the OutPipeProcessors() **552a** and InPipeProcessors() **552b**.

The Router and Mail Slots **553** comprises the LRU table **553a**, which is coupled to an AddMessageToOutQueue() **557**. The InPipeProcessors() **552b** of the NAU Server **552**
5 are coupled to the AddMessageToOutQueue() **557**. Also, the InPipeProcessors() **552b** of the Services Server **554** are coupled to the AddMessageToOutQueue() **557**. The AddMessageToOutQueue() **557** is coupled by way of a IntraNodal Output Queue **553b** to an IntraNodalOutThreadProcessor() **558a**. The IntraNodalOutThreadProcessor() **558a** is coupled to any process on any NT line replaceable unit connected by way of the
10 Ethernet network **228**. Similarly any process on any NT line replaceable unit connected by way of the Ethernet network **228** to an IntraNodalInThreadProcessor() **558b** is coupled to the AddMessageToOutQueue() **557**.

The primary duty of the Transaction Dispatcher **421** is to move information between the logical devices (or NAU clients **551**) and the Application Services(or service clients
15 **555**). By using a Transaction Dispatcher **421**, the NAUs and the Services do not have to control I/O traffic. In addition, the number of Named Pipes (or communication lines) between processes is greatly reduced because each Service and NAU need only communicate with one process, rather than each other. This simplifies the software design and efficiently uses a finite number of available Named Pipes.

20 To support this, the transaction dispatcher **421** includes the following sub-functions. Upon demand, the transaction dispatcher **421** creates two Named Pipes (input and output) for each NAU and Service, maintaining the lookup table **553a** of pipe names (or handles) and their corresponding NAU or Service IDs.

The transaction dispatcher **421** uses Blocking I/O to await a message from any
25 incoming Named Pipe. Once it receives an IFE-structured Message, it examines only the message destination (NAU or Service ID) portion of the message to identify the appropriate Named Pipe to use by cross-referencing the lookup table **553a**. It then routes the complete message to an output queue **552c** and **552d** for that Named Pipe.

30 The transaction dispatcher **421** uses Mail Slots to send and receive messages from processes that are resident on remote WINDOWS NT line replaceable units, routing them to the appropriate destination. Using this technique, any Service or NAU can

communicate with any other Service, NAU or program on this line replaceable unit or any line replaceable unit that also runs a transaction dispatcher **421**.

The detailed design of the transaction dispatcher **421** will now be discussed. Figure 14 illustrates the transaction dispatcher function and data paths. TD.EXE is the
5 transaction dispatcher **421** and is comprised of the following file:

TRNSCTND.CPP - the Main Program and TransactionDispatcherClass

The *Main()* function of the transaction dispatcher **421** is responsible for initializing all its processing threads using *CreateMainServiceThreads()*, *CreateMainNAUThreads()* and *CreateMainIntraNodalThreads()* functions. These threads operate continuously to move
10 data from source to destination.

Main() also registers its existence with the system monitor program **412** (using *Register()*) and waits for a shutdown signal from the system monitor **412**, after which it performs an orderly shutdown of all its threads via its destructor. The relationships of the transaction dispatcher functions are shown in Figure 14.

15 The term NAU Server means a set of routines that comprise a "Server" for the Network Addressable Unit processes. Two threads, *NAUInThreadProcessor()* and *NAUOutThreadProcessor()* are used to launch a set of I/O threads (*InPipeProcessor()* **552b** and *OutPipeProcessor()* **552a**) for an as yet unknown NAU process. The first message received from any NAU registers it to this set of threads, causing
20 *NAUInThreadProcessor()* and *NAUOutThreadProcessor()* to launch another set, getting ready for the next NAU to speak. In this way, the transaction dispatcher **421** is dynamic and can support different NAUs as needed.

With regard to Incoming Messages, *InPipeProcessor()* **552b** continuously receives an IFE Message from its Input Pipe and sends it to *AddMessageToOutQueue()* **557** which routes
25 it to the appropriate output queue. With regard to Outgoing Messages, *OutPipeProcessor()* **552a** continuously reads an IFE Message from the NAU Out Queue **552c** and sends it to its associated NAU process via its named pipe **556**.

The term Services Server **554** means the set of routines that comprise a "Server" for Cabin and Sales Services. Two threads, *ServiceInThread()* and *ServiceOutThread()* are

used to launch a set of I/O threads (*InPipeProcessor()* **552b** and *OutPipeProcessor()* **552a**) for an as yet unknown Service process. The first message received from any Service registers it to this set of threads, causing *ServiceInThread()* and *ServiceOutThread()* to launch another set, getting ready for the next Service to speak. In
5 this way, the transaction dispatcher **421** is dynamic and can support different Services as needed.

With regard to Incoming Messages, *InPipeProcessor()* **552b** continuously receives a message from its Input Pipe and sends it to *AddMessageToOutQueue()* **557** which routes it to the desired output queue. As for Outgoing Messages, *OutPipeProcessor()* **552a**
10 continuously reads a message from the Service Out Queue **552d** and sends it to its associated Service process via its named pipe.

The router **553** comprises routines that use the lookup table **553a** to determine which processing thread needs to process the message. With regard to the From Any Source Router, upon demand, *AddMessageToOutQueue()* **557** calls the appropriate *PutData()*
15 function to move the message to the NAU or Service output queue.

The LRU Lookup Table **553a** is an internal memory structure that contains an entry for each device in the system **100**. It contains sufficient information to translate message addresses for any piped destination. Specifically, it contains: Pipe Handle, Registeree, Queue Pointer, Queue Semaphore, and Thread Pointer. This information is kept in an
20 SQL database table which is read during the *Main()* initialization via *CreateLRUTable()*. Then as piped processes register with the transaction dispatcher **421**, their identities are updated in this table **553a** via *AddQueueInfoToLookUpTable()*, *AddThreadPointerToLookUpTable()* and *AddPipeHandleToLookUpTable()* functions.

The term Intra Nodal Server means the set of routines that permit communications
25 between two WINDOWS NT line replaceable units connected via the Ethernet network **228**. This differs from the Named Pipe communications in that a set of communication pipes is not created and maintained for each process. Instead, a single mail slot is maintained for incoming messages, and an appropriate outgoing mail slot is created for each outgoing message as needed.

30 With regard to Incoming Messages, *IntraNodalInThreadProcessor()* **558b** continuously receives a message from its Mail Slot and sends it to *AddMessageToOutQueue()* **557**,

which routes the message to the appropriate destination. The destination may be an NAU, a Service or even back out to another process via a mail slot. With regard to Outgoing Messages, *IntraNodalOutThreadProcessor()* **558a** continuously reads a message from its Out Queue and sends it to its associated process via the Mail Slot. This mail
5 slot is created for just this message, and then is closed after the message is sent.

The System Monitor program **412** is automatically invoked by the operating system when the line replaceable unit boots. The system monitor function and data paths are shown in Figure 15. The System Monitor program **412** comprises a *service_main()* **561** that is coupled to a *StopServices()* **565**. The System Monitor program **412** is coupled to
10 console services **562** by way of a *ConsoleInput()* **562a**. Other outside testing processes **562b** are coupled to a *service_cntrl()* **563**. A WatchDogDrive **591** along with the *service_cntrl()* **563** and the *ConsoleInput()* **562a** are coupled to a MainQueue **564**.

A Process/Event Lookup table **567** is coupled to a *GetSystemFullActionItemn()* **568** that interact with a *serv_server_main()* and *server_main()* **566**. The MainQueue **564** is
15 coupled to the *server_main()* **566**. The MainQueue **564** is coupled to a *ProcessEventList()* **569**. The *ProcessEventList()* **569** is driven by a plurality of Sysmon Class and Process Class State Machine Functions **570a**, **570b**. Output of the Process Class State Machine Functions **570b** are coupled to OutputQueues **571** of various Process and Process I/O functions **572**, **572a**. The Process and Process I/O functions
20 **572**, **572a** are coupled by way of *OutputLoop()* **573** and Name Pipes **574** to the transaction dispatcher **421** and message processor **404**. The transaction dispatcher **421** and message processor **404** are coupled by way of Name Pipes **574** to respective *InputLoop()* **575**. The respective *InputLoop()* **575** are coupled to the MainQueue **564**.

Sorted functions of the Process Class State Machine Functions **570b** are coupled by
25 way of a QueueSorted Queue **576** and a *StatPutQueueThread()* **577** to the MainQueue **564**. Additional runtime processes **578** are also coupled by way of Name Pipes **574** to *SysmonConnectThreads()* **579**. The *SysmonConnectThreads()* **579** are coupled by way of a *Register::RegisterInput()* **580** to the Process functions **572**.

A WatchDogDrive **591** is provided that comprises a WatchStaticThread **592**, a
30 DogQueue **593** and a *StatQueueThread* **594**. The WatchStaticThread **592** outputs to the DogQueue **593** and a *PExternalKillProcess()* from the Process Class State Machine

Functions **570b** are coupled to the DogQueue **593**. The DogQueue **593** outputs to the StatQueueThread **594** which in turn drives the WatchDog Driver **410**.

The System Monitor program **412** operates in the background during the life of the control center applications and has the following four basic duties:

- Start-Up The Start-up function starts the Executive and Application programs after any system boot.
- Shutdown The Shutdown function provides an orderly shutdown, flushing working data from memory to hard disk as appropriate. Then it terminates the execution of the Executive and Application programs.
- Power Down This function works in conjunction with the Uninterruptable Power Supply (UPS) **400** which is connected via one of the serial ports on each of the Control Center LRUs. The operating system is notified by the UPS when power has been lost, causing it to start this function (POWERDWN.EXE, POWERDWN.CPP). The Power Down program notifies the System Monitor that power has been lost to invoke an orderly shutdown using a 'ProcessStop' IFE Message. POWERDWN.EXE is listed in the NT Register as the program to start when power failure is detected.
- Restart The Restart function scans for failed Executive and Application programs, and restarts them.

5 The detailed design of The System Monitor **412** will now be discussed.

SYSMON.EXE includes the following primary components:

- SYSMON.CPP The *Main()* Program and Sysmon Class
- DLYSCHDL.CPP The DelayScheduler Class
- PROCESS.CPP The Process Class to manage the external programs
- QUEESORT.CPP The QueueSort Class - Used to manage sorted queues
- RGSTRBJC.CPP The Register Class used to register external processes
- SMScript.CPP The SysmonScript Class to manage the state tables
- SYSGLOBA.CPP Global routines to map to state-machine functions
- SYSMNCNN.CPP The SysmonConnect Class used to communicate externally
- SYSMNSPC.CPP SysmonSpecial Class

UTL150.CPP RandomPack and Liner Classes plus other utilities

WTCHDGDR.CPP The WatchDogDrive Class

Referring to Figure 15, the System Monitor **412** is a *Windows NT Service Process*, which means it runs in the background and is controlled by the following functions in the Win32 SDK Library: *StartServiceCtrlDispatcher()*, *ControlService()*, *Handler()*, *RegisterServiceCtrlHandler()*, and *ServiceMain()*.

- 5 The System Monitor **412** was designed as a state machine, but, it's actual code is more of an in-line design with state flags used to keep track of processing. For example, a single function calls another function which calls yet another function, and all three are only used once. For clarity, these are grouped together herein.

- The *main()* function updates its revision history information in the WINDOWS NT
10 Register, determines where to find the other programs to be started, launches itself as a WINDOWS Service by connecting to the WINDOWS Service Control Manager via *StartServiceCtrlDispatcher()*, identifying *service_main()* **561** as the main function for this service. The *main()* function is identified in advance of runtime during software installation, which calls the NT *CreateService()* to set up the System Monitor **412** as a
15 WINDOWS NT Service. *Main()* also alters its behavior depending on whether a console service **562** (i.e., a display monitor) is available for testing. *Main()* uses *SetConsoleCtrlHandler()* to allow someone to abort the programs by pressing Ctrl-C at any time.

- Service_main()* **561** is the main program that continually runs when the system monitor
20 service is running. It calls *RegisterServiceCtrlHandler()* to identify *service_ctrl()* **563** to NT as the function to execute when other outside programs want to alter the execution of this service. It maintains a combination state-checkpoint to identify to the outside world (i.e., test programs) what it is doing:

State	Checkpoint(s)	Service Control Code to get there
SERVICE_START_PENDING	1,2	(none)
SERVICE_RUNNING	0	Service_Control_Continue
SERVICE_PAUSED	0	Service_Control_Pause

SERVICE_STOP_PENDING	0,1	Service_Control_Stop
SERVICE_STOPPED	0	(none)

When *service_main()* **561** starts, it is in SERVICE_START_PENDING state, checkpoint #1. If it successfully creates all its event handles, it moves to checkpoint #2. It then sets up a Security Descriptor and launches a *serv_server_main()* thread, moving its state to SERVICE_RUNNING.

- 5 The outside world can alter its state by calling *service_ctrl()* **563** and providing a Service Control Code. The table above shows which state *service_main()* **561** moves to based on the control code received. If the SERVICE_STOPPED state is reached, a *hServDoneEvent* is triggered, causing this function to exit, terminating the System Monitor **412**.
- 10 The *service_ctrl()* **563** routine is called via an NT Service utility *ControlService()* by any outside program that wishes to control the System Monitor service in some way. *Service_ctrl()* **563** uses a *MainQueue* **564** to issue commands to various Process Class objects that are running.

- The *server_main()* **566** routine creates the Sysmon object *MainSysmon* and executes its
- 15 *Sysmon::StartHandler()* to get the other processes running. If running in test mode, *server_main()* **566** is called directly by *main()*. If running in runtime mode, *server_main()* is called by *serv_server_main()* **566** which is a thread launched by *service_main()* **561** (the main program initiated by the WINDOWS NT Service Manager). Finally, *server_main()* **566** calls *Sysmon::MainQueueProcessing()* which loops until it is time to
- 20 shutdown. Once *MainQueueProcessing()* returns, this thread ends.

- The *StopService()* function **565** can be used by any thread to report an error and stop the Sysmon Service. It logs the reason that it was called via *ReportEvent()*, and tells *service_main()* to abort via *hServDoneEvent*. Derived from *Process*, the Sysmon Class contains all the software needed to drive all the Process Class state machines. It uses
- 25 *MainQueue* **564** as its primary input.

Sysmon::StartHandler() is responsible for launching all the external programs and providing a means to monitor them. First, it compiles the file *SYSMON.ASC*. Then, it queries the NT Registry to determine which type of line replaceable unit it is running on

(PAT, CFS or test unit) to know which processes to initiate. It creates a SmScript object to establish system-level state machine tables using *SmScript::InitiateTables()*. It sets up communications with the UPS **400** via a communication port, and determines whether the UPS **400** is working, whether the line replaceable unit has power and whether it should continue processing as a result. Finally, it creates the following objects and runs a starter function for each of them:

Object	Class	Starter Function
ConnectTask	SysmonConnects	<i>StartHandlerConn()</i>
MyWatchDog	WatchDogDriver	<i>StartHandler()</i>
ProcessItem[i]	Process	<i>Initialize()</i>
(one for each process for this LRU)		(<i>StartHandler()</i> is called later, after Process Registration)
SelfHeartBeatTask	SysmonSpecial	<i>StartHandlerSpecial()</i>
SelfMonitorTask	SysmonSpecial	<i>StartHandlerSpecial()</i>
DelayTask	DelayScheduler	<i>StartHandlerDelay()</i>
QueueSorted	QueueSort	None, used to schedule events (i.e., <i>Process::PPostExternalKillProcess()</i>)

It creates an EventOnQueue object with an UpSystem event in it and places it in the MainQueue queue **564** to start the external processes (beginning with the Transaction Dispatcher **421**). Finally, it calls *Sysmon::MainQueueProcessing()* which loops forever, using *Sysmon::MainProcess()* to handle all processing requests which get placed on the MainQueue queue by this and the other classes' threads.

The basic flow of startup events is:

UpSystem Event from Sysmon::StartHandler	start Transaction Dispatcher
Registration received from Transaction Dispatcher	start Message Processor
Registration received from Message Processor	start Service
Registration received from Service	start NAUs

In this way, the system comes up in a sequential, orderly fashion.

MainQueueProcessing() loops forever waiting for Events to appear on the MainQueue queue. Once found, it calls *MainProcess()* which uses the information from the EventOnQueue object to lookup the 'real' action(s) to perform using the
5 *SmScript::GetSystemFullActionItem()* and *Process::GetTotalMatrix()* functions. It processes these actions using *Sysmon::ProcessEventList()* **569**.

ProcessEventList() **569** is only called by *MainProcess()* to look up and process the desired actions from a table of actions, which are maintained in the SmScript Class.

10 The above processes loosely form a state machine. In fact, a series of flags denoting the state of the Sysmon system is used to decide what to do next. The following routines are used to support this state machine. There is only one system level Action List to do: UpSystem[] or UpPAT[]. They each have several Actions which point to SYSGLOBAL functions. These functions in turn determine whether they should call a Process class function or a Sysmon class function. The Sysmon Class functions are:

PSysSoftReboot() Calls *softboot()* which uses the *ExitWindowsEx()* command to reboot the LRU. Called via the global *PSoftReboot()* function.

PSysHardReboot() Reboot via *WatchDogDriver::Watch_Reboot()* which causes the hardware to reset. Called via the global *PHardReboot()* function.

PSysGetState() Retrieves the state of the system state machine. Called via the global *PGetProcessState()* function. This is not used: The variable 'selfstate' is used directly.

PSetSysState() Sets the state of the system state machine, which is used in *GetSystemFullActionItem()* along with the current event to know what action to do to the system. Generally called via the global *PSetState()* function.

15 The SysmonConnects class contains code necessary to communicate to the other processes in the line replaceable unit, for example the Transaction Dispatcher **421**. It establishes a Named Pipe set to communicate with each of them. It works very closely with the RegisterObject Class to provide pipes to each of the Process Class handlers. This method of creating a generic Named Pipe set and assigning it to the first process to
20 register was taken from the Transaction Dispatcher **421**, however, because this

program directs which external process is executed, and therefore which one is registered.

The *StartHandlerConn()* routine simply launches two threads, one for Named Pipe Input and one for Named Pipe Output.

- 5 *InputConnectThread()* is launched by *StartHandlerConn()*. It calls *DynInput()* which loops forever, opening a Named Pipe for input, then waiting for an outside process to connect to it. It then creates a temporary *RegisterObject* class object to tie this Named Pipe to the connecting outside process, and loops to create another named pipe.

- 10 *OutputConnectThread()* is launched by *StartHandlerConn()*. It calls *DynOutput()* which loops forever, opening a Named Pipe **574** for output, then waiting for an outside process to connect to it. It then creates a temporary *RegisterObject* class object to tie this Named Pipe to the connecting outside process, and loops to create another named pipe.

- 15 When the *DynInput()* and *DynOutput()* routines of *SysmonConnect* receive input from an outside process to claim a Named Pipe, they create a temporary *RegisterObject* class object to receive Registration information from the calling process and tie the current Named Pipe to the *Sysmon Process* object associated with that process. In this way, each *Process* object has its own set of I/O to its corresponding external process.

- 20 This launches *RegisterInput()* as a new thread. It is called by both *SysmonConnects::DynInput()* and *DynOutput()*. The *RegisterInput()* code calls *DynRegisterInput()* and kills itself and its *SELF* (its own object) when *DynRegisterInput()* is done. The *DynRegisterInput()* routine tries to read from the Named Pipe to get a Registration message from the outside process. It attempts this 100 times before it gives up and exits. If successful, it calls *Process::StartHandler()* to get its Input or Output thread started with this Named Pipe.

- 25 The *SmScript Class* contains the tables of events and actions that are used to move each *Process* object state machine from one state to the next. *FullActionItem* arrays read like pseudo code, each entry containing the following set of information: Function-Name, Process ID, Additional Data for the named Function. Thus, for example, .
30 "{PHardReboot,systemflag,150}" means to run global function *PHardReboot(150)*, which in turn runs the system function *Sysmon::PSysHardReboot(150)*.

The *InitiateTables()* routine is called once per power-up to prepare the event/action table *SysMatrix* as appropriate for the runtime LRU system monitor. It fills this array with a pointer to the *UpSystem* or *UpPAT FullActionList* array.

5 The *InitProcess()* routine is called by *Process::Initialize()* for each process object created to complete the tables for the Process to use. It moves the appropriate event/actions into this Process object's *TotalMatrix* array. This permits the use only one System Monitor executable program, even though its specific duties vary from line replaceable unit to line replaceable unit. For example, the primary access terminal LRU does not have the Service process and the File Server LRU does not have the primary access
10 terminal NAU process.

The *GetSystemFullActionItem()* routine returns the appropriate value from the *SysMatrix* table. The is used only in *Sysmon::MainProcess()*.

The Process Class *Initialize()* initializes the *TotalMatrix* table via *SmScript::InitProcess()*.

15 The Process Class *StartHandler()* is called by *RegisterObject::DynRegisterInput()* after an external process has successfully registered with Sysmon. It calls *StartInputThread()* or *StartOutputThread()* depending on the Named Pipe which was registered.

StartInputThread() is called by *StartHandler()* and simply launches a new thread, *InputLoop()*. *InputLoop()* in turn simply calls *DynInputLoop()* for this process. *DynInputLoop()* continuously loops, collecting any IFE Message from its Named Pipe
20 (using the *IFE_Message::GetData()* function), and processing it using *ProcessIncoming()*. Errors are reported using *ProblemReport()* and the *MainQueue* is updated to control either a shutdown or retry, depending on the severity of the error. If it's error is severe enough, it exits the loop and the thread dies.

StartOutputThread() is called by *StartHandler()* and simply launches a new thread,
25 *OutputLoop()*. *OutputLoop()* in turn calls *DynOutputLoop()* for this process. *DynOutputLoop()* continuously loops, collecting any IFE Message from its *OutputQueue* and sending it out its Named Pipe (using the *IFE_Message::PutData()* function). Errors are reported using *ProblemReport()* and the *MainQueue* is updated to control either a shutdown or retry, depending on the severity of the error. If it's error is severe enough,
30 it exits the loop and the thread dies.

GetTotalMatrix() returns the corresponding Action List from TotalMatrix for the current event and state of this process. It is called only by *Sysmon::MainProcess()*.

The following State Machine routines are stored in the SmScript State Machine Tables (called FullActionItems) and are activated as a result of certain event/state

5 combinations via *ProcessEventList()*:

PExternalKillProcess() Kills its associated external process with the *TerminateProcess()* function. Called from the global *PExternalKillProcess()* function.

PGetProcessState() Returns the current state of this state-machine. Called from global *PGetProcessState()*.

PKillProcess() Issues IFE message to external process to commit suicide. Currently not supported by most external processes. Called from global *PKillProcess()*.

PPostExternalKillProcess() Uses the *QueueSorted::PutSorted()* function to schedule a Kill command to go into the MainQueue later. Called from global *PPostExternalKillProcess()*.

PSetState() Updates the current state of this state-machine. Called from global *PSetState()*.

PStartProcess() Gets the full pathname of the associated external process and starts executing it. Called from global *PStartProcess()*.

The WatchDogDriver class contains code necessary to manage watchdog driver messages. The watchdog is a hardware component that is responsible for re-starting the line replaceable unit if it fails to receive input in regular intervals. Using this class ensures that the watchdog receives that input from the System Monitor **412** regularly,
10 unless some system or software error prevents it. Commands available for use by Sysmon and Process objects are: *Watch_Enable()*, *Watch_Disable()*, *Watch_Maintain()* and *Watch_Reboot()*. These functions all put the corresponding watchdog action command onto a DogQueue **593** for processing by *DynQueueThread()*, which is the only function allowed to actually talk to the driver directly.

15 The Watchdog Driver **410** controls a watchdog device supplied by Octagon (called the Octagon PC-450) which, when activated by the System Monitor **412**, reboots the system unless it is accessed no less than every 1.6 seconds by the watchdog driver **410**. The driver **410** can receive a command to force a reboot of the system, which stops it from

updating the watchdog driver **410**. The watchdog driver **410** then times-out and a reboot occurs. Use of the watchdog driver **410** helps improve system availability in the event of a software or hardware anomaly that causes unpredictable results in system operation.

- 5 *Sysmon::StartHandler()* creates the WatchDogDriver object and calls its *StartHandler()* routine, which is responsible for launching two threads. One thread manages the I/O with the watchdog hardware, and the other thread maintains the regular output commands to it.

- 10 *WatchStaticThread()* calls *WatchDynamicThread()* which places a request for a 'strobe' to the watchdog onto the DogQueue **593** (via *Watch_Maintain()*). It then sleeps for 1,000 seconds and loops again.

- 15 *StatQueueThread()* calls *DynQueueThread()* which performs the actual output to the watchdog hardware, "\wdog". It reads a command request from the DogQueue queue **593** and calls either *Watch_Enable_DO()*, *Watch_Disable_DO()*, *Watch_Maintain_DO()* or *Watch_Reboot_DO()* to perform the requested command using the WINDOWS *DeviceIoControl()* function.

- 20 The QueueSorted Class coordinates activity in the MainQueue **564**. For example, it is sometimes necessary to schedule tasks to occur in the future (such as shutdown due to loss of power). To do this, QueueSorted provides the following functions. The *QueueSorted()* constructor creates its own queue and launches a thread, *StatPutQueueThread()* to monitor the queue periodically. The *PutSorted()* function allows users to add elements to the queue along with a timestamp indicating the time at which this element should be dealt with. The *PutSorted()* function puts them on the queue sorted by the timestamp so that they are dealt with in the proper order.

- 25 *StatPutQueueThread()* calls *DynPutQueueThread()* which loops forever, trying to process the elements on its queue. If the current time is less than or equal to the time of the element's timestamp, the element is moved to the MainQueue for processing by *Sysmon::MainQueueProcessing()*. Even though it is scheduled, it is only placed at the end of MainQueue **564**, not at the front. Therefore, it does not supercede any existing
30 MainQueue elements.

The following common software libraries of functions and utilities are used throughout the primary access terminal **225** and cabin file server **268** applications.

The CAPI (RPC Client) Library **427**, or RPCLIENT.DLL **427**, provides a means of communication between the graphical user interface **426** and the rest of the system

5 **100** through the primary access terminal NAU **409**. The RPC Client Library **427** is shown in Figure 16. The RPC Client Library **427**, or RPCLIENT.DLL **427**, comprises a ToExec Queue **770**, a FromExec Queue **771**, a FromGUI Queue **772**, and an APIINT::CMSToGui Queue **773**. The ToExec Queue **770** and FromExec Queue **771** are coupled to transmit and receive CGUIService::ProcessRequest() threads **775**. The

10 FromGUI Queue **772** is coupled to transmit various APIINT.CCP calls **782** to the CGUIService::ProcessRequest() threads **775**. The APIINT.CCP calls **782** are derived from CAPI_C.C Calls **783** that are routed by way of the Ethernet network **228** from CAPI_S.C calls **784** in the Services.exe program **477** running in the cabin file server **268**. The CGUIService::ProcessRequest() threads **775** route messages to and from a

15 local transaction dispatcher **421a**. The APIINT::CMSToGui Queue **773** receives messages from the local transaction dispatcher **421a** and from a remote transaction dispatcher **421b**. Messages sent from the transaction dispatchers **421a**, **421b**, are forwarded to an APIINT::CAPIMessageInThreadProcedure(): **785** which routes the messages to the CAPI Message Service Window **781**.

20 The PAT GUI **426** cannot be communicated to via Named Pipes because it is a WINDOWS application, and must therefore communicate using standard WINDOWS messages. The CAPI Message Handler is a set of routines within the CAPI Library **427** which provides a bridge between the IFE messages and the GUI WINDOWS application. Instead of communicating via Named Pipes directly with the GUI, Unsolicited Messages

25 **780** utilize Named Pipes into a Message Service Window **781**. In order for the GUI **426** to be able to receive them, it must have already opened or started a Window capable of receiving this type of message in the background using the appropriate CAPI Library calls.

Any WINDOWS User Interface that needs to communicate with the transaction

30 dispatcher(s) **421** of the primary access terminal **225** and/or cabin file server **268**, or who needs to access the CAPI calls in the SERVICE.EXE program of the cabin file server **268** needs to link in and use the RPCLIENT.DLL library **427** which contains the following files:

APIINT.CPP *Dllmain()* and Visual Basic Application Interface
Routines

CAPIC.C The CAPI's RPC Client Support Routines

HOOKSDLL.C 'Canned' Dynamic Link Library 'glue' from MICROSOFT

CGUSRVCE.CPP Core Gui (CGUIService) Class (connects to TD)

CPMSSGSR.CPP CAPI_Message_Service Class

UNSLCTDM.CPP Unsolicited_Message Class

APPIINT.CPP is the interface between the graphical user interface **426** (GUI or Main Application) and the rest of the system **100**. In order to connect to the rest of the system **100**, *InitializeInterfaceVB()* must be called to establish communications with the transaction dispatcher(s) **421** and start *CAPI_Message_Service::GetTDInMessage()*

5 threads, which receive all unsolicited messages from the transaction dispatcher(s) **421**.

A call to *StartMessageServiceVB()* launches a thread, *CAPIMessageInThreadProcedure()* to continuously read and process unsolicited messages obtained from the CMSToGui Queue, supported by the CAPI_Message_Service class object.

10 The cabin file server **268** and the primary access terminal **225** have many similar functions such as message processors **404** and **452**, transaction dispatchers **421** and **473**, system monitors **412** and **454**, and ARCNET drivers **412** and **450**. The discussion of these functions in conjunction with the primary access terminal **225** presented above also applies to the cabin file server **268** with differences as noted. The cabin file server executive extension is discussed with reference to Figure 10.

15 The cabin file server Executive Extension set of routines together with the Common Executive Software forms the generic application for the cabin file server **268**. It includes the following components: Backbone NAU **463**, Seat NAU **465**, VCP NAU **462**, Test Port NAU **461**, High-Speed Download Driver **449**, Services **477** including Cabin Services **478-482**, **487-490** and Sales Services **483-486**, CAPI calls **476**, and the
20 database **493**, as shown in Figure 10. The function and data paths of the many of the NAUs **461-465** have a structure substantially identical to the primary access terminal **225** structure shown and described with reference to Figure 10 regarding the basic network addressable units function and data paths. The changes generally relate to the structure of the state machine objects that are used in the respective NAUs **461-465**.

The detailed design of the cabin file server executive extension will now be discussed. The BACKBONE.EXE routine contains the backbone NAU program **463**. Figure 17 illustrates the backbone NAU program **463** function and data paths. The backbone NAU **463** is responsible for receiving and processing messages that originate from the audio-video units **231**, area distribution boxes **217**, passenger entertainment system controllers PESC-A **224a** and the PESC-V **224b**, and any other communications backbone line replaceable unit. The structure of the backbone NAU **463** is substantially the same as the network addressable unit **409** function in the primary access terminal **225** and data paths discussed with reference to Figure 13. The backbone NAU **463** comprises a PESC-V NAU dispatcher **500a** and PESC-V and PESC-AP VLRU state machine objects **510a** shown in Figure 17. The backbone NAU program **463** includes the following primary components:

BACKBONE.CPP	The <i>Main()</i> Program
PSCPDSPT.CPP	The NAU Dispatcher for the PESC-A
PSCVDSPT.CPP	The NAU Dispatcher for the PESC-V
PSCPVLRU.CPP	The VLRU Class for the PESC-A
PSCVVLRU.CPP	The VLRU Class for the PESC-V

The *Main()* program is a standard NAU starter that registers the Backbone NAU **463** with the system monitor **454** using a *SysMonInterfaceClass::Register()* routine.

15 The *Main()* program launches a *PescV_Dispatch* object to open up PESC-V VLRU communications between the message processor **452** and the transaction dispatcher **473**, and a *PescAp_Dispatch* object as well to launch the PESC-A **224a**. It calls *PescV_Dispatch::startItUp()* to initialize both of the VLRUs.

20 The *Main()* program launches 14 *Session()* threads, although only three are actually in use. It sends a *SubProcessStart* command to the VLRUs which causes the first *Session()* threads in to connect to each VLRU permanently. Only the *PescV_Dispatch* object maintains a set of *MPRight()*, *MPLeft()*, *TDRight()* and *TDLeft()* threads.

Finally, the *Main()* program sleeps forever until interrupted. It does not call *shutItDown()* to close all the VLRUs down and exit gracefully. Instead, it simply deletes the *PescV_Dispatch* object and dies.

The VLRUs in this NAU contain their own set of *NAUPutTD()*, *NAUPutMP()*, *NAUGetTD()* and *NAUGetMP()* routines because they use I/O routines from the *PESCA_Message* class and *PESCV_Message* class instead of the *IFE_Message* class.

5 The *PescAp_VLRU* object attaches directly to the first *Session()* possible via its *StartItUp()* function. Then it continuously loops waiting for data to appear in its message processor and transaction dispatcher input queues. It processes the following commands:

FlightInfoRequest IFE Function from the **PESC-A 224a**. This VLRU creates its own IFE message to the IFE Control Service asking for Flight Information.

10 FlightInfoUpdate IFE Function from the IFE Control Service, after the **PESC-A 224a** issues it a FlightInfoRequest. This VLRU creates its own IFE message to forward this to the **PESC-A 224a** via the message processor **452**.

15 *PES_CONTROL* command from the **PESC-A 224a**. This VLRU examines the state of the WeightOnWheels using *PESCA_Message::IsGearCompressed()*. If the state of the wheels has changed, it forwards this new information to the database using *NotifyNewFlightState()*, and to the CAPI Message Service via its own *NAUPutTD()*. All other messages are ignored.

20 The *PescV_VLRU* object attaches directly to the first *Session()* possible via its *StartItUp()* function. Then, it continuously loops waiting for data to appear in its message processor **452** and transaction dispatcher **473** input queues. It processes the following commands:

VideoControl command from IFE Control Services is formatted and forwarded to **PESC-V 224b**. Any other message from **PESC-V 224b** is routed directly to the IFE Control Services.

25 The Seat NAU program **465** function and data paths are depicted in Figure 18. The Seat NAU **465** controls communication with the seats in the aircraft **111**. It maintains three kinds of VLRUs: one that controls high speed download of games and programs to the seats **123**; one that periodically broadcasts status messages to the seats **123**, and one for each seat **123** to communicate during the flight for sales and other requests.

The structure of the Seat NAU **465** is substantially the same as the Network Addressable Units function and data paths discussed with reference to Figure 13. However, the Seat NAU **465** also includes VLRU state machine objects **510b** comprising an HSDLInterface VLRU **650**, a SeatInterface VLRU **651**, and a SeatBroadcast VLRU **652**.

The HSDLInterface VLRU **650** comprises a ProcessFileChanges() **650a**, ProcessDownloads() **650b**, and a RefreshThread() **650c**. The SeatInterface VLRU **651** comprises a Crank() **651a**, a SessionQueueLeft **651b**, and a SessionQueueRight **651c**. The SeatBroadcast VLRU **652** comprises a PendingSessionMonitor() **652a** and a WheelStatusMonitor() **652b**.

SEAT.EXE contains the Seat NAU program **465**. This program includes the following primary components:

NAUMAIN.CPP	The <i>Main()</i> Program
HSDLDSPT.CPP	The High Speed Download NAU Dispatcher
STDSPTCH.CPP	The Seat NAU Dispatcher
STNTRFCE.CPP	The Seat VLRU Class
SESSION.CPP	The Service Session Class
STBRDCST.CPP	The Seat Broadcast VLRU Class
HSDLNTRF.CPP	The HSDL VLRU Class
DWNLDFLN.CPP	For HSDL, the DownLoadFileInfo Class
FILEMAP.CPP	For HSDL, The FileMap Class

A VLRU Session is characterized by the *NAU::Session()* threads, one for each VLRU that may be active concurrently. A Service Session is characterized by the Session class that controls a stream of communications between a single seat and a Service (such as a Sales Service). This stream may include several messages back and forth before a Service Session is complete.

The Main Program is a standard NAU starter. *Main()* registers this program with the System Monitor **454** using the *SysMonInterfaceClass::Register()* routine. For test purposes only, if any parameter is passed to this program, it bypasses this step.

The Main Program creates a `HSDLDispatch` object to open up communications between the message processor **452** and the transaction dispatcher **473** and create the High Speed Download VLRU **650**. Then the Main Program creates the `SeatDispatch` object to create all the `SeatInterface` VLRUs **651** and the `SeatBroadcaster` VLRU **652**. The Main
5 Program launches 14 `Session()` threads **507** that are shared by all the VLRUs. A typical number of Sessions is 14 including 10 seats' Service Sessions, plus HSDL, plus Broadcast, plus two more to control seats that are waiting for a Service Session to free up (pending seats). The Main Program calls `NAUDispatch::startItUp()` **518** to initialize the VLRUs with a `SubProcessStart` command.

10 The `HSDLDispatch` file defines a `MPRightHook()` function to be called within the `NAUDispatch::MPRight()` thread prior to processing the incoming message from the message processor **452**. It uses this hook function to intercept the High Speed Download Request messages and route them to the HSDL VLRU **650** instead of to the Seat VLRU **651**, where its LRU address would normally send it. This reduces traffic to
15 the 10 `Sessions()` **507** reserved for the seats.

Finally, `Main()` sleeps forever until interrupted. It does not call `shutItDown()` to close all the VLRUs down and exit gracefully. Instead, it simply deletes the NAU Dispatch and dies.

The `SeatInterface` VLRU **651** is responsible for processing requests from the seats **123**
20 such as ordering a movie or a game. It routes these requests to the applicable Service via the Transaction Dispatcher **473**. One VLRU for each seat **123** in the system exists; however, only 10 VLRUs at a time may actively be engaged in a communication session between seat 123 and Service.

Each `SeatInterface` VLRU **651** has a `Session` object that it uses as its state machine.
25 Its `StartItUp()` function loops continuously as long as it is actively engaged within a session (that is, the session state is not idle), looking for one of the following events: Data from the message processor **452**, Data from the transaction dispatcher **473**, an NAU TIMEOUT, an NAU RUN IMMEDIATE, a NAU AUX, a `SessionQueue.Right` or `SessionQueue.Left` events. It passes any TD messages on to the seat display unit **122**
30 provided they do not affect the State of the VLRU. `StartItUp()` then calls `Session::Crank()` to process one event from the `SessionQueue.Right` queue. Once it has been processed, `StartItUp()` forwards any message that may be waiting in `SessionQueue.Left` (sending it

out to the message processor **452** or transaction dispatcher **473**), then determines what to do with the input event that got it going (from the message processor **452**, transaction dispatcher **473**, Timeout etc.). Usually, it simply puts it in SessionQueue.Right, which re-triggers *StartItUp()* to again call *Session::Crank()* until all
5 events and/or messages are processed. Once the processing is complete for this VLRU's Session, *StartItUp()* exits, to give the session thread to another seat. It uses *MessageToEvent()* to convert a Seat_Message into its corresponding Event value, and it uses *EventToMessage()* to develop an appropriate outgoing message based on the current VLRU Event.

10 *StartItUp()* also processes the following control messages:

IFE Message	Action
StartStatisticsCapture	Sent by the SeatBroadcast thread when WeightOnWheels is detected, uses <i>timedCallback::queue()</i> to set a timer to a random value to cause the Statistics request to go to the seat after the timeout. This prevents all seats from processing the request at the same time (as it would from a broadcast), to keep the traffic on the network less congested.
SubProcessReinit	Re-Initializes tables via <i>Initialize()</i> .
SubProcessStart	Starts the State Machine for this VLRU, putting it into the <u>Start</u> state.
SubProcessStop	Exits.

At a minimum, a seat transaction requires sending a message to a service **477** and receiving an answer back. However, if it is a complex transaction (for example, a multiple-product merchandise order), several messages are routed before the entire
15 transaction is complete. Because 500 seats **123** may be all communicating at the same time, the basic design of communications flow from the seat **123** to the services **477** and back can get highly fragmented when these complex transactions are involved. To minimize this fragmentation (and thus create the appearance of faster response at the seats), the Service Session protocol has been developed.

Supported by the Session class and the SDU interface, this protocol requires a seat **123** to open a session (or tap dibs) with the Seat NAU **465** before a transaction can take place. Only 10 Sessions **507** are supported simultaneously (controlled in the Session constructor by hSessionSemaphore), so if they are all busy, a Pending message is
5 returned to the seat **123** to tell it to wait, and the seat's ID is kept on the SeatInterface::PendingSeats queue. Once a seat has a Session **507** assigned to it, it can communicate freely with the Service **477** via the NAU **465** until it closes or releases the Session.

The following table illustrates a Sample Session Communication Flow.

Seat	Seat NAU	Sales Service
Session Control - OPEN>	<Session Status - Pending	
Session Control - SDU Pending>	<Session Status - Opened	
Transaction Command - Order>	Transaction Command - Order>	<Transaction Status - Ordered
	<Transaction Status - Paid	
Transaction Command - Order>	Transaction Command - Order>	<Transaction Status - Ordered
	<Transaction Status - Paid	
Session Control - Close>	<Session Status - Closed	

Each SeatInterface VLRU **651** has a Session class, called the_Session to support this which uses an EventStateTable that keeps track of the action to perform for any given Event and/or State. Each action is maintained as a separate function whose name begins "Ac" (e.g., *AcTerminateSelf()*). These Action functions are all static BOOL

5 functions that need the current Session and Event pointers passed to them to operate. They are called by the function *Crank()* **651a** after it looks them up in the EventStateTable.

The following state table, called "Action" in the software, shows the relationship between the States, Events, Actions and changed or new states, sorted by From-State. Using this table, one can see how a Seat's Session moves from one state to another, which events can trigger the change and what actions are performed to cause the change. In the software, the events are prefixed with "Ev" (such as "EvSelfBackOut"), actions with "Ac" (such as "AcBackOut") and states with "St" (such as "StBackOut"). These prefixes are omitted from the table below for easier reading.

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
BackOut	SelfBackOut	BackOut	BackOut
BackOut	ServiceBackedOut	BackOut	BackOut
BackOut	SelfBackOutDone	BackOutDone	Opened
CancelPending	ServiceCanceled	ServiceGeneralAction	Opened
CancelPending	SelfTimeOut	GeneralTimeOut	Terminating
Closed	SelfClosed	SessionNormal-Terminate	Terminated
Closed	SelfTimeOut	GeneralTimeOut	Terminating
CompleteUpdate-ByCommand	SDUGetNext-Transaction	SendTransaction-Update	Complete-UpdatePending
Complete-UpdatePending	SDUGetNext-Transaction	SendTransaction-Update	CompleteUpdate-Pending
Complete-UpdatePending	SelfUpdateDone	TransactionUpdate-Complete	Opened
Complete-UpdatePending	SelfTimeOut	GeneralTimeOut	Terminating
DeliveryPending	ServiceDelivered	ServiceGeneralAction	Opened
DeliveryPending	SelfTimeOut	GeneralTimeOut	Terminating
End	SelfTimeOut	GeneralTimeOut	Terminating
Foo	SDUPending	SessionNotAvailable	Paused

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
Incremental- Update- ByCommand	SDUGetNext- Transaction	SendTransaction- Update	Incremental- UpdatePending
Incremental- UpdatePending	SDUGetNext- Transaction	SendTransaction- Update	Incremental- UpdatePending
Incremental- UpdatePending	SelfUpdateDone	Transaction- UpdateComplete	Opened
Incremental- UpdatePending	SelfTimeOut	GeneralTimeOut	Terminating
Opened	SDUCancel	SDUGeneralAction	CancelPending
Opened	SDUClose	SessionClose	Closed
Opened	SDUDeliver	SDUGeneralAction	DeliveryPending
Opened	SDUOpen	DoNothing	Opened
Opened	SDUStatisticsData	Statistics	Opened
Opened	SDUSurveyData	Survey	Opened
Opened	SDUOrder	SDUOrder	OrderPending
Opened	SDURefund	SDUGeneralAction	RefundPending
Opened	SelfTimeOut	GeneralTimeOut	Terminating
Opened	SDUCompleteUpdate	DetermineUpdate- TypeNeeded	UpdateType- Pending
Opened	SDUIncremental- Update	DetermineUpdate- TypeNeeded	UpdateType- Pending
Opened	SDUUpdateRequest	DetermineUpdate- TypeNeeded	UpdateType- Pending
Ordered	SelfDeliverOnOrder	ServicePaid	Opened
Ordered	SDUPayment	SDUPayment	PaidPending
Ordered	SelfTimeOut	GeneralTimeOut	Terminating
OrderPending	ServiceOrdered	ServiceOrdered	Ordered

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
OrderPending	SelfTimeOut	GeneralTimeOut	Terminating
PaidPending	ServiceNotPaid- ForReason	ServiceNotPaid	BackOut
PaidPending	ServicePaid	ServicePaid	Opened
PaidPending	SelfTimeOut	GeneralTimeOut	Terminating
Paused	SDUOpen	SessionOpenNow	Waiting
Pending	SelfSystem- NotAvailable	SystemNotAvailable	Closed
Pending	SelfSession- NotAvailable	SessionNotAvailable	Foo
Pending	SelfSession- Available	SessionAvailable	Opened
Pending	SDUOpen	SessionTryToOpen	Pending
Pending	SelfTimeOut	GeneralTimeOut	Terminating
RefundPending	ServiceRefunded	ServiceGeneralAction	Opened
RefundPending	SelfTimeOut	GeneralTimeOut	Terminating
SessionInit	SDUClose	SessionNormal- Terminate	Closed
SessionInit	SDUOpen	SessionTryToOpen	Pending
SessionInit	Terminate- Immediately	SessionInit	SessionInit
SessionInit	SDUTerminate	SessionAbnormal- Terminate	Terminating
SessionInit	SelfTimeOut	GeneralTimeOut	Terminating
SessionInit	SelfStatisticsNotify	SendUpdate- NotifyToSDU	UpdateNotify- AckPending
SessionInit	ServiceComplete- UpdateNotify	SendUpdate- NotifyToSDU	UpdateNotify- AckPending

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
SessionInit	ServiceInc- UpdateNotify	SendUpdate- NotifyToSDU	UpdateNotify- AckPending
SessionInit	ServiceIncUpdate- NotifyWithRevoke	SendUpdate- NotifyToSDU	UpdateNotify- WithRevoke- AckPending
Start	Start	SessionInit	SessionInit
Start	SelfTimeOut	GeneralTimeOut	Terminating
Terminated	SelfReinitialize	SessionInit	SessionInit
Terminated	SelfTimeOut	GeneralTimeOut	Terminating
Terminating	SelfTerminated	Terminated	Terminated
Terminating	SelfTimeOut	GeneralTimeOut	Terminating
TVOffAck- Pending	SelfTimeOut	UpdateNotifyTimeOut	DontChangeState
TVOffAck- Pending	SDUTVOffAck	ServiceUpdate- NotifyComplete	SessionInit
TVOffAck- Pending	SelfCancel- UpdateNotify	DoNothing	SessionInit
UpdateNotify- AckPending	SelfTimeOut	UpdateNotifyTimeOut	DontChangeState
UpdateNotify- AckPending	SDUUpdateNotify- AckFromSDU	ServiceUpdate- NotifyComplete	SessionInit
UpdateNotify- AckPending	SDUUpdateNotify- AckFromSI	ServiceUpdate- NotifyComplete	SessionInit
UpdateNotify- AckPending	SelfCancel- UpdateNotify	DoNothing	SessionInit
UpdateNotify- WithRevoke- AckPending	SelfTimeOut	UpdateNotifyTimeOut	DontChangeState
UpdateNotify- WithRevoke- AckPending	SDUUpdateNotify- AckFromSI	SendTVOff	TVOffAckPending

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
Update- TypePending	SelfCompleteType	SendUpdateType	CompleteUpdate- ByCommand
UpdateType- Pending	SelfIncrementalType	SendUpdateType	Incremental- UpdateBy- Command
Waiting	SelfSessionAvailable	SessionAvailable	Opened
Waiting	SelfSession- NotAvailable	SessionNotAvailable	Waiting

All possible From-State/Event Trigger combinations are not represented in the Action table. Many do-nothing or illogical combinations need to default. For that reason, the Action table is used to fill in a larger, more comprehensive table called the EventStateTable. This two-dimensioned table uses the values of From-State and Event Trigger as indexes, and defaults the illogical values to either do nothing or to terminate.

A typical session flow (with no errors) to place an order would start and end in the SessionInit state as shown below:

From-State (St...)	Event Trigger (Ev...)	Action Function (Ac...)	To-State (St...)
Start	Start	SessionInit	SessionInit
SessionInit	SDUOpen	SessionTryToOpen	Pending
Pending	SelfSessionAvail able	SessionAvailable	Opened
Opened	SDUOrder	SDUOrder	OrderPending
OrderPending	ServiceOrdered	ServiceOrdered	Ordered
Ordered	SDUPayment	SDUPayment	PaidPending
PaidPending	ServicePaid	ServicePaid	Opened
Opened	SDUClose	SessionClose	Closed
Closed	SelfClosed	SessionNormalTerminate	Terminated
Terminating	SelfTerminated	Terminated	Terminated
Terminated	SelfReinitialize	SessionInit	SessionInit

Each Session **507** has a SessionQueue queue pair that is used to store the Events to perform for this Session's State Machine. The SessionQueue's Right queue **651c** stores incoming message/event pointers for *Session::Crank()* **651a** to process, while its Left queue **651b** stores outgoing event/message pointers for *SeatInterface::StartUp()* **518** to forward to either the message processor **452** or the transaction dispatcher **473** or timeouts as appropriate.

The SeatBroadcast VLRU **652** is a child of the SeatInterface class so that it can help monitor the seat communication traffic for the other SeatInterface objects. It is responsible for sending messages to more than one seat or more than one SeatInterface VLRU **652**. Only one message is actually sent in a broadcast to the seats with the destination set to "AllSeats". It uses the CalledTimeOut utilities to create a TimeOut Thread called *SeatBroadcastTimeout()* to force periodic, unsolicited broadcasts. It also launches the *PendingSessionMonitor()* **652a** and *WheelStatusMonitor()* threads **652b**.

It's *StartItUp()* **518** function loops forever, retaining possession of one of the *Session()* **507** threads. It continuously monitors messages and processes the following events or messages:

Message or Event	Action
CPMS Message	Tells all SDU-SI boards the current status of the HSDL Queue. Retriggeres the <i>HSDLInterface::ProcessDownLoadQ()</i> event.
MovieTimes Message	Tells the MP what the Movie Run Times are
NAU_TIMEOUT Event	Triggers every tenth of a second using the <i>timedCallback::queue()</i> function. When received, this broadcasts a "Session Complete" message to all seats if a Service Session has just completed, so they can retry communications, if needed.
ProcessReinit Message	Tells all VLRUs to "SubProcessReinit".
SeatTransfer Message	Uses <i>ProcessSeatTransfer()</i> to parse and forward this message to the two <i>SeatInterface</i> VLRUs that are involved in the transfer.
SubProcessStart Message	Tells all VLRUs to "SubProcessReinit".
SubProcessStop Message	Stops the Timeout thread and ends the program.
Weight_On_Wheels Event	Tells all VLRUs to Start Statistics Capture, now that the aircraft has landed (ending flight).

5 The *PendingSessionMonitor()* **652a** has nothing to do with Seat Broadcasting: It is a supplement to the normal *SeatInterface* processing. This monitor continuously waits for a Seat **123** to be put onto the static *SeatInterface::PendingSeats* queue (by any of the other *SeatInterface::StartItUp()* threads), and then waits until one of the Seat Sessions is available for processing. Then it puts this Seat ID onto the *AuxFifo* queue to be taken by the next available *Session()* thread **507**.

10 The *WheelStatusMonitor()* **652b** is a High Priority thread that waits for a signal from the PESC-A VLRU in the Backbone NAU, which pulses the Weight On Wheels or the Weight Off Wheels events when their status changes. This monitor forwards this event information to the *StartItUp()* **518** to process when it next loops.

The HSDLInterface VLRU **650** is a standard NAU child dedicated to servicing all download requests for games or application programs by the seats. Its constructor connects to the driver, "HSDL1" to transmit data to the seats via the Digitized Video Multiplexer system. The constructor also prefills a CRC Table used for deriving the
5 CRC values during downloads. It creates a Mutex to control access to the HSDL directory to ensure that the routines in COPYDNL.CPP and SDU_BLDR.CPP don't interfere with the download process by modifying the files in the download directory at the wrong time.

The *StartItUp()* **518** routine launches the following threads:

Thread	Function
<i>ProcessFileChanges()</i>	Reacts to changes in the NT Registry as well as changes in the Download Files Directory. It then calls <i>ProcessEntireDirectory()</i> to read the directory that contains the files that can be downloaded, creating a <i>DownloadFileInfo</i> object for each, and placing all download files in the ConvertQ for <i>RefreshThread()</i> to handle. This thread places all programs and database files ahead of games in the ConvertQ so that the Seats can be ready for use as soon as possible.
<i>RefreshThread()</i>	Looks for files in the ConvertQ queue to prepare for later downloading. Calls <i>DownloadFileInfo::Refresh()</i> to block the data and add checksums and CRCs for Seat verification. It also saves the identity of the requesting seat for communication during the actual download.
<i>ProcessDownloads()</i>	This thread is launched at a low priority, so that the others can prepare all the files beforehand. It calls <i>ProcessDownloadQ()</i> to use <i>SeatInterface::GetDownloadInstruction()</i> to handle this file properly. Calls <i>DownloadFileInfo::Download()</i> for each file in the DownloadQ to actually send them to the output driver. During the download, it redirects message handling away from the seat's SEB and toward its SDU I/F board because the seat display unit 122a can't receive messages without its application running, which is true whenever it is receiving a download.

10 Then *StartItUp()* calls *ProcessIOQueues()* to continuously sample the message processor and transaction dispatcher input queues. It processes the following message processor messages:

IFE Message	Action
HighSpeedDownload	Puts the download request onto the DownLoadQ. It moves a request to the top of the queue if the request is for a program (high priority).
SubProcessStart	Simply recognizes this command, no further processing.
SubProcessStop	Flushes its MP and TD Input queues and tells the DestructFifo queue (one of the few VLRUs to use this) that it can be shut down.

The VCP NAU controls communications with the video players and other video sources. It maintains one VLRU for each video source, and constantly polls the players for their status. The VCP Network Addressable Unit program **462** function and data paths are shown in Figure 19. The structure of the VCP NAU **462** is substantially the same as
5 the Network Addressable Units function and data paths discussed with reference to Figure 13.

VCP.EXE contains the VCP NAU program. This program includes the following primary components:

VNUMAIN.CPP	The <i>Main()</i> Program
VCPDSPTCH.CPP	The NAU Dispatcher
VCPNTRFC.CPP	The VCP VLRU Interface Class
VCPSTSVL.CPP	The VCP Status VLRU Class

Main() issues a call to *GetLruInfo()* to read the database **493** for all the VCP names (e.g.,
10 "VCP01"). It then launches a VCPDispatch object to open up communications between the message processor **452** and the transaction dispatcher **473**. It calls *VCPDispatch::startItUp()* to initialize the VLRUs, one for each video cassette player **227** plus one for periodic statusing of all video cassette players **227**. It also launches the *Session()* threads **507**.

15 *Main()* then calls *ConsoleCmd()* to process all console characters that may be in the input buffer. If "S" is encountered, a STOP command is issued to VCP01. If "P" is encountered, a PLAY command is issued to VCP01. This is for testing purposes only.

Finally, *Main()* sleeps forever until interrupted. It calls *shutItDown()* to close all the VLRUs down and exit gracefully.

A VCP VLRU is created for each video cassette player **227** in the database **493** using the *VCPInterface* Class. This class is derived from the Generic NAU Class; however,
5 due to the communications protocol employed by the players, many of the generic functions are overcast or not used at all.

The *VCPInterface()* constructor creates two unique controllers: Static *hIOSemaphore* and *bHasSemaphore*. These are used to enforce single-threaded communications between a video cassette player **227** and the transaction dispatcher **473**. Using these
10 controllers, only one VLRU can be processing communications at a time.

hIOSemaphore is a handle that acts as 'dibs': When this handle is owned by a thread, that thread can process communications. *bHasSemaphore* is a local flag that tells the thread whether it currently is the owner of the semaphore.

VCPInterface::StartItUp() is called immediately for each *Session()* to process a 'dummy' message from the message processor **452** for each of the video cassette players **227**.
15 This 'dummy' message was invoked at their creation to glue each video cassette player **227** to its own Session.

This function then loops forever to continuously process messages. The basic loop does the following:

20 If this session does not have dibs, it waits for input from the transaction dispatcher **473** and waits for the *hIOSemaphore*. Then it flushes all possible input from the message processor **452**, reads the transaction dispatcher message and transmits it to the message processor **452**. It retains ownership of the I/O handle, and loops again.

If this session already has dibs (from the previous paragraph), it waits for input from
25 the message processor **404**. Once received, it processes it and sends an acknowledgement back to the video cassette player **227** via the message processor **452**. It then releases dibs for use by the other VLRUs.

A single VLRU of class *VCPSts_VLRU* is created to periodically poll the players for their status. Two lists of information are used to organize this: *MessageMap*, that contains a
30 list of each video cassette player **227** and its network address; *PendingStatus*, that

contains a list of video cassette players **227** that have just completed a communications event. MessageMap is maintained via *AddVLRU()* as each VCP VLRU is created by the dispatcher. PendingStatus is maintained by *XmitResponse()* each time the VCP VLRU completes a communications event.

5 VCPSts_VLRU contains a timeout function that is invoked approximately 10 times per second. The *StartItUp()* **518** function is immediately invoked and tied permanently to a *Session()* **507** thread. It then loops forever waiting for both a timeout to occur and the hIOSemaphore to be available. Once both events have occurred, it examines the contents of the PendingStatus string list and prompts the topmost video cassette player
10 **227** on this list for its status. If none are on this list, it prompts the next video cassette player **227** in the MessageMap list. This is performed via *SendStatus()*. These status responses are formatted and forwarded to the Video Control Service via the transaction dispatcher **473**. The I/O semaphore is released and the process cycle repeats.

The Test Port NAU program **461** function and data paths is shown in Figure 20. The
15 Test Port NAU **461** controls communications to the serial test port for BIT/BITE and MAINT system access. The structure of the Test Port NAU **461** is substantially the same as the Network Addressable Units function and data paths discussed with reference to Figure 13. However, the Test Port NAU **461** includes NAU VLRU state machine objects **510d** comprising a LoopbackThread() **660**, a EthernetThread() **661**, a
20 VCPStatusThread() **662**, and a Loopback Timeout() **663** that are initiated by StartItUp() **518**.

The Test Port NAU program **461** has two exclusive behaviors: BIT test mode and BITE test mode. The Test Port NAU program **461** starts out in BIT mode, and upon receipt of a GO_BITE command (presumably from the PESC-A **224a**), it attempts to switch to
25 BITE mode. BITE test mode is only available while the aircraft **111** is on the ground (as indicated by weight-on-wheels).

A BITE test is a three-pass 'loopback' in which data is sent to one of the I/O devices (the primary access terminal **225** to test the Ethernet network **228**, a PESC-A **224a** to test the ARCNET **216**, and VCP Status Service to test video cassette players **227**) and
30 an answer is expected back.

BIT tests are continuously occurring 'loopback' tests, however 3 consecutive failed communications are needed before a fault is recorded for any I/O device. A BIT test failure is only reported once per device per flight.

5 All BIT/BITE information is forwarded to a 'depository' or line replaceable unit that stores the information. In addition, BITE tests are initiated by an outside source or BITE Host. The default value for both of these is the primary PESC-A **224a**, however, a SET_DEPOSITORY command executes *SetBITEDepository()* to alter these values.

TESTPORT.EXE contains the Test Port NAU program **461**. The Test Port NAU program **461** includes the following primary components:

TESTPORT.CPP	The <i>Main()</i> Program
TSTPRTDS.CPP	The NAU Dispatcher
TSTPRTVL.CPP	The VLRU Class

10 The Main Program is a standard NAU starter. *Main()* registers the program with the System Monitor **412** using the *SysMonInterfaceClass::Register()* routine. *Main()* launches a TestPortDispatch object to open communication between the message processor **452** and the transaction dispatcher **473** and calls *TestPortDispatch::startItUp()* to initialize the VLRU. *Main()* launches two *Session()* threads **507**, although only one is
15 actually busy. *Main()* sends a SubProcessStart command to the TestPort VLRU which causes the first *Session()* thread to connect to the VLRU permanently. Finally, *Main()* sleeps forever until interrupted. *Main()* does not call *shutItDown()* to close all the VLRUs down and exit gracefully, it deletes the VLRU and dies.

20 A single Test Port VLRU is created using the TestPortVLRU Class. This class is derived from the Generic NAU Class, however it overcast the communications routines to support the TestPort_Message Class data routines. This constructor reads the database to develop a table of all Test Port LRUs, PESC LRUs, Process LRUs, ADB LRUs and ALAC LRUs. This table of LRU addresses is passed to the TestPort VLRU for reference in *GetSourceAddress()* and *SetBITEDepository()*.

25 *TestPortVlr::StartItUp()* is called immediately for the first *Session()* to process a 'dummy' message from message processor **452**. This 'dummy' message is invoked at their creation to glue the VLRU to a Session (a SubProcessStart message).

The VLRU then creates a set of 6 events used to communicate to 3 new threads:

Thread Name	Event 1	Event 2
ARCNET LoopbackThread	Message	Abort
EthernetThread	Message	Abort
VCPThread	Message	Abort

This function loops forever to continuously process messages to-and-from the message processor **452**. As a message is received, it is tested for validity, and then passed to the appropriate thread via a Message Event. Typically, the Message Events are used to
5 determine what to do next, however to end BITE mode testing, the Abort Event is triggered for each thread to stop BITE testing, making BIT testing possible again.

StartItUp() **518** uses the TimedCallback Utility Class to periodically launch *LoopbackTimeout()* which is responsible for issuing a command to the ARCNET network **216**, the primary access terminal **225** and the VCP Service to initiate a 'loopback' test,
10 in that it causes these devices to respond. Failure to respond within a specified timeframe causes the associated thread to log that device as FAILED. The initiation is accomplished by calling *PerformLoopback()*. It uses its own versions of *NAUPutMP()* and *NAUPutTD()* to communicate because it needs to use the TestPort_Message class instead of IFE_Message class routines to process the data.

15 When an event is received, the *LoopbackThread()* Thread process calls *ProcessLoopback()* to fully process the event. It tests ARCNET by communicating with the PESC-A 224a. If the PESC-A **224a** fails to respond within a given timeframe, it times out, causing a failure to be noted.

In order to efficiently load programs, data and video games in the seats **123**, the high-speed download driver **449** in Figure 10 provides the ability to convert this information
20 into a synchronous data link control (SDLC) data stream. This data stream is forwarded to the video modulator (VMOD) **212b** to broadcast to all seats **123** via the RF distribution system. Any seat **123** that requires the download can then tune to the download channel and retrieve the information. HSDL.SYS is the high speed down load
25 driver, written in C as a standard WINDOWS NT driver.

HSDL.SYS is the High Speed DownLoad driver, written in C as a standard WINDOWS NT driver, and includes the following files:

CONFIG.C Code for the initialization phase of the HSDL device driver.

DISPATCH.C Code for the function dispatcher.

DMA.C Code for input and output which is non-hardware specific.

HARDWARE.C Code for communicating with the Zilog 85230 processor on the HSDL card.

HSDLLIB.C Common code for HSDL Kernel mode device drivers.

INIT.C Code for an initialization phase of the HSDL device driver.

ISR.C Code for an Interrupt Service Routine for the HSDLBlaster device driver.

REGISTRY.C Common code for Sound Kernel mode device drivers for accessing the registry.

The HSDL device is a Zilog 85230 Enhanced Serial Communications Controller (ESCC), which is an industry-standard serial controller. HSDL is a Synchronous Data Link Control (SDLC) data stream running at 409.6 Kbps with 514-byte frames using FM0 (biphase space) data encoding. To move the data as quickly as possible, DMA transfers are employed.

The driver is registered as "\\HSDL1" and the following NT driver commands are supported: *CreateFile()*, *WriteFile()*, *DeviceIoControl()* and *CloseFile()*. The calling program writes to the device in 514-byte blocks. Currently, only *CreateFile()* and *WriteFile()* are used in the system **100**.

The application functions are divided into Services **477** that are responsible for carrying out the requests that come from the various devices (Seats **123**, PAT GUI **426**, etc.). Requests come in two forms: IFE_Messages from the transaction dispatcher **473** and CAPI calls from the GUI **426**. Service functions are the primary functions that interact with the database **493** during runtime. Each Service is connected to the transaction dispatcher **473** via its own Named Pipes, and as needed, it connects to the SQL Server **492** for database access.

SERVICE.EXE is organized into 4 basic components: Main, CAPI Calls **476**, Cabin Services **478-482**, **487-490** and Sales Services **483-486**. The Cabin Services **478-482**,

487-490 and Sales Services **483-486** are sets of Service classes whose objects each connect to the transaction dispatcher **473** via named pipes. They also each have a thread and subroutines to process all IFE messages received, and they all have sets of functions that are used by CAPI.CPP routines of the same name.

5 SERVICE.EXE is comprised of the following source files:

SRVCPRCS.CPP	The Main Program and Service Class
CAPI_S.C	The RPC Server Functions (See CAPI_C for its client companion functions)
CAPI.CPP	The actual CAPI Application Functions, called by CAPI_S.C, APIINT.CPP, and the Services.
CBNSRVCC.CPP	The CabinService Base Class
CRDTCRDP.CPP	The CreditCardProcessor Class
DTYFRSRV.CPP	The DutyFreeService Class
GMSRVCCCL.CPP	The GamesService Class
IFCNTRLS.CPP	The IFECtrlService Class
MVCYCLCL.CPP	The MovieCycle Class
MVSRVCCL.CPP	The MovieService Class
OFFLOADR.CPP	Database Offloader Functions
PCKGSRVC.CPP	The PackageService Class
PLYRCNFG.CPP	The PlayerConfiguration Class
SET.CPP	The Set Class (to support the _Set table)
SLSSRVCE.CPP	The SalesService Base Class
VCPMSSGE.CPP	The VCP_Message Class (see MESSAGES.LIB for details)
VDNNNCMN.CPP	The VideoAnnouncement Class
VDSRVCCCL.CPP	The VideoService Class

The Services NAU program **477** function and data paths are shown in Figure 21. Located in SRVCPRCS.CPP file, the *main()* program is responsible for launching each of the services. Once launched, they are each connected to the named pipes that communicate with the transaction dispatcher **473**.

- 5 The services include CAPI.CPP calls **701** which access CAPI_S.C. calls **702** that access CAPI_C.C programs **427**. The services include an IFECtrlService Class **703**, MovieCycle, VideoService and VideoAnnouncement Classes **704**, and SalesService, MovieService and GameService Classes **705**. The Services NAU program **477** includes a ServiceProcessor **706** that employs a GetContextHandle() **722** a
- 10 ContextHandleSessionQueue **723**, and a PutcontextHandle() **724**.

- The IFECtrlService Class **703** employs a CabinService::Get Message() thread **711** and a CabinService::Put Message() thread **712** that are coupled to the transaction dispatcher **473** by way of name pipes **474**. The CabinService::Get Message() thread **711** is routed to an InQueue **713** to a ProcessRequest() **715** which accesses IFE
- 15 Message Support Functions **718**. The ProcessRequest() **715** is coupled by way of an OutQueue **714** to a CabinService::Put Message() thread **712** which is coupled to the transaction dispatcher **473** by way of the name pipe **474**. A TimeSynchronizationThread() **716** is also routed through the OutQueue **714** and CabinService::Put Message() thread **712**. CAPI Support functions **717** are routed to the
- 20 CAPI.CPP calls **701** and to the SQL server **492**. The IFE Message Support Functions **718** access the SQL server **492**.

- The MovieCycle, VideoService and VideoAnnouncement Classes **704** employs a CabinService::Get Message() thread **711** and a CabinService::Put Message() thread **712** that are coupled to the transaction dispatcher **473** by way of name pipes **474**. The
- 25 CabinService::Get Message() thread **711** is routed to an InQueue **713** to a ProcessRequest() **715** which accesses IFE Message Support Functions **718**. The ProcessRequest() **715** is coupled by way of an OutQueue **714** to a CabinService::Put Message() thread **712** which is coupled to the transaction dispatcher **473** by way of the name pipe. CAPI Support functions **717** are routed to the CAPI.CPP calls **701** and to
- 30 the SQL server **492**. The IFE Message Support Functions **718** access the SQL server **492**.

The SalesService, MovieService and GameService Classes **705** employs GetMessage() **719** and PutMessage() threads **720** that interface to the transaction dispatcher **473** by way of name pipes **474**. The GetMessage() thread **719** is routed by way of an InQueue **713** to a ProcessRequest() **715** which accesses IFE Message Support Functions **718**.

- 5 ProcessRequest() **715** are routed by way of an OutQueue **714** to the Put Message() thread **720** which is coupled to the transaction dispatcher **473** by way of the name pipe **474**. CAPI Support functions **717** are routed to the CAPI.CPP calls **701** and to the SQL server **492**. The IFE Message Support Functions **718** access the SQL server **492**.

- 10 The *main()* program establishes a logon to the SQL Server **492** for database access using the standard SQL library commands in NTWDBLIB.LIB library. The *main()* program establishes 10 SQL Sessions, for example, with Context Handles to be used by the Services **477** to talk to the database **493**. The *main()* program establishes multiple handles to the database **493** for all the services and CAPI functions to use, then starts Pipe Threads and Process Threads for each service to run independently.

- 15 The *main()* program establishes itself as an RPC Server to communicate with the PAT GUI **426** and any other RPC Clients with the NT RPC utilities. Any program that has CAPI_C.C linked into it is an RPC Client in the system **100**. The *main()* program registers itself with the system monitor **454** for subsequent Shutdown support with *SystemMonitor::Register()*. The *main()* program issues a call to *ServiceProcessor::*
20 *StartActivityMailSlotThread()* to hook up to the primary access terminal NAU's GUI Monitor process, periodically sending it a message to let it know that *Service* is alive and well. Finally, the *main()* program waits forever listening to the RPC Server that it set up (via *RpcServerListen()*) until System Monitor's *Shutdown()* kills the process.

- 25 The ServiceProcessor class is used by *main()* and the Services **477** to control the access to the database **493** using the finite number of Context Handles available. This program has more Service SQL functions than Context Handles. It is conceivable that as many as 25 SQL requests may be present at one time (10 games, 10 movies, 1 CAPI, 1 IFE Control, 1 Movie Cycle, 1 Video Service and 1 Video Announcement). As a result, this code provides for optimum processing efficiency by queueing up the available
30 Context Handles and issuing them on a first-come first served basis.

ServiceProcessor Public Functions

Purpose

CONTEXTHANDLESTRUCT *
GetContextHandle()

Returns the handle to the next available context structure for access to the database.

int
GetContextHandleCount()

Returns the number of available Context Handles.

HANDLE
GetContextHandleSemaphore()

Returns the semaphore for the context handle Queue.

DWORD
GetLastError()
PCONTEXT_HANDLE_TYPE phContext)

Retrieves the error code associated with the specified context handle (phContext) that was most recently set by the *SetLastError()* member function.

void
PutContextDB()
int dContextLocation,
DBPROCESS*pDBProc)

Adds the DPROCESS handle to the context handle structure.

void
PutContextHandle()
CONTEXTHANDLESTRUCT*
pContextHandle)

Replaces the context structure into the context structure queue. Service Classes use this one.

void
PutContextHandle()
int dContextLocation)

Adds the context structure to the context structure queue. The *main()* program uses this one to initialize the queue.

void
SetLastError()
PCONTEXT_HANDLE_TYPE phContext,
DWORD dwErrorCode)

Associates the error code in dwErrorCord with the context handle pointer (phContext) storing them in the LastErrorMap structure. Values are retrieved from the structure via the *GetLastError()* member. This makes the errors available to all RPC Clients outside the Services.

bool
StartActivityMailSlotThread()

Starts the Mail Slot Thread used for transmitting an "I'm alive" signal to the PAT NAU GuiMonitor.
Returns FALSE if fails to start the thread.

Based on the DBAccess class, the Service class is a template for all the Services **477** to follow for proper operation. As a result, all its functions are virtual, and are defined in its children classes.

Service Class Virtual Functions	Purpose
virtual bool <i>ConnectToTD()</i>	Abstract definition to interface supports Service-to-TD named pipe connections.
virtual void <i>GenerateReport</i> (ReportType nReport)	Abstract definition to define the interface to launch a report. (All of them are stubs for now, and not called by anyone.)
virtual void <i>GetMessage()</i>	Abstract definition to receive data into the Service.
virtual PolicyType <i>GetPolicy()</i>	Abstract definition to retrieve the access policy for the Service. (All of them are stubs for now, and not called by anyone.)
virtual bool <i>IsAvailable()</i>	Abstract definition that defines an interface to evaluate whether a Service is available and ready to process requests or commands. (All of them are stubs for now, and not called by anyone.)
virtual void <i>MakeAvailable</i> (SERVICESTATE ServiceAction)	Abstract definition that defines an interface to make a Service available. (All of them are stubs for now, and not called by anyone.)
virtual void <i>ProcessRequest()</i>	Abstract definition for an interface that handles IFE_Messages for the Service. In addition to specific messages designed for each Service, all <i>ProcessRequest()</i> functions should handle the SubProcessStart, SubProcessStop and SubProcessReinit messages to get themselves going and synchronized as needed by the rest of the system.
virtual void <i>PutMessage()</i>	Abstract definition to send data out of the Service to TD and beyond.

The Cabin Services **477** control all the functions of In-Flight Service except those in which individual passengers **117** are involved. Cabin Services **477** are divided into the following Services: IFE Control Service **703**, Movie Cycle Service, Video Service and the Video Announcement Service **704**. In addition to its overcast versions of the Service

5 class functions, CabinServiceClass includes:

CabinServiceClass Public Functions

Purpose

TIME

GetRemainingFlightTime

Retrieves the remaining flight time using the *CalcRemainingFlightTime* stored procedure.

(PCONTEXT_HANDLE_TYPE
phContext)

bool

RegisterPipe

Registers this named pipe with the Transaction Dispatcher to make I/O possible.

(HANDLE hPipeHandle)

bool

SetStatus

Transfers the data contained in pszData into the status message field identified by nStatusType.

(STATUS_TYPE nStatusType,
char *pszData)

bool

StartPipeThreads

Called by *main()* to get a pair of named pipes to TD for this Service.

(ServiceProcessor *pServiceProcessor)

bool

StartProcessThreads

Called by *main()* to get the child's *ProcessRequest()* loop going by invoking *ProcessRequestInterface()*.

(ServiceProcessor *pServiceProcessor)

static UINT

GetMessageThreadInterface

Shared by all the CabinServiceClass children, this launches the child's *GetMessage()* function to handle its input from TD.

(LPVOID lpParam)

static UINT

ProcessRequestInterface

Shared by all the CabinServiceClass children, this launches the local *ProcessRequest()* function that loops forever handling the messages that it receives.

(LPVOID lpParam)

static UINT

PutMessageThreadInterface

Shared by all the CabinServiceClass children, this launches the child's *PutMessage()* function to handle its output to TD.

(LPVOID lpParam)

void

Wait

(DWORD dwSeconds)

Initiates a delay for the number of seconds specified by the input parameter dwSeconds.

The IFESControlService **703** class is derived from the CabinService class and contains several additional sets of functions that are used sporadically throughout the flight including:

Function Set	Tables Used
IFE State Changes	Aircraft, Order_
Flight Duration Management	
Statistics	Member, PassengerMap, PassengerStatistics, Set_
Surveys	SurveyAnswer
Seat Transfers	
Database Backup	All Database Tables

5 CAPI support **717** includes the following public functions accessed by CAPI.CPP **701** calls (having the same name):

IFESControlService Class Public Functions	Purpose
bool <i>CommandSeat</i> (PCONTEXT_HANDLE_TYPE phContext, SEAT_COMMAND nCommand, PGENERIC_TEXT pszSeatName)	Formats an IFE Message as specified by nCommand and transmits the message to the seat specified by pszSeatName.
bool <i>SeatTransferInit</i> (PGENERIC_TEXT pszSeat1, PGENERIC_TEXT pszSeat2)	Due to a CAPI call, Formats and sends an IFE_Message to the Seat NAU, which is where the actual transfer takes place. The data in the message reflects the two seats that are to be transferred.
void <i>SendStatusMessage</i> (PCONTEXT_HANDLE_TYPE phContext)	Formats and transmits an unsolicited Status Window Message to the GUI.

IFEControlService Class Public Functions

Purpose

bool
SetIFESate

(PCONTEXT_HANDLE_TYPE
phContext,
IFESTATE IFESateValue)

Calls the local *SetState()* to update the system state information. IFE State is a term that describes whether the IFE System is IDLE, STARTED, PAUSED, and more. This allows CAPI to alter these states to either free up services or disable them as appropriate for the current runtime state of the system. For example, when the system is IDLE or PAUSED, movies cannot be viewed which affects the Movie Cycle Service as well as the Movie Rental Service.

void
SetRemainingFlightDuration

(PCONTEXT_HANDLE_TYPE
phContext)

Called to refresh the value contained in the *tmRemainingFlightDuration* which is defined statically in the CabinService class. This function is called periodically from the *IFEControlService::TimeSynchronizationThread()* thread to update the value as the flight progresses, and directly from the CAPI when a change to the flight duration occurs.

In addition to the CAPI support functions **717**, the IFE Message Support **718** also handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. In addition to the standard messages, this class handles the following messages: *Statistics*, *Survey*, *SeatFault*, *FlightInfoRequest* and *DatabaseBackup*.

IFE Message	Function Called	Purpose	Tables Affected
DatabaseBackup	<i>ProcessDatabaseBackup()</i>	Generates a backup of the entire CFS database to recover after a possible CFS hard disk failure.	All database tables

IFE Message	Function Called	Purpose	Tables Affected
FlightInfoRequest	<i>ProcessFlightInfo()</i>	Gathers flight information from the CFS database and uses the information to populate an IFE_Message. The IFE_Message is then returned to the requesting program	Aircraft FlightV
SeatFault	<i>ProcessSeatFault()</i>	Updates the database, clearing or setting a fault indication for the seat or range of seats in the IFE message	PassengerMap
Statistics	<i>ProcessStatistics()</i>	Stores statistical information from the seats to the database and prepares them for output to a text file. Statistics include information such as how many hours of which movie was viewed, which games were played and more.	Member Set_ PassengerMap PassengerStatistics
SubProcessStart	<i>InitService()</i>	Establish IFE State and tell it to all affected programs via IFE Messages. Calls <i>StartTimeSynchronizationThread()</i> to launch <i>TimeSynchronizationThread()</i>	Aircraft

IFE Message	Function Called	Purpose	Tables Affected
Survey	<i>ProcessSurvey()</i>	Stores the answers given by passengers to survey questions available through the IFE system. These answers are stored in the database, as well as prepared for output to a text file	Survey SurveyAnswer SurveyAnswerKey SurveyQuestion

The TimeSynchronizationThread() thread **716** in the IFEControlService class **703** is responsible for managing flight duration information, which changes all the time. It uses SetRemainingFlightDuration() to update values, and calls AutoEndRevenue() to send a Stop Revenue Unsolicited Message to the GUI **426** once there is no time for
5 further revenue purchases.

The PlayerConfiguration class supports any Service that uses video players, such as the MovieCycle, VideoAnnouncement and Video Services **704**. The PlayerConfiguration class contains all pertinent information necessary to describe information specific to a Movie Cycle or Video Announcement. The PlayerConfiguration class also contains the
10 methods needed to issue all appropriate messages to start a specific Movie Cycle or Video Announcement.

PlayerConfiguration Class Public Functions

Purpose

PlayerConfiguration

(Queue *pParentQueue,
CString csName,
CString csAddress,
TIME tmIntermission,
TIME tmStart)

Creates a PlayerConfiguration object of specified Name, Intermission Time and Start time. In addition, a reference to the parent object's queue is stored in order for this PlayerConfiguration object to communicate with the parent object.

PlayerConfiguration

(Queue *pParentQueue,
CString csName,
CString csAddress)

Same as above, except default values for Intermission Time and Start Time are assigned as Zero.

PlayerConfiguration Class Public Functions

Purpose

void AddPlayer

(CString csPlayerName,
BYTE bySegment,
BYTE byRepeat,
DWORD dwMediaId)

Adds the specified player to this Player Configuration. If the program to be played is a Video Segment, then a segment number is provided, otherwise a value of zero is passed in the bySegment argument. If the repeat flag is set TRUE then the associated player is placed into it's REPEAT state.

bool ChangeCabinAudioLevel

(BYTE byAudioLevel,
BYTE byZone)

Updates internal data structures for this PlayerConfiguration object with the audio level specified in the byAudioLevel argument.

void CommandCabinAudio

(bool bAudioOn)

Transmits the necessary messages to the Backbone NAU which command the PESC-V to make the necessary cabin audio connections for the zones associated with this Player Configuration object. If the input argument bAudioOn is TRUE, the connections are enabled, if bAudioOn is FALSE, the connections are disabled.

void CommandCabinVideo

(bool bVideoOn)

Sends messages to the PESC-V to activate or de-activate the Overhead Monitors and override the in-seat video displays associated with this Player Configuration object. A value of TRUE for the input argument bVideoOn causes cabin video connections to be enabled, a value of FALSE for bVideoOn causes cabin video connections to be disabled.

bool CommandPlayer

(CString csPlayerName,
PLAYERCOMMANDS nCommand,
PGENERIC_TEXT pszExtra)

Transmits the player command specified by nCommand to the player specified by csPlayerName. Any additional data needed for the command must be passed in pszExtra.

bool CommandPlayers

(PlayerCommands nPlayerCommand)

Issues the commands to start, stop or rewind the player.

bool CreateAssignmentMap

(PCONTEXT_HANDLE_TYPE
phContext)

Populates the static data structure AssignMap with a status record for each LRU of type VCP residing in the LRU table.

BYTE GetCabinAudioZoneMap()

Returns the Cabin Audio Zone BitMap.

PlayerConfiguration Class Public Functions

Purpose

BYTE <i>GetCabinVideoZoneMap()</i>	Returns the Cabin Video Zone BitMap.
CString <i>GetConfigAddress()</i>	Returns the Configuration Address.
PLAYERSTATE <i>GetConfigState()</i>	Returns the cumulative state of all players currently assigned in this PlayerConfiguration object.
PLAYERSTATE <i>GetConfigState()</i>	Returns the state of the Player's Configuration.
void <i>GetConfigStatus</i> (ULONG *ulCurrentViewing, long *tmElapsed, long *tmRemaining, long *tmNextShow)	Returns information pertinent to this PlayerConfiguration object. The information returned is: - Number of configurations started - Elapsed time current configuration has been playing - Remaining play time for current configuration - Number of minutes until the next Configuration starts.
ConfigState <i>GetCurrState()</i>	Returns the current configuration state.
TIME <i>GetCycleTime()</i>	Returns the sum of the Longest Program Time and the Intermission.
int <i>GetCycleTimes</i> (TIME tmFlightRemaining, CDWordArray *dwCycleTimeList)	Computes a list of start times for all movie cycles contained in this PlayerConfiguration object. Cycle time values are store in dwCycleTimeList and the number of elements added to the array is returned to the calling function.
long <i>GetLongestProgramTime()</i>	Returns the Longest Program duration in minutes.
CString <i>GetLongestProgramVcp()</i>	Returns the value of the Longest VCP Program name.
DWORD <i>GetMediaId</i> (CString csPlayerName)	Returns the MediaId associated with the Video Player specified in csPlayerName. A value of -1 is returned if an invalid player name is specified.
CString <i>GetName()</i>	Returns the configuration name.

PlayerConfiguration Class Public Functions

Purpose

int *GetPlayerList*

(CStringArray &csList)

Populates a CStringArray with a list of the VCP Player Names currently associated with this PlayerConfigurationObject.

WORD *GetPlayerStateCount*

(PLAYERSTATE nPlayerState)

Returns the number of players in this PlayerConfiguration object that are currently in the state specified by nPlayerState.

ConfigState *GetPrevState()*

Returns the previous configuration state.

BYTE *GetSeatVideoZoneMap()*

Returns the Seat Video Zone BitMap.

TIME *GetStartTime()*

Returns the Start Time.

bool *GetTimeoutFlag()*

Returns the value of the Timeout Flag.

PLAYERSTATE *GetVCPState*

(CString csVCPName)

Returns the state currently stored in the assignment map for the player specified by csVCPName.

bool *IsCabinAudioActive()*

Returns a value of TRUE to the calling function if cabin audio is being used by any of the currently active assignments. A value of FALSE is returned otherwise.

bool *IsLastViewing*

(TIME tmFlightRemaining)

Determines whether or not the cycle being played is the final cycle based on the remaining time in the flight. It returns a value of TRUE if the last cycle has started and returns a value of FALSE otherwise.

bool *IsRunning()*

Returns TRUE if the current state is IDLE.

bool *IsTransitionActive()*

Returns TRUE if Transition is marked as active.

bool *IsValidVCP*

(CString csVCPName)

Returns a value of TRUE to the calling function if the player name specified by the csVCPName argument is found in the Assignment map. Otherwise a value of FALSE is returned.

void *Purge()*

Removes references to all video player names and configuration data associated with this PlayerConfiguration Object.

PlayerConfiguration Class Public Functions

Purpose

void RecoverCycle

(IFE_Message *msgRecoveryInfo)

Extracts recovery information from the IFE_Message object referenced by msgRecoveryInfo, converts the data into Binary and uses the converted data to initialize timing information for this PlayerConfiguration object.

bool ReplacePlayer(
CString &csOld,
CString &csNew)

Removes the player identified by csOld from this PlayerConfiguration object and adds the player identified by csNew to this PlayerConfiguration object.

void ResetTransitionActive()

Sets Transition to InActive.

void SetAudioDistributionInfo

(BYTE byAudioMap,
BYTE byMapType,
CByteArray *pbyVolume)

Stores the Audio distribution information for this Player Configuration.

bool SetConfigState

(ConfigState nState)

Sets the state of this PlayerConfiguration object to the value specified by nState. Performs all initialization necessary to make the transition into the new state. Returns TRUE if the state was successfully entered, returns FALSE otherwise.

void SetIntermission

(TIME tmIntermission)

Sets the Intermission Duration for this Player Configuration.

void SetLongestProgram

(int nPlayTime,
CString csPlayerName)

Identifies a VCP Name and Program Duration as the longest program in this PlayerConfiguration.

void SetStartTime

(TIME tmStartTime)

Sets the player start time.

void SetTransitionActive()

Sets Transition to Active.

PlayerConfiguration Class Public Functions

Purpose

int SetVCPAssignment
(int nLockState)

Updates the pConfig entry in the PlayerMap data structure associated the player identified by csVCPName. If the value of nLockState is LOCK the pointer to this PlayerConfiguration object is written. If the value of nLockState is AVAILABLE and the player is currently assigned to this player configuration object, the pConfig field is set to NULL.
Returns the number of players which were successfully assigned.

bool SetVCPState
(CString csVCPName,
PLAYERSTATE nVCPState,
DWORD dwVCPTIME)

Updates the entry in the PlayerMap data structure associated the player identified by csVCPName with the value contained in the nVCPState argument.

void SetVideoDistributionInfo
(BYTE byRFChannel,
BYTE bySeatMap,
BYTE byOHMap,
BYTE byMapType)

Stores the video distribution information for this Player Configuration.

void UpdateConfigState
(VCP_Message *pMessage)

Updates the state of this PlayerConfiguration object based. The state may be changed based on the content of the input message or based on a timeout applied to the current state.

void UpdateConfigTimeout()

Sets the state of the bConfigTimeoutFlag variable TRUE if the elapsed time for the current state has been exceeded. Otherwise, the bConfigTimeoutFlag variable is set False.

void UpdateCycleStatus
(TIME tmStatusUpdateRate,
TIME tmRemainingCycleTime)

Used periodically to transmit the Movie Cycle Times (based on RemainingCycleTime) message to the Seat NAU. Also periodically transmits a RecoveryInfo message to the IFEControlService.

Throughout the In-Flight operation, one or more movies continuously play, all starting together as a set, providing maximum viewing possibilities for the passengers 117.

This is known as Movie Cycling. The Movie Cycle Service controls the synchronization of these cycles.

Derived from the CabinService class, MovieCycleClass is responsible for keeping track of the remaining time of the flight, as well as the longest movie duration. It starts a cycle, stops a cycle, pauses a cycle, and recovers a cycle. The following database tables are used to support the MovieCycle Class: Member, MovieCycle, Set_, VideoMedium, 5 VideoPlayer, VideoSegment, and VideoUse.

The following table shows those functions that are used by CAPI.CPP calls **701**:

MovieCycle Class Public Functions	Purpose
bool <i>AddPlayerToMovieCycle</i> (PCONTEXT_HANDLE_TYPE phContext, PGENERIC_TEXT MovieCycleName, PGENERIC_TEXT PlayerName)	Adds a player to a movie cycle.
bool <i>ChangeMovieCycleIntermissionTime</i> (PCONTEXT_HANDLE_TYPE phContext, PGENERIC_TEXT MovieCycleName, TIME Intermission)	Modifies the movie cycle intermission time.
bool <i>ChangeMovieCycleStartTime</i> (PCONTEXT_HANDLE_TYPE phContext, PGENERIC_TEXT MovieCycleName, TIME StartDelay)	Update the start delay time for the PlayerConfiguration object specified by MovieCycleName. Updates the start delay locally: The value is written to the database as part of the StartMovieCycle processing.
APIResult <i>GetFirstMovieCycleTime</i> (PCONTEXT_HANDLE_TYPE phContext, PGENERIC_TEXT pszMovieCycleName, TIME *tmMinUntilStart)	Calculates the number of minutes until each of the remaining movie cycles starts. Returns the first start time in tmMinUntilStart. The return value is APIOK if there are 2 or more entries in the list and APIEndOfList if there is only 1 entry in the list.
bool <i>GetMovieConfigurationState</i> (PCONTEXT_HANDLE_TYPE phContext, PGENERIC_TEXT pszMovieCycleName)	Returns TRUE if the movie cycle specified by pszMovieCycleName is running.

MovieCycle Class Public Functions

Purpose

bool

GetMovieCycleDuration

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT pszMovieCycleName,
TIME *tmDuration)

Returns the duration, in minutes, of the Movie Cycle specified by pszMovieCycleName. A return value of TRUE indicates that the specified movie cycle was found and the time is valid.

APIResult

GetNextMovieCycleTime

(PCONTEXT_HANDLE_TYPE phContext,
TIME *tmMinUntilStart)

After *GetFirstMovieCycleTime()* has been called to calculate movie cycle times and return the first one, this can be called iteratively to retrieve the remaining movie cycle start times.

Returns APIEndOfList for the last entry in the list.

Returns APIOK for all other entries.

bool

RemovePlayerFromMovieCycle

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT MovieCycleName,
PGENERIC_TEXT PlayerName)

Removes the PlayerName player from the movie cycle MovieCycleName.

bool

ReplaceMovieCyclePlayer

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT pszMovieCycleName,
PGENERIC_TEXT pszPlayerToRemove,
PGENERIC_TEXT pszPlayerToAdd)

Swaps players (usually because of a hardware failure, and movies must be moved to new devices).

bool

SetMovieCycleUpdateRate

(PCONTEXT_HANDLE_TYPE phContext,
long lSeconds)

Sets the movie cycle update rate. The movie cycle update rate is the rate at which the system transmits movie cycle update information to the seats in seconds.

bool

StartMovieCycle

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT MovieCycleName,
TIME tmStartTime)

Starts the specified MovieCycleName at the given tmStartTime.

MovieCycle Class Public Functions

Purpose

bool
StopMovieCycle

Stops the specified Movie Cycle.

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT MovieCycleName)

void
UpdateSystemState

Notifies MovieCycleService that a change to the system state has occurred. The Service retrieves the system state from the database and updates the state of the active cycle(s) accordingly.

(PCONTEXT_HANDLE_TYPE phContext)

IFE Message Support **718** handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. In addition to the standard IFE messages, this class handles the following messages: *MovieTimes* and *MovieCycle*.

IFE Message	Function Called	Purpose
MovieCycle	<i>StopMovieCycle()</i> or <i>StartMovieCycle()</i>	Starts or Stops the movie cycle as needed.
MovieTimes	<i>UpdateMovieTimes()</i>	Updates the duration of the movies that are playing or scheduled to play.
SubProcessStart	<i>InitService()</i>	Creates a PlayerConfiguration object, determines what the players are doing using <i>UpdateSystemState()</i>

5 Flight Attendants often need the ability to view and listen to videos to verify quality and accuracy (for example, to determine if the expected movie is installed in the proper player **227**). The Video Service functions support this capability. Derived from the CabinService class, the VideoServiceClass is responsible for connecting the GUI **426** to the individual players **227** for preview and overhead control. The following database tables are affected by the Video Service Class: VideoMedium, VideoPlayer, and

10 VideoUse.

The following table shows those functions that are used by CAPI.CPP calls **701**:

**VideoServiceClass Public
Function**

Purpose

PLAYERSTATE
CommandPlayer

Uses PlayerConfiguration class functions to tell VCP pszPlayerName to perform nCommand (e.g., start, stop, play etc).

(PGENERIC_TEXT pszPlayerName,
PLAYERCOMMANDS nCommand,
PGENERIC_TEXT pszExtra)

void
GetOverhead

Returns the state and channel # of the currently selected Overhead Video source.

(OVERHEADSTATETYPE
*pOHState,
long *pChannel)

PLAYERSTATE
GetPlayerState

Uses *CommandPlayer()* to prompt the VCP to supply its current state.
Returns this state to caller.

(PGENERIC_TEXT pszPlayerName)

long
GetRemainingPlayerTime

Uses *CommandPlayer()* to prompt the VCP to supply its remaining play time.
Currently, this always returns ZERO.

(PGENERIC_TEXT pszPlayerName)

bool
SetAnnouncementAudioLevel

Sets the Cabin Audio volume level.
A value of -1 for dwZone specifies that PA volume for all zones is to be set to the specified audio level. If Persist is set TRUE, this updates the database as well, making this a permanent setting.

(PCONTEXT_HANDLE_TYPE
phContext,
long lAudioLevel,
DWORD dwZone,
bool Persist)

void
SetOverhead

Transmits a message to the PESC-V via the Backbone NAU to identify which channel represents the overhead video source. All parameters are Input Parameters.

(OVERHEADSTATETYPE OHState,
long Channel,
PGENERIC_TEXT pszPlayerName)

bool
SetPlayerSegment

Tells the VCP NAU to set the given pszPlayerName VCP to the selected lSegment. Returns FALSE if Segment value is invalid (> 0xff).

(PGENERIC_TEXT pszPlayerName,
long lSegment)

VideoServiceClass Public Function

Purpose

void
UpdateSystemState

Notifies this Service that a change to the system state has occurred.

(PCONTEXT_HANDLE_TYPE
phContext)

IFE Message Support **718** handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. In addition to the standard IFE messages, this class handles the following messages: *FailedPlayer*, *VCPStatus*, and *VideoControl*..

IFE Message	Function Called	Purpose
FailedPlayer	<i>ProcessFailedPlayer()</i>	Returns to the caller the number of players and which ones are flagged as failed.
SubProcessStart	<i>InitService()</i>	Creates a PlayerConfiguration object and initialize its variables.
VCPStatus	<i>ProcessVCPStatus()</i>	Updates the VCPState (via <i>PlayerConfiguration::SetVCPState()</i>), updates the database and tell the MovieCycle Service of the changed status via an IFE_Message.
VideoControl	<i>ProcessVideoControl()</i>	Updates the named player's status as given in the message, and outputs it to the Status Window.

The VideoAnnouncementService class is derived from the CabinService class and
5 contains several additional sets of functions that are used sporadically throughout the flight to support the playing of video clips, such as a safety video that must be broadcast to all passengers **117** at specific times during the flight. It provides the following functionality: creates a message for cabin configuration (cabin audio/video), works with MovieCycleService to pause the movie cycle, starts an announcement tape,
10 and talks to PESC-V **224b** to control PA. The database tables affected by the VideoAnnouncementService Class are: Aircraft, PA_Volume, VA_Distribution, VideoMedium, and VideoSegment.

The following table shows those functions that are used by CAPI.CPP calls **701**:

VideoAnnouncementService Public Functions

Purpose

APIRESULT

GetFirstVideoAnnouncementPlayList

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT
pszVideoAnnouncementName,
PGENERIC_TEXT pszPlayerName,
VIDEOANNOUNCEMENTSTATUSTYPE
*nState)

APIRESULT

GetNextVideoAnnouncementPlayList

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT
pszVideoAnnouncementName,
PGENERIC_TEXT pszPlayerName,
VIDEOANNOUNCEMENTSTATUSTYPE
*nState)

bool

ReplaceVideoAnnouncementPlayer

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT pszAnnouncementName,
PGENERIC_TEXT pszReplacementPlayer)

bool

ResumeVideoAnnouncement

(PCONTEXT_HANDLE_TYPE phContext)

Starts the PlayerConfiguration
Object associated with the next
Video Announcement to be played.

bool

StartVideoAnnouncement

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT pszAnnouncementName)

Starts the specified video
announcement.

bool

StopVideoAnnouncement

(PCONTEXT_HANDLE_TYPE phContext,
PGENERIC_TEXT pszAnnouncementName)

Stops the specified video
announcement.

void

UpdateSystemState

(PCONTEXT_HANDLE_TYPE phContext)

Notifies this Service that a change
to the system state has occurred.

In addition to the CAPI support functions **717**, IFE Message Support **718** also handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. In addition to the standard IFE messages, this class handles the following messages:

IFE Message	Function Called	Purpose
Ack or Nak	<i>SetNextState()</i>	Sets the next state for the video announcement associated with the Player Configuration Object <i>pPlayerConfig</i> .
PlayNextVA	<i>PlayNextAnnouncement()</i>	First, determines if the next announcement in the Video Announcement Play list requires installation of a new tape (i.e., Media ID). If so, then an Unsolicited message is transmitted to the GUI and the video announcement cycle is suspended. Once paused, the cycle must be restarted via either <i>StartVideoAnnouncement()</i> or <i>ResumeVideoAnnouncement()</i> .
SubProcessStart	<i>InitService()</i>	Performs the necessary Inits to get this Service going, including: <i>SetAudioDistributionInfo()</i> <i>SetVideoDistributionInfo()</i> <i>SetPlayerInfo()</i>

5 Sales Services control all the functions of In-Flight Service in which goods and entertainment are made available to passengers **117**. Sales Services **482-486** are divided into the following Services: GamesService **482**, MovieSaleService **483**, CatalogService **484**, DutyFreeService **486**, and DrinkService **485**.

10 The design structure of the Sales Service classes are similar to the Cabin Service classes, except that sales services **482-486** launch many more *ProcessRequest()* threads **715** to be able to service as many passengers **117** as possible. This is not necessary for the Cabin Services because they do not service individual passengers **117**; they service the system as a whole.

15 In addition to its overcast versions of the Service class virtual functions, SalesService Class includes its own virtual definitions within its children classes. This keeps the CAPI consistent in its calls:

SalesService Virtual Function	Purpose
virtual bool <i>CancelOrder</i> (ID OrderID)	Abstract to cancel an open order.
virtual ID <i>CreateOrder</i> (unsigned char *ProductCode, long Quantity, LRU_NAME Seat, unsigned char *EmployeeNumber, long lProductMap, MONEY AmountDue)	Abstract to Create an order.
virtual bool <i>DeliverOrder</i> (ID OrderID, GENERIC_TEXT EmployeeNumber)	Abstract to schedule an Order for Delivery.
virtual bool <i>PayForOrder</i> (ID OrderID, MONEY AmountCash, MONEY AmountCredit, GENERIC_TEXT CurrencyCode, GENERIC_TEXT EmployeeNumber, GENERIC_TEXT AccountNumber, GENERIC_TEXT ExpirationDate, GENERIC_TEXT CardName, CREDITCARDS CardType)	Abstract to record the payment for an order.
virtual bool <i>RefundOrder</i> (ID OrderID, GENERIC_TEXT EmployeeNumber, bool RevokeProduct)	Abstract to Refund an order.
virtual bool <i>StartPipeThreads()</i>	Abstract to start the I/O with Transaction Dispatcher.

SalesService Virtual Function	Purpose
virtual bool <i>StartUpProcessThreads()</i>	Abstract to start <i>ProcessRequest()</i> threads.

SalesService also provides several 'generic' sales functions, as shown in the sub-sections that follow.

The following functions are called by CAPI functions. In the Sales Services **482-486**, all CAPI calls cause an update message to be built and sent to the applicable seat **123**, so that it knows the status of its sales.

5

SalesServiceClass Public Functions	Purpose
bool <i>BackOrderOut</i> (CONTEXTHANDLESTRUCT *pContextHandle, ID OrderID)	Removes the any OrderID records from the database.
bool <i>CloseSalesStore</i> (ID StoreID)	Sets the status of the store to Closed.
SERVICESTATUS <i>IsValidCreditCard</i> (char *CardNumber, char *ExpirationDate, double CreditAmount, CONTEXTHANDLESTRUCT ContextHandle)	Verifies the type of card, expiration date and checksum according to the policy of this card type.
bool <i>OpenSalesStore</i> (ID StoreID)	Sets the status of the store to Open.

The following functions are provided to support these IFE Messages for all Sales:

IFE Message	SalesService Function	Purpose
BackOut	bool <i>BackOrderOut</i> (CONTEXTHANDLESTRUCT *pContextHandle, ID OrderID)	Removes the order from the database. This is usually due to an error during processing, rather than a customer request.

IFE Message	SalesService Function	Purpose
Cancel	bool <i>PrepareCancel</i> (CONTEXTHANDLESTRUCT *pContextHandle, Seat_Message *pSeatMessage)	Cancels an open order upon customer request.
CompleteUpdate	void <i>ProcessUpdateRequest</i> (Seat_Message *pMsg, IfeldType nProcessID, Queue *pTransmitQueue)	Collects revenue and movie or game lock information for a specified seat and returns the data to the SeatNAU.
Delivery	bool <i>PrepareDelivery</i> (CONTEXTHANDLESTRUCT *pContextHandle, Seat_Message *pSeatMessage)	Prepares an order for delivery.
IncrementalUpdate	void <i>ProcessUpdateRequest</i> ()	See CompleteUpdate message above.
Payment	bool <i>PreparePayment</i> (CONTEXTHANDLESTRUCT *pContextHandle, Seat_Message *pSeatMessage, ID *OrderID)	Applies the provided payment information to the specified order.
Refund	bool <i>PrepareRefund</i> (CONTEXTHANDLESTRUCT *pContextHandle, Seat_Message *pSeatMessage)	Processes a refund request to return payment(s) to a customer and update inventory (if needed).

Movie Viewing is a highly variable feature of the system. At the discretion of the airline, and subject to change from time to time, different video offerings are free to certain classes of passengers **117**, while others are chargeable. The Movies Sales Service **483** controls this feature. The database tables affected by the VideoAnnouncementService Class are: Policy, Price, VideoMedium, VideoSegment, and VideoUse.

Derived from SalesService class, the MovieServiceClass provides the functions needed to process the sales of movies onboard. Like CabinService class, it provides its own *ProcessRequest()*, *GetMessage()*, *PutMessage()*, etc. functions.

The following overcast functions are called by their corresponding CAPI calls **701**:
CancelOrder(), *CreateOrder()*, *DeliverOrder()*, *PayForOrder()*, and *RefundOrder()*.

In addition to the CAPI support functions, IFE Message Support **718** also handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. Currently, all
5 of the supported messages are supported using inline code that includes functions from the generic SalesService class along with the following:

IFE Message	Function	Purpose
Order	<i>CreateOrder()</i>	See CAPI Support

Nintendo Video Games are available for passengers to enjoy. To play them, a request must be made and often a payment is required. The Games Rental Service **482** uses the database tables GameDetail, Policy, and Price.

10 Derived from SalesService class, the GameServiceClass provides the functions needed to process the sales of movies onboard. Like CabinService class, it provides its own *ProcessRequest()* **715**, *GetMessage()* **719**, *PutMessage()* **720**, etc. functions.

The following overcast functions are called by their corresponding CAPI calls:
CancelOrder(), *CreateOrder()*, *DeliverOrder()*, *PayForOrder()*, and *RefundOrder()*. See
15 SalesService class for details.

In addition to the CAPI support functions **717**, IFE Message Support **718** also handles incoming IFE Messages using its overcast *ProcessRequest()* thread **715**. Currently, all of the supported messages are supported using inline code that includes functions from the generic SalesService class along with the following:

IFE Message	Function	Purpose
Order	<i>CreateOrder()</i>	See CAPI Support

20 Package Entertainment is a hybrid of Games and Movies Sales and is maintained within the MoviesSales class. It involves a one-time purchase to all entertainment services onboard. The Package Entertainment Functions may be used to control this capability, but currently the SEAT NAU and CAPI.CPP calls **701** route Package products to either the Game Service or the Movie Service, based on the product code that is used.
25 The PackageDetail table is used to identify the components of a "Package".

Purchasing goods through an electronic catalog is an enhancement provided by the system **100**. All functions that control it are kept in the Catalog Sales Service **484**. The following tables support the feature: Address, Order_, and ShippingRate.

5 Ordering drinks through the In-Flight Entertainment system **100** is provided. All functions that control it are kept in the Drinks Sales Service **485**. The following table supports the feature: Product

10 Purchasing onboard duty-free goods through the In-Flight Entertainment system **100** is provided. All functions that control it are kept in the Duty Free Sales Service **486**. The following tables support the feature: Cart, CartInventory, Commitment, and InventoryLog.

All the application-level database functions are directly accessible via calls to the CAPI functions. These calls are available directly, or via the RPC server. Thus, any service as well as any RPC client can access the CAPI calls.

15 CAPI.CPP **701** contains the actual commands that interface to the database **493** and perform the application duties (such as CreateOrder(), GetOrder(), etc.). CAPI_S.C **702** is the RPC server whose functions are made available to RPC clients (via CAPI_C.C). The server functions use the CAPI.CPP **701** calls to perform application duties. They are used together to make up this set of routines. In addition, the PAT GUI **426** can also access CAPI.CPP via APIINT.CPP and CAPI_S.C in the RPCCLNT.DLL.

20 The cabin file server database **493** stores the following types of information. This information is utilized by both the cabin file server application and the PAT GUI **426** and is described in greater detail below.

25 The cabin file server database **493** stores other line replaceable units in the IFE system **100**, the products and services available to the passengers **117**, revenue due to the sales of products and services, system usage due to the flight attendants and passengers **117**, surveys offered to passengers **117**, the state of the cabin file server application, video announcements, and global attributes of the IFE system **100**.

30 The cabin file server database **493** provides storage for line replaceable unit information. This enables the cabin file server application to communicate with and/or control these other devices. Some line replaceable unit information is provided by the

two data files that are generated by the ACS tool. Line replaceable unit information is stored in the following tables: LRU, Member, PA_Volume, PassengerMap, Set_, and VideoPlayer.

- 5 All purchased goods and services, purchase summary information, complimentary service assignments, and movie lockout information is stored on a per passenger basis. This information may be swapped from one seat **123** to another seat to accommodate the occasion when a passenger **117** must be moved during a flight. Each passenger **117** is represented in a PassengerMap table by a single record. This record contains the following pertinent information:

Field Name	Purpose
<i>SeatNumber</i>	Passenger seat number
<i>PassengerID</i>	Passenger Identifier

- 10 When a passenger **117** changes seats, the *SeatNumber* fields of the two records involved are swapped. Thus, all the information associated with the passenger **117** is not with the seat **123**, but with their *PassengerID*.

- The viewing of any movie and/or the playing of any game can be locked out at any seat, usually at the request of a parent to prevent a child from seeing a certain movie or
15 excessive game play. Each passenger **117** is represented in the PassengerMap table by a single record. This record contains the following pertinent information:

Field Name	Purpose
<i>SeatNumber</i>	Passenger seat number
<i>MovieLockoutMap</i>	Movie lockout bit map
<i>GameLockoutMap</i>	Game lockout bit map

The *MovieLockoutMap* and *GameLockoutMap* fields are bit map fields whose bits correspond to individual movie and game titles, respectively. A movie or game is locked out when it's corresponding bit in this field is set to one.

- 20 Loss of communication with a seat display unit **122a** is also recorded in the PassengerMap table.

Field Name	Purpose
<i>SeatNumber</i>	Passenger seat number
<i>SeatCommSuccessCount</i>	# Successful communications
<i>SeatCommFailCount</i>	# Unsuccessful communications

At the beginning of each flight, the *SeatCommFailCount* and *SeatCommSuccessCount* fields for each seat are initialized to zero. The *SeatCommFailCount* field is incremented for each first-time-failure encountered for the corresponding seat **123** (i.e., increment if fail <= success). The *SeatCommSuccessCount* field is incremented for each first-time-
5 success encountered for the corresponding seat (i.e., increment if success < fail). These rules are enforced through triggers on these database fields. The seat **123** is considered bad if the *SeatCommSuccessCount* is less than the *SeatCommFailCount*.

The cabin file server database **493** provides storage for product and service information (e.g., movie titles, viewing times, movie audio languages, game titles, audio
10 entertainment titles, audio channels, etc.). This information is sent by the cabin file server application to the Seat Display Unit **122a** for each flight. This enables up-to-date information to be presented to the passengers **117** so they can know which products and services are available to them and at what cost on a per flight basis. Product and Service information is stored in the follow MovieCycle ing tables:
15 AudioDetail, Cart, CartInventory, GameDetail, IFE_Service, InventoryLog, MovieCycleDetail, PackageDetail, Price, Product, ProductEffectivity, Route, ShippingRate, Store, VideoMedium, VideoPlayer, VideoSegment, and VideoUse.

Video Game information is maintained in the GameDetail table, one record per *Title/EffectivityDate* combination:

Field Name	Purpose
<i>Title</i>	The Game Title that is displayed on the seat display unit 122a
<i>EffectivityDate</i>	The date on or after which this game information is effective.
<i>RouteType</i>	The flight route type during which this game is available.

<i>ProductCode</i>	Corresponds to a product code in the Price table for price lookups.
--------------------	---

Video Game information is maintained in the VideoMedium table, one record per video program, one record per *MediaTitle*:

Field Name	Purpose
<i>MediaTitle</i>	The Game Title that is displayed on the seat display unit 122
<i>ProductCode</i>	Corresponds to a product code in the Price table for price lookups.

5 The IFE system **100** can inhibit the selectability of these video programs based on the date stored in the *EffectivityDate* of the VideoSegment table. Movie titles are associated with a specific flight route through the *RouteType* field of the VideoUse table. Prices are controlled via these fields in the Price table, one per *ProductCode/RouteType* combination:

Field Name	Purpose
<i>ProductCode</i>	Corresponds to Game or Movie Products for sale
<i>RouteType</i>	The flight route type during which this price applies
<i>FreeMap</i>	Identifies which zones (identified in bitmap) offer this product free of charge
<i>Pricing1</i>	Pricing structure for zone 1 during this flight route
<i>Pricing2</i>	Pricing structure for zone 2 during this flight route
<i>Pricing3</i>	Pricing structure for zone 3 during this flight route
<i>Pricing4</i>	Pricing structure for zone 4 during this flight route

The database tables used in Movie Cycle are: Member, MovieCycle, Set_, Videomedium, VideoPlayer, VideoSegemnt, and VideoUse.

10 Video sources such as video cassette player **227** or video reproducers (VR) **227** are assigned to a movie cycle through the Member and Set_ tables. Each VCP or VR **227** is stored in the *Member* field of the Member table. Each movie cycle is stored in the

SetName field of the *Set_* table. The following movie cycle information is stored in the database.

A movie cycle type is a predefined grouping of video reproducers **227** and movie titles. Movie titles are assigned to video reproducers **227** through the *VideoMedium* and
5 *VideoUse* tables. The database **493** can store up to eight different movie cycle types. Information about each movie cycle type is stored in the *MovieCycle* table. A movie cycle can include from one to fifteen video reproducers **227** (i.e., one to fifteen records of the *Member* table can be associated with a single movie cycle in the *Set_* table).

The start time for a movie cycle is stored in the *RelativeStartTime* field of the *MovieCycle*
10 table. It is stored in minutes relative to the time since movie cycle initiation at the primary access terminal **225**. A between-cycle intermission time is stored in the *IntermissionLength* field of the *MovieCycle* table. It is stored in minutes and must exceed the time required to prepare the video reproducer **227** containing the longest playing tape for the next cycle (e.g., tape rewind).

15 The end time of a movie cycle is the time in which the final viewing of a particular movie cycle ends. The number of viewings that can be scheduled for each movie cycle depends upon the length of a single viewing of the movie cycle and the flight duration. The length of a single viewing of the specific movie cycle can be calculated by adding the *IntermissionLength* field of the *MovieCycle* table to the *SegmentRunTime* field of the
20 *VideoSegment* table for the movie with the longest run time in the specific movie cycle. The expected flight duration is stored in the *FlightDuration* field of the *Flight* table.

Information about the state of a particular Video Reproducer **227** is stored in the *State*
field of the *VideoPlayer* table. This information includes whether or not the video
reproducer **227** is operational, whether or not the video reproducer **227** contains a
25 tape, etc.

The number of minutes before the start of each cycle can be calculated using the *RelativeStartTime* field of the *MovieCycle* table, the calculated length of the single
viewing of the movie cycle, and the *IntermissionLength* field of the *MovieCycle* table. The
number of minutes before intermission for the current cycle is stored in the
30 *RemainingViewingTime* of the *MovieCycle* table.

The number of minutes until the next viewing of a specific movie cycle is stored in the *NextViewingTime* of the MovieCycle table. The number of minutes remaining on the current viewing of the specific movie cycle is stored in the *RemainingViewingTime* of the MovieCycle table. The number of minutes elapsed into the current viewing of the
5 specific movie cycle is stored in the *ElapsedViewingTime* of the MovieCycle table.

A predetermined set of movies and/or games can be assigned to an airline-defined package. Package information is stored in the PackageDetail table.

Audio programming (entertainment) can be distributed on a maximum of 83 mono audio channels, controlled by the AudioDetail table, one record per program. The title
10 of each audio program is stored in the *AudioTitle* field. The channel of each Audio program is stored in the *AudioChannel* field.

The VideoMedium table stores up to four different languages for a particular video tape (e.g., movies). These languages are displayed on the display screen **122** for passenger selection. The languages are stored in the *LanguageCode1*, *LanguageCode2*,
15 *LanguageCode3*, and *LanguageCode4* fields of the VideoMedium table. Each video tape must have one language designated as the default primary language (i.e., *LanguageCode1* must not be empty) but it can have up to three other languages. The relationship of the output configuration of the video players and available language configuration is stored in the VideoPlayer table.

20 Information about each video reproducer **227** is stored in the VideoPlayer table. In order to "preview" the output of a particular video player on the primary access terminal screen, both primary access terminal tuners (audio and video) must be tuned to the proper channels. Video channel information for each video reproducer **227** is stored in the *VideoRF_Channel* field. Audio time-slot information is stored in the various time
25 slot fields (i.e., *LeftTimeSlot1*, *RightTimeSlot1*, *LeftTimeSlot2*, etc.).

A video reproducer **227** can be reassigned for use during a video announcement. The *MediaType* field in the VideoMedium table distinguishes a video announcement from a movie. The VideoUse table tracks which movie or video announcement is assigned to which video reproducer **227**. When a video reproducer **227** is reassigned, the
30 *PlayerName* field in the VideoUse table is modified. The playing status of each video reproducer **227** is stored in the *State* field of the VideoPlayer table.

Overhead monitors **162** can be assigned to a video source (i.e., video player **227**) for movies. This information is stored in the *OverheadAudioMap* and *OverheadVideoMap* fields of the *MovieCycleDetail* table.

5 The cabin file server database **493** provides storage for revenue information (e.g., credit card data, cash collection data, etc.) concerning the sales of products (e.g., duty free) and services (e.g., movies and games). When a passenger **117** uses a credit card to pay for movies or games, this information must be stored in the database so that it can be transferred to the credit card company. Likewise, when a passenger **117** uses cash to pay for movies or games, this information must be stored in the database **493** so that
10 the IFE system **100** has a record of how much cash should be collected by the flight attendant.

Revenue information is stored in the following tables: Address, BadCreditCards, Commitment, CreditCard, Currency_, Exchange, Flight, Order_, OrderHistory, PassengerMap, PAT_History, Policy, Price, Product, ProductEffectivity, ShippingRate,
15 and ValidCardData.

The purpose of transaction processing is to maintain a record of monetary transactions for service and products. When a flight attendant is involved with an order placed by a passenger **117** (e.g., order refunded, order placed at the PAT, etc.), then the flight attendant ID is stored in the *FlightAttendant* field of the *Order_* table.

20 Information about each product and service is stored in the Product table. Information about each package of goods or services is stored in the PackageDetail table. The pricing information for each product, service, and package is stored in the Price table. Prices can be altered according to the policy stored in the *PolicyDescription* field of the Policy table. For example, the policy may specify different service price data for movies
25 and games offered in each seat class zone (e.g., first class) in the aircraft **111**.

Services and products may be paid by cash, credit card, or a combination of the two. Cash and credit card payments are respectively stored in the *CashTotal* and *CreditTotal* fields of the *Order_* table. Orders are comprised of sets of products or services of the same type. If the passenger **117** uses a credit card, the credit card information (e.g.,
30 passenger name, account number, etc.) is stored in the CreditCard table.

Cash transactions may be represented in up to 30 different currency types. Information about each currency type is stored in the *Currency_* table. Each aircraft **111** has associated with it a base currency that is stored in the *BaseCurrencyCode* field of the *Aircraft* table.

- 5 Passengers **117** may pay for products and services using any single card from the credit card types accepted by the airline. Information about each valid credit card type is stored in the *ValidCardData* table. The credit card payment made on a given order is stored in the *CreditTotal* field of the *Order_* table. This payment is recorded in the base currency type as specified in the *BaseCurrencyCode* field of the *Aircraft* table.
- 10 Credit card numbers are validated against the standard number format and range for that particular credit card type. This standard number format is stored in the *ValidationPattern* field of the *ValidCardData* table. Also, credit card transactions are validated against the credit limit specified by the passenger **117** for that particular credit card type. This credit limit is stored in the *CreditLimit* field of the *ValidCardData*
- 15 table. In addition, each credit card is compared against the credit card numbers in the *BadCreditCards* table. This table may contain up to 10,000 records, for example.

- All transactions (i.e., service orders, product orders) processed by the system are stored in the *Order_* table. The state of an order (open, paid, canceled, refunded) is stored in the *State* field of the *Order_* table. For refunded orders, a duplicate order record is
- 20 created with the *AmountDue* field, the *CashTotal* field, the *CreditTotal* field, and the *Quantity* field all set to negative amounts. Orders that are placed at the primary access terminal **225** also have a corresponding entry in the *PAT_History* table. A new record is generated for the *OrderHistory* table for each change to the *State* field or the *Delivered* field.

The following information is maintained for each order:

Table	Field	Description
PassengerMap	<i>SeatNumber</i>	seat number
Product	<i>ProductDescription</i>	service or product ordered
Order_	<i>Quantity</i>	quantity of service or product ordered
CreditCard	<i>all fields</i>	credit card information for credit card orders
Price	<i>UnitPrice</i>	unit cost of service or product ordered
Order_	<i>AmountDue</i>	total cost of service or product ordered

Prior to shutdown of the IFE system **100**, a message is displayed on the primary access terminal **225** if the database **493** contains any open transactions from the current flight. The number of open orders for the current flight is always displayed in the status window on the primary access terminal **225**. This is calculated by counting each order in the **Order_** table (for the current flight) whose associated *State* field is set to "Open".

A running tabulation of all expenses incurred for each passenger during the current flight can be displayed on the seat display unit **122a** or seat display **122**. Each order is associated with a specific passenger **117** via the *PassengerID* field of the **Order_** table. The total cost of each order is stored in the *AmountDue* field of the **Order_** table. Total expenses incurred for a particular passenger **117** is the sum of the total cost of each order placed by the specific passenger **117**.

The following subsections describe selected database interactions that occur when the corresponding functions in the SalesServiceClass classes are executed.

Upon cancellation of any cash passenger product and/or service order that has not been paid, the *State* field of the **Order_** table is changed from "Open" to "Cancelled". If the service (i.e., video game or movie) is revoked from the passenger **117**, then the *ProductRevoked* field in the **Order_** table is set to TRUE.

A list of orders can be generated for which cash collection is to be made in-flight. Information related to each order is as follows:

Table	Field	Description
PassengerMap	<i>SeatNumber</i>	seat number
Product	<i>ProductDescription</i>	product or service ordered
Order_	<i>AmountDue</i>	amount due

Orders can be listed by service type and/or by general service zone. The service type of an order (i.e., game, movie, package) is stored in the *ServiceType* field of the Product table. The general service zone of the passenger **117** that placed the order is stored in the *SetName* field of the Set_ table.

A list of orders can be generated for which delivery is to be made in-flight. Information related to each order is as indicated above. Orders can be listed by service type and/or by general service zone.

10 Complimentary service for movies, games, and/or entertainment packages may be offered to individual passengers or to the entire aircraft **111**. For individual passengers, an order is placed in the Order_ table for each passenger **117** receiving a service that is complimentary, the *PayCurrencyCode* field is set to "Free" and the *State* field is set to "Paid". The order is then associated with the record in the PassengerMap table where the *SeatNumber* corresponds to the specific passenger **117**.

To provide complimentary service for the entire aircraft **111**, all entertainment (movies, games, packages) must be complimentary. A single order is placed in the Order_ table: The *PayCurrencyCode* field is set to "Free" and the *State* field is set to "Paid". The order is then associated with the record in the PassengerMap table where the *SeatNumber* field is set to "Allseats". The *FreeServicesMode* field of the Aircraft table is set to TRUE.

The system **100** can support up to thirty forms of currency. Currency information is stored in the Currency_ table. Exchange rate information is stored in the Exchange table. Currency exchange rate calculations can be performed that support a display with up to four decimal places. The number of decimal places to display is stored in the *DisplayPrecision* field of the Currency_ table.

Each currency is associated with a Policy table entry to specify how to convert from one currency to another. For example, the policy for converting to US dollars might be to round to the nearest penny, or nearest whole dollar if the airline does not wish to deal with change. The policy actually points to the applicable stored procedure to perform this function.

The cabin file server database **493** provides storage for system usage by both the flight attendants and passengers **117**.

The cabin file server database **493** keeps track of each time the flight attendant logs on and off. Additionally, the flight attendants may also enter flight identification information (e.g., flight number, destination, etc.) which is stored in the cabin file server database **493**. Flight attendant activity is stored in the following tables: Access, Flight, and Personnel.

Each time a user (i.e., employee) logs in to the IFE system **100**, this login information is stored in the Access table. It is also added to the Personnel table (once for each user) if a predefined set of valid users does not already exist. If a predefined set of valid users is preloaded into the Personnel table, then each user that tries to login can be validated against this pre-defined set of valid users.

An access level for each user is stored in the *AccessLevel* field of the Personnel table. This access level can be used to direct the user's access throughout the system **100**, effectively controlling what they can see or do. For example, a Service Person should not have access to Revenue Modification functions.

When users are required to insert a magnetically encoded card during the logon process, the card is encoded with the user ID (*EmployeeNumber* field), pin number (*PIN* field), and grade level (*AccessLevel*). This information is stored in the Access table for each login. This information is also added to the Personnel table (once for each user) if a pre-defined set of valid users does not already exist. If a predefined set of valid users is preloaded into the Personnel table, then each user that tries to login can be validated against this predefined set of valid users.

In the case where the card read is not successful, the user must manually enter the user ID, pin number, and grade level. This information is stored in the Access table for each login. This information is also added to the Personnel table (once for each user) if

a predefined set of valid users does not already exist. If a predefined set of valid users is preloaded into the Personnel table, then each user that tries to login can be validated against this predefined set of valid users.

5 The cabin file server database **493** also logs system activity (i.e., passenger usage of the system **100** from the seat display unit standpoint). The database **493** stores how much time each seat spent on each movie, on each game, and on each audio selection. This allows the airline to see how passengers **117** are using the system **100**.

Passenger activity is stored in the following tables: PassengerStatistics.

The following passenger statistic information is stored in the database **493**:

Table(s)	Field(s)	Definition or Comment.
PassengerMap	<i>SeatNumber</i> <i>PassengerID</i>	Each passenger is associated with their seat number.
Member Set_	<i>Member</i> <i>SetName</i>	Each seat number is associated with one class (e.g., first class, coach, etc.). The seat number is stored in the <i>Member</i> field of the Member table. The class is stored in the <i>SetName</i> field of the Set_ table.
PassengerStatistics	<i>StatImage</i>	Time spent viewing movies by title: Each movie watched and length of time spent watching each movie is stored here as a Binary Large Object (BLOB) which can hold up to 2GBytes of data if disk space allows.
PassengerStatistics	<i>StatImage</i>	Time spent listening to entertainment audio by title: Each audio entertainment listened to and the length of time spent listening to each audio entertainment is additionally stored here (BLOB).
PassengerStatistics	<i>StatImage</i>	Time spent playing games by title: Each game played and length of time spent playing each game is additionally stored in the here (BLOB).

10 The cabin file server database **493** provides storage of passenger survey information. Passengers **117** at each seat **123** can elect to participate in the survey. The database **493** records each result (i.e., passenger's answer) to each survey taken so that this

information can be made available to the airline. Passenger survey information is stored in the following tables: Survey, SurveyAnswer, SurveyAnswerKey, and SurveyQuestion.

5 The results of each survey taken (or same survey taken multiple times) by each passenger are stored in the SurveyAnswer table. Survey results may be off-loaded using the Data Offload approach discussed above. The name of the survey is stored in the Survey table. The corresponding questions contained in the survey are stored in the SurveyQuestion table. All possible answers (i.e., six multiple choice answers) for each survey question are stored in the SurveyAnswerKey table.

10 The cabin file server database **493** provides storage for application state information. This is useful in cases where there is an interruption of aircraft power while the application is running. Storing this information in the database **493** allows the system to resume operation where it left off. There may be over 100 processes running at any given time. Each process can store as much information as needed in the *Data* field of the PowerRecovery table in order for the process to know where it should continue once
15 power is resumed. The *Data* field is defined as a Binary Large Object (BLOB).

The state (e.g., start, pause, stop, init) of the IFE system **100** is stored in the *IFE_State* field of the Aircraft table. Products and/or services ordered by the passenger **117** are stored in the Order_ table (as well as at the seat display unit **122a** for backup). This
20 enables the IFE system **100** to start from where it left off once passenger entertainment and interactive services are resumed.

The cabin file server database **493** provides storage for Video Announcement information. This information may include attributes such as video announcement titles, overhead audio, overhead video, and whether in-seat displays **122** are
25 overridden. Video Announcement information is stored in the following tables: VA_Distribution, VideoMedium, VideoSegment, VideoPlayer, and VideoUse.

Video Announcement information is stored in the VideoMedium table. Examples include boarding announcements, safety announcements, short subject programs, etc. Each Video Announcement has more specific information stored in the VideoSegment
30 table.

Attributes for each Video Announcement are stored in the VA_Distribution table. Attributes include, but are not limited to: if the announcement is heard on the overhead audio and in which zone (*OverheadAudioMap* field, where each bit in the field represents a zone), if the announcement is viewed on the overhead video and in which zone (*OverheadVideoMap* field, where each bit in the field represents a zone), if the announcement (audio and video) overrides whatever is currently being viewed at the seat (*InseatOverrideMap* field, where each bit in the field represents a zone), or be available for in-seat viewing (default) and in which zone.

Video Announcements (audio and video) are available for in-seat viewing (default). This means that the passenger **117** has the option to select the video channel on which the video announcement is being played. Video Announcements can also be set to override in-seat viewing. In this case, the IFE system **100** causes the overridden in-seat displays in a specified zone to select the video channel on which the video announcement is being played, and the passenger **117** is unable to turn off the in-seat video display **122**.

Each Video Announcement is assigned to a particular source (i.e., video player) through the VideoUse table. Attributes for each video player are stored in the VideoPlayer table. The default volume level for the PA speakers is stored in the *DefaultPA_AudioLevel* field of the Aircraft table. The volume level for the PA speakers can be different for each zone. This is stored in the *AudioLevel* field in the PA_Volume table.

Overhead monitors **162** can be assigned to a video source (i.e., video player **227**) for video announcements. This information is stored in the *OverheadAudioMap* and *OverheadVideoMap* fields of the VA_Distribution table.

The cabin file server database **493** provides storage for global attribute information (i.e., information that can be accessed by any service). Examples may include the current state of the IFE system **100**, the base currency, and the default PA audio. IFE system global attribute information is stored in the following tables: Aircraft, Airline, Airport, Country, Flight, and Route.

The following flight information is pre-loaded and stored in the Route table, one record per known route:

Field	Description
<i>FlightNumber</i>	flight number assigned to this flight leg
<i>FlightDuration</i>	estimated flight duration in minutes
<i>DepartureAirport</i>	departure airport code
<i>ArrivalAirport</i>	arrival airport code
<i>RouteType</i>	route type to determine which services are available on this route

When the flight attendant enters a *FlightNumber* and *RouteType* at the primary access terminal **225**, the corresponding flight information (i.e., *FlightDuration*, *ArrivalAirport*, and *DepartureAirport*) is found in the Route table and presented at the primary access terminal **225** and stored in the current record of the Flight table. The *DepartureDate* and *DepartureTime* are determined based on when the weight-off-wheels signal is received. This date and time is then stored in the *WeightOffWheelTime* field of the Flight table to calculate movie cycle and other sales times.

The following IFE data is configurable in order to tailor the IFE functionality for a particular airline. This tailoring is done using the *IFE Tools* software.

- 10 (a) IFE function data configuration ID: *Version* field of the DB_Version table.
- (b) For each video game: (1) The cost of each video game is specified in the *UnitPrice* field of the Price table. This cost can be altered based on the *PolicyDescription* field of the Policy table. A video game can be offered for free in a given zone by setting the associated bit in the *FreeMap* field of the Price table to 1. (2) The type of video game is stored in the *GameType* field of the GameDetail table. (3) The activation date is stored in the *EffectivityDate* field of the GameDetail table.
- 15
- (c) For each movie: (1) The cost of each movie is specified in the *UnitPrice* field of the Price table. This cost can be altered based on the *PolicyDescription* field of the Policy table. A movie can be offered for free in a given zone by setting the associated bit in the *FreeMap* field of the Price table to one. (2) The length of each movie is stored in the *SegmentRunTime* field of the VideoSegment table. (3) The activation date is stored in the *EffectivityDate* field of the VideoUse table.
- 20

- (d) For each aircraft seat class zone: whether video games and movies are pay or free is addressed in items (b) and (c) above.
- (e) For each aircraft seat class zone: which passenger survey is available.
- (f) Logical seat groups (e.g., general service zones, duty free zones) are specified in the
5 Member and Set_ tables. Seat numbers are stored in the *Member* field of the Member table. Zones are stored in the *SetType* field of the Set_ table.
- (g) For each route type: Titles to appear in the video game menu, audio menu, and movie menu of the seat display unit **122a**. Titles to appear in the video game menu can be limited according to route type. The titles are stored in the *Title* field of the
10 GameDetail table. The route type is stored in the *RouteType* field of the GameDetail table. Titles to appear in the audio menu can be limited according to route type. The titles are stored in the *AudioTitle* field of the AudioDetail table. The route type is stored in the *RouteType* field of the AudioDetail table. Titles to appear in the movie menu can be limited according to route type. The titles are stored in the *MediaTitle* field of the
15 VideoMedium table. The route type is stored in the *RouteType* field of the VideoUse table.
- (h) Currency exchange rates are stored in the *ExchangeRate* field of the Exchange table.
- (i) The primary access terminal display currency is stored in the *PAT_DisplayCurrency* field of the Aircraft table.
- 20 (j) For each flight number: Arrival/departure city pairs, flight duration and route type. Each flight number is associated with a specific route. The route is specified by the *FlightNumber* and *Leg* fields of the Route table. The arrival/departure city pairs for a given route is respectively stored in the *ArrivalAirport* and *DepartureAirport* fields of the Route table. The scheduled flight duration for a given route is stored in the
25 *FlightDuration* field of the Route table. The calculated flight duration (e.g., based on tail wind, etc.) for a given route is stored in the *FlightDuration* field of the Flight table. The route type of a given route is stored in the *RouteType* field of the Route table.
- (k) Movie cycle attributes are specified in the *Cabin File Server Executive Extensions Software Design Document*.

- (l) Video announcement titles are stored in the *MediaTitle* field of the VideoMedium table. Video announcement lengths are stored in the *SegmentRunTime* field of the VideoSegment table.
- (m) The video announcement cabin speaker default volume is stored in the
5 *DefaultPA_AudioLevel* field in the Aircraft table. This volume cannot be changed during a flight. During database initialization, a record for the PA_Volume table is created for every PA zone (as specified by the LRU table). The *AudioLevel* field in each record of the PA_Volume table is initialized to the *DefaultPA_AudioLevel*. The video announcement cabin speaker default volume can then be modified for each PA zone (e.g., passengers in
10 the PA zone over the engine may need a louder default volume). The new volume is stored in the *AudioLevel* field of the PA_Volume table.
- (n) The video reproducer **227** assigned to a particular video announcement is stored in the *PlayerName* field of the VideoUse table. The video reproducer **229** assigned to a particular movie is stored in the *PlayerName* field of the VideoUse table.
- 15 (o) Product pricing data is stored in the *UnitPrice* field of the Price table. Product effectivity data is stored in the *EffectivityDate* of the ProductEffectivity table.
- (p) Accepted credit card types (i.e., VISA, DISCOVER, etc.) are stored in the *CardName* field of the ValidCardData table. Accepted charge limits are stored in the *CreditLimit* field of the ValidCardData table. This charge limit is defined by the airline.
- 20 (q) The airline name is stored in the *AirlineName* field of the Airline table.
- (r) The number of movies in a particular package is stored in the *MovieQuantity* field of the PackageDetail table. The hours of game play is stored in the *GameQuantity* field of the PackageDetail table. Additional package details (e.g., which games/movies are in the package) are also stored in the PackageDetail table.
- 25 The primary access terminal **225** must perform certain coordinating functions prior to being able to operate with the cabin file server **268** successfully. A System Initializer establishes the cabin file server hard drives as shared devices with the primary access terminal **225**, synchronizes its system date and time with the date and time of the cabin file server **268**, and turns on the LCD's backlight so the user can see what's going

on. The System Initializer, INITSYS.EXE, performs these functions at boot time. This program includes the source file INITSYS.CPP.

Primary access terminal Stand Alone Utilities are PAT-resident utilities that are needed between runtimes (i.e., between flights). They are used by Service Personnel to manage data and system behavior.

A Data Offloader is provided so that specific data is offloaded from the aircraft 111 for the purpose of revenue collection and system performance evaluation. At the end of each flight, the NT event logs are archived on the cabin file server hard disk. Passenger Statistics information, passenger survey results, and Transaction records are stored in the cabin file server database 493 for later retrieval.

This database information is stored for up to forty flight legs. The number of flight legs is stored in the *FlightID* field of the Flight table. *FlightID* is simply a counter which is incremented after each flight. The Data Offload approach discussed previously describes the Data Archival, Data Offload and Disk Space Management processes.

The following paragraphs describe the additional functionality associated with the Data Offload process, in the utility OLUTIL.EXE.

The flight number for a test flight always begins with a "9". This enables a custom trigger, FLIGHT_ITRIG.SQL, to purge just test flight data (i.e., flights beginning with a "9") from the database at the beginning of a subsequent flight. The purge is automatically performed at the beginning of the next flight rather than at the end of the test flight so that the information can remain in the database long enough to offload the data for trouble-shooting purposes but not so long that credit card data may be compromised. However, if the Data Offload process is manually initiated at the end of the test flight, then the test flight data is purged at this time.

Archived data (i.e., previous flight leg) can be off-loaded on a per-flight basis. All credit card transaction data is encrypted using PKZIP.EXE (an industry-standard third-party file-compression utility). PKZIP was chosen because it provides excellent file compression ratios and allows for password encryption of the compressed data.

At the start of each flight, the *Offload* field in the Flight table for the specific flight is initialized to one. Once a particular flight has been off-loaded, the *Offload* field in the

Flight table is set to zero (i.e., flight data is tagged). It is possible to automatically specify the off-load of all non-tagged data (i.e., all flights with Offload field set to one). It is also possible to manually specify the off-load of data for a specific flight.

5 An operator is able to disable the Watchdog driver **410**. DISWDOG.EXE is used to disable the hardware Watchdog by issuing an IOCTL *Disable* command to the Watchdog Driver **410**.

Cabin file server Runtime Utilities **425** are programs that are used once per flight, either at the beginning or at the end. As a result, they are part of the application and are maintained along with the cabin file server Executive Extensions.

10 SDU_BLDR.EXE, the seat display unit database builder, is used to develop a download file to be downloaded to all seats **117**. The download file is comprised of product and entertainment information that is subject to change based on the contents of the cabin file server database **493**.

15 When flight information is entered by the Flight Attendants at the primary access terminal **225**, the SDU_BLDR on the cabin file server **268** is initiated. The GUI **426** calls SDU Builder via the CAPI to extract the information from the cabin file server database **493** that is pertinent to the current flight. This information is used to create the download file (sdu_data.dnl) that is sent to each seat **123** on the aircraft **111**.

20 The purpose of sdu_data.dnl is to provide current information (i.e., entertainment, pricing, etc.) from the database **493** to the passenger seats **123**. The creation of the download file triggers the Seat NAU to notify each seat that a new download file exists. Each seat then requests the file and applies the portion of the download file that is applicable to their programming (i.e., first class seats don't read the information in the download file applicable to coach seats **123**).

25 CFSLOGS.EXE is the main C++ executable associated with the archival of the event logs. It runs on the cabin file server **268** and is initiated during the data archive process. Cfslogs.exe is responsible for dumping the NT event logs of the cabin file server **268** to the hard disk using a unique archive file name. This file name is passed to cfslogs.exe as an input parameter.

DUMP_POS.EXE is the main C++ executable associated with offloading Point of Sales data. It runs on the cabin file server **268** and is initiated during the data offload process. Dump_pos.exe is responsible for writing the archived database information for a given flight to the various FLTSALES.CSV files on the hard disk. The flight ID is
5 passed to dump_pos.exe as an input parameter.

PARCHIVE.EXE is the main C++ executable associated with the purging of archive data. It runs on the cabin file server **268** and is initiated as part of the effort to manage the disk space on the cabin file server **268**. Parchive.exe is responsible for deleting both the Archive file and the Offload file from the hard drive. Both of these files are passed
10 to parchive.exe as input parameters.

DUMPSTAT.EXE is the main C++ executable associated with offloading Passenger Statistic data. It runs on the cabin file server **268** and is initiated during the data offload process. Dumpstat.exe is responsible for writing the archived database information for a given flight to the paxstats.csv files on the hard disk. The flight ID is
15 passed to dumpstat.exe as an input parameter.

Common Software Libraries

The following common software libraries of functions and utilities are used throughout the primary access terminal and cabin file server applications.

20 The Database Utilities, DBUTILS.CPP are commonly used by all database applications. They use the SQL commands (recognizable as starting with *db...()*, such as *dbexit()*, *dbresults()*, etc.):

Function	Purpose
<i>CheckResults()</i>	Continuously loops calling <i>dbresults()</i> to get the results of the prior SQL call for this process until they have all been obtained. If there are errors, it displays function text for tracing.
<i>UpdateStats()</i>	Updates the statistics of the given table for the given process.
<i>FailureExit()</i>	Standard exit function, displays the error before calling <i>dbexit()</i> .

Function	Purpose
-----------------	----------------

TransactionLogControl()

SelectIntoControl()

The event logging functions, EVENTLOG.CPP, RETRYSYS.CPP, are used exclusively in SYSMON.EXE and POWERDOWN.EXE. They each call EventLog's *ProblemReport()* subroutine (which is recursive!) which calls *EventLog::WriteHAILog()* which eventually
5 uses NT's *ReportEvent()* to record the information.

The set SQL Error and Message Handlers, HANDLERS.CPP includes two routines used by functions such as ARCHIVE.CPP CREATEDB.CPP DUMP_POS.CPP, INITDB.CPP and SUD_BLD.R.CPP to handle SQL informational and error messages: *err_handler()* and *msg_handler()*. These functions are identified to the SQL code using
10 *dberrhandle(err_handler)* and *dbmsghandle(msg_handler)* respectively.

Function	Purpose
-----------------	----------------

int err_handler(
input DBPROCESS *dbproc,
input int severity,
input int dberr,
input int oserr,
input char *dberrstr;
input char *oserrstr)

Builds a DB-LIBRARY error message containing both a database error (dberr and dberrstr) and an operating system error (oserr and oserrstr), echoes it to stdout and (if oserr is not DBNOERR) uses *UtilityClass::LogEvent()* to put this info into the event log. See *UtilityClass::LogEvent()* for severity definition.

Returns INT_EXIT if the database process pointer dbproc is no good. Otherwise, INT_CANCEL.

int msg_handler(
input DBPROCESS *dbproc
input DBINT msgno,
input int msgstate
input int severity,
input char *msgtext)

If the severity is greater than zero, it logs it to the event log, otherwise it simply builds and displays the message. It always returns ZERO.

Queues include QUEUE.CPP and QPAIR.CPP. A Queue is a dynamic list of pointers to elements of any type which must wait for sequential processing such as an output

queue. The actual elements are not stored in the Queue. A QPair is a set of two Queues used for related purposes, for example one for Input and one for Output associated with a named pipe pair or a serial port.

5 This class is used to create and maintain all Queues in the Control Center software to buffer message traffic. The first or top or head position of the queue is identified as element number zero (0).

Queues made with this class are considered to be "thread safe". That is, multiple threads can access these queues concurrently. These queues generate a signal when data is written to them. One can choose whether the queue should signal with only an event handle or with a semaphore as well. This class allows one to create and control the size of (or number of elements in) your queue, move elements in and out of the queue, and allow multiple users or readers to manipulate a single queue.

10

The following member functions are used to create and control the size of (or number of elements in) the queues.

Queue class Function	Purpose
The Constructors: <i>Queue()</i> , <i>Queue (ULONG Size)</i>	Initialize the queue. If no Size (or if Size = 0) is given, then the Queue is not delimited and can grow to the capacity of the system (defined by constant LONG_MAX). If Size is given, the queue is limited to contain no more than Size elements by having all <i>Put</i> functions display "Queue Overflow" to <i>stdout</i> and returning TRUE when an attempt is made to exceed the limit.
short <i>GetCount()</i>	Returns the number of elements currently in the queue.
ULONG <i>GetSize()</i>	Returns the preset maximum size of the queue. If the value returned is zero, the size is not delimited.
bool <i>SetSize</i> (ULONG Size)	Allows one to increase the maximum size of the queue. Returns FALSE if Queue was already defined as undelimited or if the new size is less than the previous size.

15

The Selective Style member functions are used when the priority of the queue elements is controlled.

Queue class Function	Purpose
void * <i>GetNth</i> (long N)	Removes and returns the Nth element from the queue. Returns NULL if the Nth element does not exist. If the queue is already locked, it waits for permission to access the queue. Therefore, it is important to <i>lock()</i> the queue prior to determining the Nth element (with <i>PeekNth()</i> , for example) and then retrieving it with <i>GetNth()</i> .
void * <i>PeekNth</i> (long N)	Returns the contents of the Nth element of the list but doesn't remove it from the queue. If none, returns NULL.
bool <i>PutNth</i> (void *Element, long N)	Inserts the Element's pointer into the queue at position N. If N+1 is greater than the current number of elements on the queue, then the Element's pointer is placed at the end of the queue instead of at N. Returns FALSE if.

The FIFO Style member functions are used when a First-In-First-Out FIFO style queue is desired.

Queue class Function	Purpose
void * <i>Get</i> ()	Returns the element at the top of the list. If none, returns NULL. Same as <i>GetNth(0)</i> .
void * <i>Peek</i> ()	Returns the contents of the element at the top of the list, but doesn't remove it from the queue. If none, returns NULL. Same as <i>PeekNth(0)</i> .
bool <i>Put</i> (void *Element)	Places the Element's pointer at the end of the queue. Same as <i>PutNth(Element, -1)</i> . Returns FALSE if
bool <i>PutHead</i> (void *Element)	Places Element's pointer at the head or top of the queue. Same as <i>PutNth(Element, 0)</i> . Returns FALSE if

Allow multiple users or readers to manipulate a single queue.

Queue class Function	Purpose
----------------------	---------

Queue class Function	Purpose
Constructor: <i>Queue</i> (ULONG Size, bool useSemaphore = TRUE)	Set useSemaphore = TRUE if the queue is going to be referenced by more than one 'reader' or thread. Otherwise, set it to FALSE or don't supply it. When set to TRUE, the constructor calls CreateSemaphore to establish the semaphore handle, and assigns a Resource Count equal to the Size , which means that if you specify a queue of 10, at most 10 threads can access it at once.
const HANDLE <i>getEventHandle()</i>	Returns the signal handle for use primarily with <i>WaitForSingleObject()</i> to halt a thread until something is placed in the queue.
const HANDLE <i>getSemaphoreHandle()</i>	Returns the semaphore handle for use primarily with <i>WaitForSingleObject()</i> to halt a thread until something is placed in the queue. Use only when useSemaphore is TRUE in constructor.
void <i>Lock()</i>	Locks the queue so other 'readers' can't alter its contents. If the queue is already locked (in use), this call waits until it is no longer locked. The Queue member functions each perform a lock and unlock when they update the queue, but there are times when you need to perform several queue functions while keeping total control of the queue. In this case, use the <i>Lock()</i> function.
void <i>Unlock()</i>	Releases control of the queue so others can add or remove elements. Use only if you previously used <i>Lock()</i> to isolate queue access.

The short class Queue Pairs maintains a set of two queues that are related. Typically one is used for Input and one is used for Output. Their names, however, are Lefty and Righty.

Queue class Function	Purpose
The Constructors: <i>Qpair</i> (ULONG Size, bool bUseSemaphore), <i>Qpair</i> (ULONG Size)	These constructors simply construct the two Queues, Lefty and Righty.
Queue& <i>Left</i> ()	Returns a pointer to Queue Lefty.
Queue& <i>Right</i> ()	Returns a pointer to Queue Righty.

The *RpcClientClass*, *RPCCLNTC.CPP* contains all of the functionality needed for an application to communicate with the Fileserver RPC Server via the Cabin Application Programming Interface (CAPI). To use it, the *Create()* call should be executed. Then a
5 call to *GetContextHandle()* provides the I/O handle for communications.

<i>RpcClientClass</i> class Function	Purpose
bool <i>Create</i> ()	Creates and initializes an RPC Interface channel between an application and the RPC Server process using <i>RpcNsBindingImportBegin()</i> . Returns TRUE if successful, FALSE otherwise.
bool <i>Delete</i> ()	Terminates the RPC Session with the server process. Returns TRUE if successful, FALSE otherwise.
bool <i>GetContextHandle</i> (output PCONTEXT_HANDLE_TYPE pphContext)	Retrieves a database context handle from the server process via an RPC channel previously opened using <i>Create()</i> . Calls the <i>Capi_c.c InitializeInterface()</i> function to connect to RPC. Returns FALSE if none.
bool <i>ReleaseContextHandle</i> (output PCONTEXT_HANDLE_TYPE phContext)	Returns a database context handle which was previously obtained by a call to <i>GetContextHandle()</i> . Returns FALSE if none.

The System Monitor Interface, SYSMNTR.CPP is a set of routines that is used by any process that is under the control of SYSMON.EXE for shutdown purposes. This Constructors class has three constructors available for use: *SysmonInterfaceClass()* is not used, *SysmonInterfaceClass(ParentProcess_id, EventHandle)*,

5 *SysmonInterfaceClass(ParentProcess_id, MessageQueue)*
SysmonInterfaceClass(ParentProcess_id).

ParentProcess_id is used to identify the process in all communications with SysMon (see *WriteToSysMon()*). The other parameters are used to control the method of shutdown for the given process. If the process prefers to hear about it using an event, 10 it can pass the EventHandle to be used when shutdown is needed. If the process prefers to hear about it via a message queue, it can pass the Queue ID in.

Each Initialization process must first create a SysmonInterfaceClass object and then register communications with Sysmon using *SysmonInterfaceClass::Register()*. This calls *ConnectSystemMonitor()* to create handles to two Named Pipes (input and output) 15 to use to talk to the System Monitor. It then creates an IFE_Message and sends it to Sysmon via *WriteToSysMon()*. Finally, *Register()* launches two threads to manage the named pipes with *CreateSystemMonitorThreads()*.

CreateSystemMonitorThreads() launches two communication threads who in turn call the actual I/O function: *InputThreadInterface()* calls *ReadFromSysMon()*, 20 *OutputThreadInterface()* calls *HeartBeatSysMon()*. *ReadFromSysMon()* continuously reads from Sysmon, calling *ProcessRequest()* when any message is received.

HeartBeatSysMon() continuously issues a pulse message to Sysmon, to let it know that this process is alive.

WriteToSysMon() is used to send any message to the System Monitor via the output 25 named pipe. It uses *IFE_Message::PutData()* to do it.

Anytime a message is received in *ReadFromSysMon()*, *ProcessRequest()* is called. This simply parses out any ProcessStop message and calls *Shutdown()* to continue. All other messages are ignored.

Shutdown() cares about how this class was constructed. If an event handle was given, 30 it sets this event to announce the shutdown to the host process. If a message queue

was given, it forwards the ProcessStop message to the queue so the host can shutdown in a more orderly fashion. If neither of these was given, it halts the process with a *ProcessExit()*.

- 5 A Timer Utilities file, TMDCLLCB.CPP, contains a class *timedCallback* that is used to schedule activity in regular intervals. The user first creates a function to be called when a 'timeout' occurs by declaring it as *long (*timedCallbackFun) (timedCallback *Entry)*; This function must return the number of ticks to wait until the next call should be invoked, or Zero to stop the re-queueing.

Public *timedCallback* Functions

Purpose

<i>timedCallback()</i>	Constructs a callback using a default 'do-nothing' function. This allows one to create arrays of <i>timedCallback</i> objects and define the callback function later by use of member <i>setFun()</i> .
<i>timedCallback</i> (input <i>timedCallbackFun</i> SomeFun)	Constructs a real-time clock callback to be used for later calls to <i>queue()</i> and <i>cancel()</i> . SomeFun is the user-defined function to call when a timeout occurs.
<i>~timedCallback()</i>	Cancels the callback before it goes out of scope.
void <i>cancel()</i>	Cancels 'this' callback if it is queued, but retains the object for subsequent queueing.
int <i>isQueued()</i>	Returns 1 if 'this' callback is queued, 0 otherwise.
void <i>queue</i> (input long Delta)	Queues the callback to be called after the specified number of invocations of <i>tick()</i> . Delta == 0 cancels the callback. <i>Queue()</i> is automatically called each time the user's <i>timedCallbackFunction</i> is invoked.
	<i>queue()</i> can be used to change the interval of an already queued callback.
void <i>setFun</i> (input <i>timedCallbackFun</i> SomeFun)	Redefines the callback function to be used for 'this' callback as what's contained in SomeFun.

Public timedCallback Functions

Purpose

static void
tick()

Advances the time by one tick. As a result, queued callbacks may time-out and are then invoked from within *tick()*. Normally not used externally, this is maintained by the timer thread that was launched by the constructor.

The General Utilities include UTLTYCLS.CPP. The UtilityClass Class provides a general interface to the following generic utility functions. Many of these functions are declared as STATIC, which means that you can use them without creating an object of UtilityClass, just by calling them with the class name in front, such as

5 *UtilityClass::bin2Ascii(0x2f, &Hi, &Lo).*

UtilityClass Public Function

Purpose

static void
bin2Ascii

Converts a binary hex value into a two byte ASCII character representation.

(input unsigned char Hex,
output unsigned char*Hi,
output unsigned char*Lo)

e.g., Hex = 0x2F, *Hi = '2' *Lo = 'F'.

unsigned char
BuildNetworkAddress

Receives a character buffer of input data and creates a network address, returning it as an unsigned character. DeviceHandler defines whether the data is from ARCNET or RS-422. The length of the address is returned. If ZERO, no address was made.

(input unsigned char *cpBuffer,
output unsigned char
*cpNetworkAddress,
input DeviceHandlerType DeviceHandler)

bool
ConnectNetworkResource

Connects the WINDOWS NT Network Resource specified by RemoteName to the drive specified by LocalName. Returns FALSE if any errors are encountered and connect fails.

(input char *LocalName,
input char *RemoteName)

static unsigned short
ConvertAsciiToBin

Takes 2 ASCII characters and returns them as unsigned binary.
e.g., by ASCII = "2F", returns 0x2F.

(input unsigned char*byAscii)

static unsigned char
ConvertAsciiToBin

Takes a single ASCII char and returns a single unsigned binary char.
e.g., AsciiChar = 'F', returns 0x0F.

(unsigned char AsciiChar)

UtilityClass Public Function

static bool
CreateIfeldConversionMap()

static bool
CreateIfefuncConversionMap()

bool
GetFirstRegistryValue

(input char *pszKeyName,
output char *pszValueName,
input LPDWORD dwValueNameLen,
output LPDWORD lpdwType,
output LPBYTE lpbData,
output LPDWORD lpcbData)

bool
GetNextRegistryValue

(output char *pszValueName,
output LPDWORD dwValueNameLen,
output LPDWORD lpdwType,
output LPBYTE lpbData,
output LPDWORD lpcbData)

bool
GetRegistryDWord

(input char *lpszKeyName,
input char *lpszValueName,
output DWORD *lpdwValue)

bool
GetRegistryInfo

(output CStringArray *RegValueArray)

Purpose

Initializes the IfeldMap data structure. For each entry in the Ifeld Type definition, a corresponding text string is written to the map. This data structure is used in conversions between process enumeration values and text values. Always returns TRUE.

Initializes the IfefuncMap data structure. For each entry in the Ifefunction Type definition, a corresponding text string is written to the map. This data structure is used in conversions between process enumeration values and text values. Always returns TRUE.

Retrieves the name and data associated with the first value contained in the NT Registry that matches the registry keyname. Returns FALSE if unsuccessful.

After calling *GetFirstRegistryValue()*, this function can be called to retrieve subsequent registry value names and data. Returns FALSE if unsuccessful.

Retrieves a DWORD value from the Registry into lpdwValue. Returns FALSE if unsuccessful.

Retrieves all registry information by iterating through the registry key values, returning it in an array of strings. Returns FALSE if unsuccessful.

UtilityClass Public Function

Purpose

bool

GetRegistryString

(input char *lpszValueName,
output LPBYTE lpbData,
output LPDWORD lpcbData)

Retrieves a string in lpbData corresponding to the input parameter ValueName.
Returns FALSE if unsuccessful.

static bool

IfeFuncToText

(input IfeFunctionType nIfeFunction,
output PGENERIC_TEXT pszIfeFuncText)

Converts the IFE Function Message identifier contained in the nIfeFunction input argument into a text string representing the same enumeration name.
Returns FALSE if unsuccessful.

static bool

IfeIdToText

(input IfeIdType nIfeId,
output PGENERIC_TEXT pszIfeIdText)

Converts the IFE Process/Thread identifier contained in the nIfeId input argument into a text string representing the same enumeration name.
Returns FALSE if unsuccessful.

static IfeFunctionType

IfeTextToFunc

(input PGENERIC_TEXT pszIfeFuncText)

Returns the corresponding Enumeration value for the Text String contained in pszIfeIdText from the IfeFunctionType Type definition.
If none, returns NoDestination.

static IfeIdType

IfeTextToId

(input PGENERIC_TEXT pszIfeIdText)

Returns the corresponding Enumeration value for the Text String contained in pszIfeIdText from the IfeIdType Type definition.
If none, returns NoDestination.

static void

LogEvent

(input IfeIdType nProcessId,
input WORD wCategory,
input DWORD dwErrorCode,
input char *pszFormat, input ...)

This is the call-level interface to the WINDOWS NT event log. This takes the passed variables and develops a series of strings using *printf(pszFormat, arg, arg, arg)* style, then forwards the developed string to *ReportEvent()*.

bool

SetRegistryConfigValue

(input char *ModuleName,
input REGCONFIGINFO *ConfigInfo)

This function is used by a process to register its Unit Id, Part Number, and Revision number to the WINDOWS NT Registry.
Returns FALSE if any errors are encountered.

UtilityClass Public Function	Purpose
bool <i>SetRegistryString</i> (input char *lpszKeyName, input char *lpszValueName, input char *szString)	Writes specified value and string data into specified registry key under HKEY_LOCAL_MACHINE. Returns FALSE if any errors are encountered.

The Discrete Library, DISCRETE.LIB, contains the UTILITY.LIB Library plus the following. The WinRTUtilClass class contains simple utilities for use with WinRT drivers:

WinRTUtilClass Functions	Purpose
void <i>BuildWinRTDeviceName</i> (output LPSTR szDeviceName, input LPSTR szDeviceNumber)	Returns the full WinRT device name from a null-terminated device number.
DWORD <i>GetWinRTDeviceNumber</i> (input LPSTR szDriverName, output PCHAR szDeviceNumber, input LPDWORD lpdwDeviceNumberBufSize)	Uses null-terminated DriverName to look-up WinRT device number string in the registry. Returns the value returned by its called <i>RegQueryValueEx()</i> function.

- 5 DSCRTDRV.RT replaces DSCRTDRV.CPP and is the name of the Discrete Driver code. It is fed into the WinRT Preprocessor to create DISCRETE.CPP, which is compiled into the DISCRETE.LIB library. The DiscreteDriverClass controls the system discrettes, which are used to control peripherals such as LED indicators.

DiscreteDriverClass Public Function	Purpose
void <i>CloseDiscrettes()</i>	Closes the Discrete WinRT device if it is open.
UCHAR <i>GetId()</i>	Returns the Enumerated LRU ID. If 0, LRU ID has not yet been obtained. May be called after <i>ReadId()</i> .

DiscreteDriverClass Public Function

Purpose

bool
GetLCDbacklight()

Returns the state of the LCD backlight (on or off).

bool
GetLED

Returns the state of the specified LED.

(LED_TYPE LEDchoice)

bool
GetVTRDiscrete

Returns the state of the specified VTR discrete.

(VTR_DISCRETE_TYPE
VTRdiscreteChoice)

bool
IsPAT()

May be called after *ReadId()*.

Returns TRUE if this LRU is a PAT, FALSE if this LRU is a CFS.

DWORD
OpenDiscretes()

Opens the Discrete WinRT device.

DWORD
ReadId()

Reads discrete input I/O port to obtain this LRU id and stores it in the form: 0110fijk where f=1 if CFS, f=0 if PAT; ijk is the LRU id 000-111 (0-7). In this form the byte may be used as an ARCNET address.

If successful, ERROR_SUCCESS is returned.

UCHAR
ReadInputDiscretes()

Returns a byte representing the state of the input discretes.

UCHAR
ReadOutputDiscretes()

Returns a byte representing the state of the output discretes.

bool
SetLCDbacklight

Turns the LCD backlight on or off. Returns the state of the backlight prior to this function call.

(bool bOnOff)

bool
SetLED

Turns the specified LED on or off. Returns the state of the LED prior to this function call.

(LED_TYPE LEDchoice,
bool bOnOff)

**DiscreteDriverClass Public
Function**

Purpose

bool
SetVTRDiscrete

Asserts or de-asserts the specified VTR discrete. Returns the state of the discrete before this function call.

(VTR_DISCRETE_TYPE
VTRdiscreteChoice,
bool bOnOff)

UCHAR *WriteOutputDiscretas*

Sets the output discretas according to the specified mask. Returns the state of the output discretas before they were changed by this function.

(UCHAR ucOutputMask)

A message library MESSAGE.LIB provides the means of moving data from one place and format to another without needing detailed understanding of the protocols involved.

In general, all messages transmitted within the control center are of the type

- 5 IFE_Message. Therefore, a class called IFE_Message is used to translate information into and out of this message type. Similarly, many messages enter the control center from the ARCNET devices, so to support them the ARCNET_Message Class is made. Instead of requiring the user to start with an ARCNET_Message and convert it to an IFE_Message, the ARCNET_Message is a superset of IFE_Message. In this way, the
- 10 ARCNET_Message contains the additional functions to manage the translations, and the migration from one form to another is nearly transparent.

For example, when raw data is read into MP.EXE from ARCNET, it is put into a new ARCNET_Message object and passed to *MessageToPipeProcessor()* that treats this message as an IFE_Message to send it to the appropriate NAU. The NAU uses its own

- 15 flavor of IFE_Message (*Seat_Message*, for example) to read the data (via its own *NAUGetMP()*) and from that point forward, the IFE_message is treated more specifically. No special handling is needed to affect this change. By the time the message finally reaches its ultimate destination process, the message class functions are used to deal with the actual bytes of the messages. These functions are described below.

- 20 The IFE_Message class IFMESSAGE.CPP is the base class for all IFE message processing. A hierarchy exists such that each derived class implements specifics for its data processing. This makes translating data formats transparent to application programmers.

IFE_Message Public Function

Purpose

IFE_Message

This constructor prefills the local *IfeMessageData* with the raw *pIfeMessageData*.

(IFE_MESSAGE_DATA
*pIfeMessageData)

virtual void
GetAddress

Returns the Address data, (e.g., "SDU 001A"), from the Address member found in the *IfeMessageData*.

(char *pAddress)

bool
GetData

Initializes the *IfeMessageData* structure of an *IFE_Message* object with data from the Queue. The address of an *IfeMessageData* structure is read from the specified queue, the data is copied into the *IFE_Message* class. The *IfeMessageData* structure read from the input queue is then Deleted. Returns FALSE if fails to get data.

(Queue *pInputQueue)

bool
GetData

Does a *ReadFile()* on the specified handle and uses the data read to populate the *IfeMessageData* structure contained in this instance of the *IFE_Message* class. Returns FALSE if fails to get data from Pipe.

(HANDLE hInPipe,
ULONG *pBytesRead)

virtual IfeIdType
GetDestination()

Returns the Destination data found in the *IfeMessageData* data member.

IfeFunctionType
GetIfeFunction()

Returns the *IfeFunction* element of the *IFE_MESSAGE_DATA* structure associated with this *IFE_Message*.

void
GetLruInfo

Returns the LRU information from the *IFE_Message*.

(char *pLruInfo)

bool
GetLruType

Copies the data contained in the *LRUType* field of the *IfeMessageData* structure contained in this *IFE_Message* into the location specified by the input argument *pszLruType*. Returns FALSE if *pszLruType* is a null pointer.

(char *pszLruType)

IFE_Message Public Function

Purpose

void
GetMessageData

Copies the data field of this IFE_Message object into the pData argument. The number of bytes copied is written to the wDataLen argument.

(BYTE *pData,
WORD *wDataLen)

virtual long
GetMessageLength()

Returns the MessageLength data member value.

CString
GetNetworkAddress()

Retrieves the network address from the raw data buffer of an IFE_Message. GetNetworkAddress determines the location of address information in the Raw Data buffer based on the destination ID. Address information is converted from Binary to ASCII if necessary then placed into a CString which is returned to the calling function.

virtual IfeIdType
GetSource()

Returns the Source data found in the IfeMessageData data member.

UnsolicitedMessageType
GetUnsolicitedMessage()

Returns the value contained in the UnsolicitedMessage field of this IFE_Message object.

void
Log(int nMessageDirection,
IfeIdType nProcessId,
char *pszDataFormat)

Formats a text string containing pertinent message information and writes it to standard output.

MessageDirection can be set to LogInpMsg or any other value to indicate whether the log should say 'Received' or 'Transmitted', respectively. ProcessId is simply added to the Log string along with the IFE_Message data. The DataFormat is used to determine which fields are used. If null, only the Process Id, Function, Destination Id, Source Id and Address are output to stdout. Otherwise the actual message data also prints.

bool
PutData

(Queue *pOutputQueue)

Allocates sufficient memory to hold a copy of the IfeMessageData structure associated with a message. The IfeMessageData is copied from the Class data area to the newly allocated memory. The pointer to the copied data is then placed on the specified queue. Returns FALSE if fails to create a new IFE_Message object.

IFE_Message Public Function

Purpose

bool
PutData

(HANDLE hOutPipe,
ULONG *pBytesWritten)

Copies the contents of the IfeMessageData class variable to the pipe specified by hOutPipe. The number of bytes actually written to the pipe are returned in the pBytesWritten argument. Returns FALSE if fails to output to the pipe.

virtual void
SetAddress

Updates the IfeMessageData Address data field with pAddress info.

(char *pAddress)

virtual void
SetDestination

Updates the Destination field in the IfeMessageData data member.

(IfeldType DestinationId)

void
SetIfeFunction

Copies the IfeFunctionType input argument into the IfeFunction element of the IFE_MESSAGE_DATA structure associated with this IFE_Message.

(IfeFunctionType nIfeFunction)

void
SetLruInfo

Saves information about the host LRU.

(char *pLruInfo)

bool
SetLruType

Fills the LRUType field in the IfeMessageData structure for this IFE_Message with the data contained in the input argument pszLruType. Returns FALSE if input LruType is too big to store.

(char *pszLruType)

void
SetMessageData

Copies the specified data block to the MessageData field of this IFE_Message object.

(BYTE *pData,
WORD wDataLen)

void
SetMessageLength

Sets the MessageLength local data member to Length.

(long Length)

IFE_Message Public Function

Purpose

void
SetNetworkAddress
(CString csNetworkAddress)

Converts the Network Address in csNetworkAddress as necessary and writes the resulting data to the Raw Message Data buffer. The type of conversion required as well as the location of data in the Raw Message data buffer is determined by the identifier of the process that sent the message (i.e., Message Source Id).

virtual void
SetSource
(IfeIdType SourceId)

Updates the Source field found in the IfeMessageData data member with SourceId.

void
SetUnsolicitedMessage
(UnsolicitedMessageType Message)

Sets the UnsolicitedMessage field for this IFE_Message object with the value contained in Message.

The ARCNET_Message class ARCNTMSS.CPP is a derived class from IFE_Message. It is used to carry and process ARCNET data from the Message Processor to an appropriate Network Addressable Unit (e.g., Seat NAU, Backbone NAU). It is used as a base class to any ARCNET devices, such as the Seat_Message, PESCA_Message, and PESCV_Message classes.

Some of the virtual functions defined in IFE_Message have been overridden within ARCNET_Message.

ARCNET_Message Class Public Functions

Purpose

ARCNET_Message(
IFE_MESSAGE_DATA
*pIfeMessageData)

This constructor fills the IfeMessageData data member with the message data structure.

ARCNET_Message(
BYTE *pMessageData,
CMapStringToPtr& LookUpTable)

This constructor takes what must be a valid message and parses it to fill the local structure.

ARCNET_Message Class Public Functions

bool
BuildArcnetMessage(
CMapStringToPtr& LookUpTable,
char *pLRUName,
BYTE *pOutBuf)

BYTE
GetCommand()

IfeldType
GetDestination(
CMapStringToPtr LookUpTable,
char *pAddress)

IfeFunctionType
GetIfeFunction()

long
GetMessageLength(
BYTE *pMessageData)

bool
IsTestPrimitive(
BYTE byTestPrimitive)

bool
PutData(
HANDLE hOutPipe,
ULONG *pBytesWritten)

Purpose

This method builds the MessageData into an ARCNET message. The first two bytes of the output message buffer are set to the length of the message (as read from the MessageLength field of the IfeMessageData structure. The remainder of the output buffer is populated with the raw ARCNET data from the MessageData field of the IfeMessageData structure.

Returns FALSE if failure.

Returns the value of the Command Byte in the ARCNET MessageData.

Extracts the Destination bytes from the ARCNET MessageData, attempts to map the raw data and returns the Enumerated IfeldType and Mapping address.

Returns NoDestination if none found.

Returns the IfeFunction data member.

Processes the raw ARCNET data to determine the message length, update the local data member and return the value.

Determines whether or not this IFE_Message is a test primitive by comparing the command byte with the constant TP_COMMAND. A value of TRUE is returned if the command byte equals TP_COMMAND.

A value of FALSE is returned otherwise.

Overloaded ARCNET *PutData*() method. Completes the Message Header and calls the IFE_Message function.

Returns FALSE if write to OutPipe fails.

ARCNET_Message Class Public Functions

Purpose

bool
PutData(
Queue *pOutputQueue)

Overloaded ARCNET *PutData()* method. Completes the Message Header and calls the IFE_Message function.

Returns FALSE if no data was found to put into Queue.

bool
SetAddress(
CMapStringToPtr LookUpTable,
char *pAddress)

This method is an override of the IFE_Message *SetAddress()*. It takes in a mapping table and an Address. The address is looked-up in the mapping table and if a match is found the Address data member is updated.

Returns FALSE if unsuccessful.

void
SetCommand(
BYTE Command)

This method takes a Command Byte and update the MessageData member.

void
SetDestination(
IfeldType DestinationId)

Simply calls the same IFE_Message function to set the Destination data member.

void
SetDestination(
BYTE *pDestinationNetworkAddress)

Parses the DestinationNetworkAddress for the IFE_Message Destination.

bool
SetDestination(
CMapStringToPtr& LookUpTable,
char *pAddress)

Looks up the pAddress in the specified LookUpTable to determine the corresponding Destination and stores it in the IFE_Message Destination member. Returns FALSE if lookup fails.

void
SetIfeFunction(
IfeFunctionType Function)

Updates the IFE Function with the given value.

bool
SetSource(
CMapStringToPtr LookUpTable,
char *pAddress)

Cross-references the Address, (e.g., 'SDU 01A') in the LookUpTable. If a match, updates the Source bytes of MessageData with corresponding value.

Returns FALSE if failure.

void
SetSource(
BYTE *pSourceNetworkAddress)

This method takes the BYTE parameter and update the MessageData data member for source.

The following are virtual functions that may be used in classes derived from this class:

ARCNET_Message Class Virtual Functions	Purpose
virtual void <i>CompleteMessageHeader()</i>	To finish up the message for shipment. Base version simply calls <i>SetMessageLength()</i> .
virtual void <i>GetAddress</i> (char *pAddress)	Base version simply calls the IFE_Message version.
virtual IfeldType <i>GetDestination()</i>	Base version simply calls the IFE_Message version.
virtual IfeldType <i>GetSource()</i>	Base version simply calls the IFE_Message version.
virtual void <i>SetAddress</i> (char *pAddress)	Base version simply calls the IFE_Message version.
virtual void <i>SetDestination</i> (IfeldType DestinationId)	Base version simply calls the IFE_Message version.
virtual void <i>SetMessageLength()</i>	Handles ARCNET messages that do not have sub-functions (i.e., 1F messages). Base version does nothing.
virtual void <i>SetSource</i> (IfeldType SourceId)	Base version simply calls the IFE_Message version.

- ARCNET Simulation class ARCSMCLS.CPP contains similar functions to the runtime
- 5 ARCNET_Message class, except that instead of communicating with the actual ARCNET Driver, this simulates data I/O for test purposes.

PESC-A_Message class PSCMSSGE.CPP is derived from the ARCNET_Message class to implement the functions needed to support the PESC-A devices.

PESC-A_Message Function	Purpose
bool	Returns indication of whether landing gear is

PESC-A_Message Function

Purpose

IsGearDown()

down and locked.

bool

IsGearCompressed()

Returns indication as to whether landing gear is compressed (weight on wheels).

PESCV_Message class PSCVMSSG.CPP is derived from the ARCNET_Message class to implement the functions necessary to format and transmit interface messages between the Cabin Control Center and the PESC-V **224b**.

PESC-V_Message Function

Purpose

void

WriteVideoControlData

(BYTE *byData)

Initializes the data portion of this PESCV_Message with all information necessary for a Video Control Message (0xE9). byData must contain the Video Control Data bytes.

- 5 The Seat_Message class SETMSSGE.CPP is derived from the ARCNET_Message class to process Seat data between the Seat NAU and the Services. Methods and data relating to all seat sessioning and sales services, along with some cabin services, are provided.

Seat_Message Function

Purpose

void

CompleteMessageHeader()

Finishes up the message for shipment, adds message length, et. al.

BYTE

GetApplicationId()

Retrieves the Application ID from the IFE_Message data.

double

GetCashTotal()

Retrieves the Cash Total from the IFE_Message data.

BYTE

GetCommandId()

Returns the Command ID found in the IFE_Message data.

BYTE

GetControlIdentifier()

Returns the Control Identifier found in the IFE_Message data.

void

GetCreditCardAccountNumber

Retrieves the Credit Card Data from the IFE_Message data.

(BYTE *pCreditCardAccount)

Seat_Message Function

Purpose

void
GetCreditCardCustomerName

(char *pCustomerName)

Retrieves the Credit Card Customer Name from the IFE_Message data.

void
GetCreditCardExpirationDate

(BYTE *pExpirationData)

Retrieves the Credit Card Expiration Date from the IFE_Message data.

double
GetCreditTotal()

Retrieves the Credit Total from IFE_Message data and returns it as a floating point value.

short
GetFlags()

Retrieves the Flags from the IFE_Message data.

void
GetFlightAttendantId

(char *pAttendantId)

Retrieves the Flight Attendant Id from the IFE_Message data.

BYTE
GetMessageId()

Returns the Message ID found in the IFE_Message data.

ID
GetOrderId()

Returns the Order ID from the IFE_Message data.

void
GetProductCode

Returns the Product Code from the IFE_Message data.

(char *pProductCode)

long
GetProductMap()

Returns the Product Map from the IFE_Message data.

BYTE
GetQuantity()

Returns the Quantity from the IFE_Message data.

BYTE
GetRetryCount()

Returns the Retry Count from the IFE_Message data.

void
GetSeat(
char *pSeat)

Returns the Seat from the IFE_Message data.

Seat_Message Function

void
GetSeatTransferData

(CString &csSeat1,
CString &csSeat2)

WORD
GetSequenceNumber()

BYTE
GetSessionStatus()

BYTE
GetTransactionStatus()

BYTE
GetUpdateType()

void
InitializeSeat()

void
SetAddress(
char *pAddress)

void
SetCashTotal

(double Amount)

void
SetControllIdentifier

(BYTE ID)

void
SetCPMSFlags

(BYTE byFlags)

void
SetCreditCardAccountNumber

(BYTE *pCreditCardAccount)

Purpose

Transfers the seat identifiers from the data area of this IFE_Message object into the two output arguments.

Returns the value of the Sequence Number data member.

Retrieves the session status from the message

Retrieves the Transaction Status from the IFE message.

Retrieves the Update Type from the IFE message.

Initializes the LengthMap array with seat Ids once per flight.

Copies the Address info into the IFE_Message data member.

Copies the Amount into the IFE_Message data.

Copies the ID info into the IFE_Message data.

Writes the value contained in byFlags to the Flags location in the CPMS Status message.

Copies the CreditCardAccount data into the IFE_Message data.

Seat_Message Function

Purpose

void
SetCreditCardCustomerName

Copies the CustomerName data into the IFE_Message data.

(char *pCustomerName)

void
SetCreditCardExpirationDate

Copies the ExpirationDate data into the IFE_Message data.

(BYTE *pExpirationDate)

void
SetCreditTotal

Formats as a dollar amount and copies Amount into the IFE_Message data.

(double Amount)

void
SetDBBuildId(
WORD wBuildId)

Writes the value in wBuildId to the Database Build ID field position in the IFE_Message data.

void
SetElapsedTime

Formats elapsed time 0 - 999 into IFE_Message data. Values greater than 999 are reduced to 999.

(TIME tmElapsed)

void
SetHSDLQueueStatus

Copies the High Speed Download Queue Status into the IFE_Message data.

(BYTE *pHSDLQueueStatus)

void
SetIfeState(
BYTE IfeState)

Copies the IFE State value into the IFE_Message data.

void
SetMessageId

Copies the Message Id into the IFE_Message data.

(BYTE MessageId)

void
SetMessageLength()

Sets the length of the IFE_Message data based on the raw data message length.

void
SetMessagesProcessed

Copies the MessagesProcessed into the IFE_Message data.

(short MessagesProcessed)

Seat_Message Function

Purpose

void
SetMovieCycleId

Copies the MovieCycleId into the IFE_Message data.

(BYTE MovieCycleId)

void
SetMovieCycleStatus

Copies the MovieCycleStatus into the IFE_Message data.

(BYTE MovieCycleStatus)

void
SetMovieNumber

Copies the MovieNumber into the IFE_Message data.

(BYTE MovieNumber)

void
SetNewVideoChannelNumber

Copies the ChannelNumber into the IFE_Message data.

(BYTE ChannelNumber)

void
SetNewVideoRecordNumber

Copies the RecordNumber into the IFE_Message data using LanguageId to pad the text field appropriately.

(BYTE RecordNumber,
BYTE LanguageId)

void
SetOrderId

Copies the OrderId into the IFE_Message data.

(ID OrderId)

void
SetProductCode

Copies the ProductCode into the IFE_Message data.

(char *pProductCode)

void
SetProductMap

Copies the ProductMap into the IFE_Message data.

(long ProductMap)

void
SetQuantity

Copies the Quantity into the IFE_Message data.

(BYTE Quantity)

Seat_Message Function

Purpose

void
SetQueuePosition

Copies the QueuePosition into the IFE_Message data.

(short QueuePosition)

void
SetSeatTransferData

Copies the seats identified by the two input arguments into the IFE_Message data.

(CString &csSeat1,
CString &csSeat2)

void
SetSEBMessagingOff()

Sets IFE_Message data to SEB-Messaging Off.

void
SetSEBMessagingOn()

Sets IFE_Message data to SEB-Messaging On.

void
SetSEBMessageSeatAddress

Copies SeatAddress into the IFE_Message data.

(char *SeatAddress)

void
SetSequenceNumber

Copies SequenceNumber into the IFE_Message data.

(WORD SequenceNumber)

void
SetSessionStatus

Copies the SessionStatus into the IFE_Message data.

(BYTE SessionStatus)

void
SetSIBacklightCmd

Sets the Message ID to SI_BACKLIGHT_CTL and the first data byte 1 (ON) or 0 (OFF) based on bBacklightOn.

(bool bBacklightOn)

void
SetStoreStatus

Copies StoreStatus into the IFE_Message data.

(BYTE *StoreStatus)

void
SetTimeLeftOnCurrentCycle

Copies tmRemaining into the IFE_Message data.

(TIME tmRemaining)

Seat_Message Function	Purpose
void <i>SetTimeUntilNextShowing</i> (TIME tmNextShow)	Copies tmNextShow into the IFE_Message data.
void <i>SetTransactionStatus</i> (BYTE TransactionStatus)	Copies TransactionStatus into the IFE_Message data.
void <i>SetUpdateType</i> (BYTE UpdateType)	Copies UpdateType into the IFE_Message data.

The TestPort_Message class TSTPRTMS.CPP is derived from ARCNET_Message to communicate with the test port of the file server.

TestPort_Message Class Function	Purpose
void <i>GetBiteResults</i> (DWORD *pdwErrorCode, DWORD *pdwTestID, DWORD *pdwWitnessType, DWORD *pdwSuspectType, DWORD *pdwSuspectID, DWORD *pdwTSData, DWORD *pdwErrorClear)	Extracts data from an BIT_BITE_STATUS (op_status) and returns it to the calling function for inclusion in the Application event log.
void <i>GetRawSourceAddress</i> (BYTE *pszSrcAddrs)	Extracts the source address field from the IFE_Message data and copies it into pszSrcAddrs.
BYTE <i>GetSubCommand()</i>	Returns the SubCommand byte from the IFE_Message data.
bool <i>SetRevInfo</i> (BYTE *pbyRevInfo)	Parses the text contained in the pszRevInfo string and formats the data into the IFE_Message data.

void <i>SetSubCommand</i> (BYTE command)	Sets the SubCommand byte in the IFE_Message data with command.
--	---

StandardProtocol class STNDRDPR.CPP is derived from the IFE_Message class and is the base class that supports the Hughes standard *start-stop* protocol as described in the, which is used in communications with PATMessage class, PIMessage class,

5 PATSEBMessage class.

StandardProtocol Class Functions	Purpose
bool <i>Decode()</i>	Decode data from Hughes standard start-stop data into just plain data. Returns FALSE if decoding failed.
void <i>Encode()</i>	Encodes the data into the Hughes standard start-stop format.
BYTE <i>GetCommand()</i>	Returns the Command Byte from the IFE_Message data.
bool GetData (HANDLE hInPipe, ULONG *pBytesRead)	Reads data from the hInPipe into the IFE_Message data. Returns the number of bytes read in pBytesRead. Returns FALSE if read failed.
bool GetData (Queue *pInputQueue)	Reads and encodes the data from the InputQueue into the IFE_Message data. Returns FALSE if no data or if pointer is NULL.
BYTE <i>GetLengthOfCommand()</i>	Returns the Command Length from IFE_Message data.
bool <i>IsValidCommand()</i>	Returns FALSE if Command in IFE_Message is not recognized as one of the Standard Protocol commands.
bool <i>PutData</i> (HANDLE hOutPipe, ULONG *pBytesWritten)	Outputs encoded data from IFE_Message data to the OutPipe, reporting the number of BytesWritten. Returns FALSE if failed the written.

StandardProtocol Class Functions	Purpose
bool <i>PutData</i> (Queue *pOutputQueue)	Decodes the data from the IFE_Message data and puts it on the OutputQueue. Returns FALSE if message could not be decoded.
void <i>SetLength()</i>	Sets the Message Length and Destination Address of the IFE_Message.

The PATMessage PATMSSGE.CPP is derived from StandardProtocol to support communication with the primary access terminal's **225** PI board.

PATMessage Function	Purpose
void <i>ConvertCardDataToASCIIFormat</i> (unsigned char *pCardData, long lCardDataLength)	Converts binary format card data in pCardData to ASCII format in IFE_Message data. Requires CardDataLength to set the length of the IFE_Message data field.
void <i>ConvertPrinterStatusToASCII</i> (long lPrinterStatus)	Converts PrinterStatus to ASCII format and stores in IFE message data.
void <i>DerivedDecode()</i>	Stub.
void <i>DerivedEncode()</i>	Stub.
void <i>GetAudioChannel</i> (BYTE *LeftTimeSlot, BYTE *RightTimeSlot)	Stub.
long <i>GetCardDataBinaryFormat</i> (unsigned char *pCardData)	Copies magcard data (MagCardReadData Command is first byte) in the original binary format into pCardData. Size of user-supplied buffer should be MAXMESSAGEDATASIZE. Returns adjusted message length. Returns 0 if unable to copy data.

PATMessage Function

BYTE
GetControlByte()

BYTE
GetDestinationDevice()

BYTE
GetSourceDevice()

void
GetVideoPreviewChannel

(BYTE *Channel,
BYTE *AudioSel)

void
GetVideoPreviewSource

(char *Source)

void
SetAddress

(char *Address)

void
SetAudioChannel

(BYTE LeftTimeSlot,
BYTE RightTimeSlot)

void
SetAudioVolume

(BYTE LeftVolume,
BYTE RightVolume)

void
SetCardData(
unsigned char *pCardData)

void
SetDestinationDevice

(BYTE byDstDeviceAddr)

Purpose

Returns the control byte from the IFE_Message data.

Returns address of destination device from IFE_Message data.

Returns address of source device from IFE_Message data.

Returns the Preview Channel info from the IFE_Message data into Channel and AudioSel.

Stub.

Simply calls the IFE_Message version.

Develops the Audio Channel info in the IFE_Message data based on the LeftTimeSlot and RightTimeSlot values.

Develops the Audio Volume info in the IFE_Message data based on the LeftVolume and RightVolume values.

Sets up request to PI to dump the most recent magcard buffer into CardData.

Sets address of destination device in IFE_Message data to byDstDeviceAddr.

PATMessage Function	Purpose
void <i>SetSourceDevice</i> (BYTE bySrcDeviceAddr)	Set address of source device in IFE_Message data to bySrcDeviceAddr.
void <i>SetVideoPreviewChannel</i> (BYTE Channel, BYTE AudioSel)	Copies the Channel and AudioSel data into IFE_Message data.
void <i>SetVideoPreviewSource</i> (har *Source)	Stub.

The PIMessage class PIMSSAGE.CPP is derived from the StandardProtocol class to handle the specifics of the primary access terminal's **225** PI board.

PIMessage Class Function	Purpose
void <i>DerivedDecode()</i>	Massages the data in IFE_Message data for local usage.
void <i>DerivedEncode()</i>	Massages the data in IFE_Message data for output to the PI board.
BYTE <i>fooGetCommand()</i>	For testing only.
BYTE <i>fooGetLengthOfCommand()</i>	For testing only.
bool <i>fooIsValidCommand()</i>	For testing only.
bool <i>GetCardData</i> (unsigned char *CardData)	Stub. Always returns FALSE. See PATMessage for this functionality.

PIMessage Class Function

Purpose

bool
GetCurrentChannelResponse

(BYTE *Channel,
BYTE *AudioSel)

If the current command was a Channel Request, this returns the Channel and AudioSel.
Otherwise returns FALSE.

BYTE
GetMsgCommandByte()

Returns the Command Byte from last PIMessage.

bool
GetPartAndRevisionData

(BYTE *PartAndRevision)

If current command was a Part&Revision command, copies the data from IFE_Message data into PartAndRevision.
Otherwise returns FALSE.

bool
GetStatusResponse

(BYTE *Response)

If current command was a Status Request command, copies the data from IFE_Message data into Response.
Otherwise returns FALSE.

bool
GetVideoPreviewVCP

(char *VCPName)

If current command was a Video Preview VCP command, returns the current VCP assigned to Video Preview screen, persisted by PIInterface VLRU into VCPName.
Otherwise returns FALSE.

bool
IsCardReaderCommand()

Returns TRUE only if the current Command is one from the card reader.

bool
IsTunerCommand()

Returns TRUE only if the current Command is one from or for the Tuner.

bool
IsUnsolicited()

Stub. Always returns FALSE.

void
PartAndRevisionRequest()

Builds a Part&Revision Request into the IFE_Message data.

void
PutCardData

Stub. See PATMessage for this functionality.

(unsigned char *CardData)

void
RequestCurrentChannel()

Builds a Current Channel Request into the IFE_Message data.

void
SetAck(
BYTE byCmdToBeAcked)

Builds an Ack-by-Current-Command into the IFE_Message data.

PIMessage Class Function	Purpose
void <i>SetMsgCommandByte</i> (BYTE byMsgCmd)	Copies byMsgCmd into the Message Command Byte class member data.
void <i>SetNak</i> (BYTE byCmdToBeNaked)	Builds a NAK-by-Current-Command into the IFE_Message data.
void <i>SetVideoPreviewToVCP</i> (char *VCPName)	Stub.
void <i>SoftwareReset</i> ()	Builds a Software Reset Command into the IFE_Message data.
void <i>StatusRequest</i> ()	Builds a Status Request Command into the IFE_Message data.
void <i>SwitchTunerType</i> (BYTE TunerType)	Builds a Switch Tuner Type Command into the IFE_Message data.
void <i>TuneChannel</i> (BYTE Channel, BYTE AudioSel)	Builds a Tune Channel Command into the IFE_Message data using Channel and AudioSel as part of the command.

The PATSEBMessage class PTSBMSSG.CPP is derived from StandardProtocol but currently none of its functions are implemented. Therefore, it behaves exactly like StandardProtocol.

PATSEBMessage Class Function	Purpose
void <i>DerivedDecode</i> ()	Stub.
void <i>DerivedEncode</i> ()	Stub.
BYTE <i>GetLengthOfCommand</i> ()	Stub. Returns Zero.

PATSEBMessage Class Function	Purpose
<code>bool IsValidCommand()</code>	If Command is recognized by <i>GetLengthOfCommand()</i> , returns TRUE. Currently returns FALSE.

The Serial_Message SRLMSSGE.CPP is derived from IFE_Message. It is used to carry and process Serial data from the Message Processor to any serial I/O devices NAU. Currently, it is the base class for VCP_Message. The pure virtual functions defined in IFE Message is implemented within Serial Message.

Serial_Message Function	Purpose
<code>bool GetData (HANDLE hInPipe, ULONG *pBytesRead)</code>	Local version reads data into IFE_Message data from InPipe, returning the number of BytesRead. Returns FALSE if no data read from InPipe.
<code>bool GetData (IfeIdType idSource, IfeIdType idDestination, BYTE *pData, DWORD dwDataLen)</code>	Local version fills IFE_Message data structures with data contained in input arguments. Always returns TRUE.
<code>bool GetData (Queue *pInputQueue)</code>	Simply calls the IFE_Message version.
<code>bool PutData (BYTE *byData, DWORD *pDataLen)</code>	Local version copies the data and length elements from an IFE_Message to the specified arguments. Always returns TRUE.
<code>bool PutData (HANDLE hOutPipe, ULONG *pBytesWritten)</code>	Simply calls the IFE_Message version.
<code>bool PutData(Queue *pOutputQueue)</code>	Simply calls the IFE_Message version.

The VCP_Message class VCPMSSGE.CPP is derived from Serial_Message (which is derived from IFE_Message) to communicate with the Video Players. It is used between the Message Processor and the VCP NAU.

VCP_Message Class Function	Purpose
void <i>Format</i>	Stub.
(VCPMessageFormat nMessageFormat)	
CString <i>GetAddress()</i>	Overrides the one in the IFE_Message base class. Returns the contents of the IFE_Message data Address field in a CString.
void <i>GetCommandData</i>	
(PLAYERCOMMANDS *pPlayerCommand, BYTE *byData, int *pDataLen)	If a valid VCP PlayerCommand, parses out the Command Bytes from the IFE_Message data, returning it in byData. Returns the number of bytes in DataLen, Zero if invalid command.
CString <i>GetLruInfo()</i>	Overrides the one in the IFE_Message class. This version creates a CString from the data contained in the LruInfo field of the IfeMessageData structure and returns it to the function.
void <i>GetPlayerResponse</i>	Stub
(PlayerCommands *pPlayerCommand, PLAYERSTATE *pPlayerState, BYTE *pData, BYTE *pDataLen)	
void <i>GetResponseData</i>	
IfeFunctionType *pResponseCommand, BYTE *byData, int *pDataLen)	Parses data from IFE_Message data into byData, returning the DataLen size of the data. Returns responses Ack or Nak in ResponseCommand.
PLAYERSTATE <i>GetState()</i>	Returns the enumerated state of the VCP (e.g., Playing, FastForward, etc.)

VCP_Message Class Function

Purpose

void
GetStateInfo

Retrieves state information from this IFE Message object. Assumes that state information was writing using the SetStateInfo member function.

(PLAYERSTATE *pState,
DWORD *pTime)

bool
IsValidChecksum()

Returns FALSE if checksum test.

void
SetAddress

Overrides SetAddress in IFE_Message base class. Address field of the IfeMessageData structure for this message is populated using the CString input argument.

(CString csAddress)

void
SetChecksum()

Calculates and writes a checksum to the IFE Message. Then stores the full length of the message in the MessageLength field of the message.

void
SetLruInfo(
CString csLruInfo)

Overrides the function in the IFE_Message base class. This version copies the csLruInfo data to the LruInfo field of IFE_Message data.

void
SetPlayerCommand

Converts enumerated internal PlayerCommand into the actual command byte to go to the VCP. Returns any associated data from IFE_Message data into byData and returns its length in DataLen.

(PlayerCommands nPlayerCommand,
BYTE *byData,
BYTE byDataLen)

void
SetStateInfo

Writes VCP State and Time information to the IFE Message data. State information is retrieved using *GetStateInfo()*.

(PLAYERSTATE nState,
DWORD dwTime)

void
SetUnitId

Writes the UnitId into the IFE Message data.

(PGENERIC_TEXT pszUnitId)

Thus, systems, methods and articles of manufacture have been disclosed that provide for a networked passenger entertainment system that integrates audio, video, passenger information, product ordering and service processing, communications, and

maintainability features, and permits passengers to selectively order or request products and services, receive video, audio and game data for entertainment purposes, and communicate with other passengers and computers on- and off-board the aircraft, and which thereby provides for passenger selected delivery of content over a

5 communication network. It is to be understood that the above-described embodiments are merely illustrative of some of the many specific embodiments that represent applications of the principles of the present invention. Clearly, numerous and other arrangements can be readily devised by those skilled in the art without departing from the scope of the invention.

10

ABSTRACT

A system server is used to manage communication over a network between the system server and a plurality of physical devices of a passenger entertainment system. The system is configured and operated using software to provide passenger entertainment. The system server comprises software for instantiating a dispatch object to open a framework network addressable unit objects, for instantiating one or more virtual line replaceable unit objects to manage communication between a network address unit and physical devices, and for communicating network messages through the dispatch object to the physical devices. The dispatch object tracks messages to the physical devices utilizing a queue and tracks messages from the physical devices utilizing a queue. The dispatch object maintains the status of related devices. The dispatch object also adds and removes one or more of the virtual line replaceable units. The network addressable unit objects move data from one storage location to another.